



Liebert® CCD25 and CCD35

User Manual (Original Instructions)

50/60 Hz, Condenser

The information contained in this document is subject to change without notice and may not be suitable for all applications. While every precaution has been taken to ensure the accuracy and completeness of this document, Vertiv assumes no responsibility and disclaims all liability for damages result from use of this information or for any errors or omissions.

Refer to local regulations and building codes relating to the application, installation, and operation of this product. The consulting engineer, installer, and/or end user is responsible for compliance with all applicable laws and regulations relation to the application, installation, and operation of this product.

The products covered by this instruction manual are manufactured and/or sold by Vertiv. This document is the property of Vertiv and contains confidential and proprietary information owned by Vertiv. Any copying, use, or disclosure of it without the written permission of Vertiv is strictly prohibited.

Names of companies and products are trademarks or registered trademarks of the respective companies. Any questions regarding usage of trademark names should be directed to the original manufacturer.

Technical Support Site

If you encounter any installation or operational issues with your product, check the pertinent section of this manual to see if the issue can be resolved by following outlined procedures.

Visit <https://www.vertiv.com/en-us/support/> for additional assistance.

TABLE OF CONTENTS

1 Important Safety Instructions	1
1.1 Conformity to EU Directives	1
2 Nomenclature and Components	3
2.1 Model Number Nomenclature	3
2.2 Main Components	4
2.2.1 Fan	4
2.2.2 Heat Exchanger	4
2.2.3 Low Ambient Kit	4
2.3 Accessories	6
2.4 Dimensions and Weights	6
2.5 Operation Environment	6
2.6 Storage Environment	7
3 Pre-installation Preparation	9
3.1 Moving the Unit	10
3.2 Unpacking the Unit	10
4 Installation	11
4.1 Installation Notes	11
4.2 Installing the Unit	11
4.2.1 Vertical Airflow Installation	11
4.2.2 Horizontal Airflow Installation	16
4.3 Installing the Low Ambient Kit	20
4.4 Connecting Pipelines	21
4.5 Connecting Power Cables and Communications Cable	21
4.5.1 Connecting Power Cable for Condenser	22
4.5.2 Connecting Power Cable for the Low Ambient Kit	27
4.5.3 Connecting Communications Cable for Condenser	29
4.6 Charging Refrigerant and Adding Lubricating Oil	30
5 Maintenance and Troubleshooting	31
5.1 Maintenance	32
5.1.1 Refrigeration System	32
5.1.2 Heat Exchanger	32
5.1.3 Fan	32
5.2 Troubleshooting	33
Appendices	35
Appendix A: Technical Support and Contacts	35

This page intentionally left blank

1 Important Safety Instructions

NOTE: Prior to moving, installing, or servicing this unit, read the Safety Instructions sheet provided as a separate document shipped with the unit.

NOTE: The Vertiv™ Liebert® CRV CCD25 and CCD35 condensers are for outdoor use only.

1.1 Conformity to EU Directives

Fabbricante-Manufacturer-Hersteller-Fabricant-Fabricante

Fabricante- Tillverkare – Fabrikant – Valmistaja – Produsent

Fabrikant – Κατ ασκεναστ ηξ – Producent

Il Fabbricante dichiara che questo prodotto è conforme alle direttive Europea:

The Manufacturer here by declares that this product conforms to the European Union directives:

Der Hersteller erklärt hiermit, dass dieses Produkt den Anforderungen der europäischen Richtlinien gerecht wird:

Le Fabrican déclare que ce produit est conforme aux directives Européennes:

El Fabricante declara que este producto es conforme a las directivas Europeas:

O Fabricante declara que este produto está em conformidade com as directivas Europeias:

Tillverkare försäkrar härmed att denna produkt överensstämmer med Europeiska Uniones direktiv:

De Fabrikant verklaart dat dit product conform de Europese richtlijnen is:

Vaimistaja vakuuttaa täten, että tämä tuote täyttää seuraavien EU-direktiivien vaatimukset:

Produsent erklærer herved at dette produktet er i samsvar med EU-direktiver:

Fabrikant erklærer herved, at dette product opfylder kravene i EU direktiverne:

κατ ασΑευαστ ρj δηλνξιϋτ ιτ ο παΑϋν πΑοιϋν εβναι Αατ ασΑευαμϋνο αϋμ ωνα με τ ιj οδηγβεj τ ηj Ε.Ε.:

2006/42/EC

2014/30/EU

2014/35/EU

2014/68/EU

2011/65/EU with its amendment (EU) 2015/863

This page intentionally left blank

2 Nomenclature and Components

2.1 Model Number Nomenclature

Table 2.1 below and Table 2.2 below describe the model number for Vertiv™ Liebert® CRV CCD25 and CCD35 condensers.

Table 2.1 CCD25 Model Number Example

Model Number										
1	2	3	4	5	6	7	8	9	10	11
C	C	D	2	5	4	H	-	0	0	A

Table 2.2 CCD25 and CCD35 Model Number Digit Definitions

Digit	Variable	Description of Variable
1	CCD	Vertiv™ Liebert® CRV Condenser
2		
3		
4	25, 35	Model number
5		
6	4	400 V, 3-phase, 50/60 Hz, CE
7	H	High ambient temperature (-5 °C to 52 °C (23 °F to 125.6 °F))
8	-	Separator
9	0	R410A refrigerant
10	0, N	0 - Standard Environments
		N - Aggressive Environments (with nano coating)
11	A	Revision

2.2 Main Components

2.2.1 Fan

The EC axial fan uses low noise fan blades and a high performance three-phase motor.


2.2.2 Heat Exchanger

The finned tube heat exchanger provides high heat dissipating efficiency and is convenient for maintenance.

2.2.3 Low Ambient Kit

The low ambient kit consists of a receiver with four heater belts, a head pressure valve, a safety valve, a check valve, and a pressure switch. The kit is designed to maintain proper operating pressure in outdoor temperature down to -40°C (-40°F). The low ambient kit is an optional component and is field installed.

Figure 2.1 Diagram of Condenser with Low Ambient Kit



Item	Description	Item	Description
1	Condenser	7	Liquid pipe
2	Discharge pipe	8	Receiver
3	Refrigerant flow direction	9	Check valve
4	Outdoor environment	10	Head pressure valve
5	Indoor environment	11	Safety valve
6	Evaporator	12	Pressure switch

Receiver


The receiver stores refrigerant to help fulfill the needs for low temperature load in winter and high temperature load in summer. There are three connection ports in the receiver to connect refrigerant inlet pipe, refrigerant outlet pipe, and safety valve. Two sight glasses are also installed on the receiver to observe the refrigerant level in the receiver conveniently.

Head Pressure Valve

The head pressure valve is a three-way modulating valve that responds to discharge pressure. When the discharge pressure falls below a certain value, the discharge port is opened and the discharge gas bypasses the condenser. When the discharge pressure is high, the discharge port is closed and there is full liquid flow to the condenser.

During the soldering process, care must be taken not to overheat and damage the valve.

Figure 2.2 Structure Diagram of Head Pressure Valve



Item	Description
1	Connected with discharge pipe
2	Connected with condenser
3	Connected with receiver

Heater Belt

The receiver is equipped with four heater belts which consume a total power of 300 Watts. The heater belt is controlled by the pressure of refrigerant in the receiver. When the pressure is lower than 1.4 MPa (203.1 psig), the heater belt will start heating. When the pressure is higher than 1.9 MPa (275.6 psig), the heater belt will stop heating.

Pressure Switch

Pressure switch controls the heater belt. When the refrigerant pressure in the receiver is lower than 1.4 MPa (203.1 psig), the pressure switch will be closed and the heater belt will start working. When the refrigerant pressure in the receiver is higher than 1.9 MPa (275.6 psig), the pressure switch will be opened and the heater belt will stop working.

Check Valve

Check valve is installed between the head pressure valve and the receiver on the liquid line, to prevent the refrigerant from flowing back to the condenser. The arrow on the valve indicates the direction of the flow and it should point towards the receiver.

2.3 Accessories

The accessories provided with the condenser are listed in **Table 2.3** below .

Table 2.3 Accessories of the Condenser

Component	Quantity
Leg for condenser	4
M6 x 16 Phillips hex head screw	20
User manual	1
EU declaration of conformity	1

The accessories provided with the low ambient kit are listed in **Table 2.4** below .

Table 2.4 Accessories of the Low Ambient Kit

Component	Quantity
Cable gland	1
EU declaration of conformity	1

2.4 Dimensions and Weights

Table 2.5 Dimensions and Weights of Condenser

Condenser Model	Unit Dimensions (W x D x H) mm (in.) without legs, with fan	Shipping Dimensions (W x D x H) mm (in.)	Net Weight kg (lb)	Shipping Weight kg (lb)
CCD25	1562 x 830 x 1272 (61.5 x 32.7 x 50.1)	1651 x 916 x 1486 (65 x 36.1 x 58.5)	100 (220.5)	199 (438.7)
CCD35	2362 x 830 x 1272 (93 x 32.7 x 50.1)	2451 x 916 x 1486 (96.5 x 36.1 x 58.5)	125 (275.6)	250 (551.2)
Low ambient kit	1270 x 280 x 554 (50 x 11 x 21.8)	1356 x 666 x 430 (53.4 x 26.2 x 16.9)	34 (75.0)	62 (136.7)

2.5 Operation Environment

Table 2.6 Operation Environment

Item	Requirements
Installation position	The maximum equivalent pipe length between the indoor unit and the condenser is 120 m (393.7 ft). Vertical difference: -8 m (-26.2 ft) ≤ ΔH ≤ 30 m (98.4 ft)
Installation mode	Standard condenser: horizontal airflow installation and vertical airflow installation Condenser with low ambient kit: vertical airflow installation
Ambient temperature	Standard condenser: -20 °C to 48 °C (-4 °F to 118 °F) . Unit remains operational up to 52 °C (125.6 °F) with reduced capacity. Condenser with low ambient kit: -40°C to 48°C (-40 °F to 118 °F)

Table 2.6 Operation Environment (continued)

Item	Requirements
Ambient humidity	Outdoor: 5% RH to 95% RH
Operation power	AC 400V 3Ph+N+PE 50/60 Hz. The voltage tolerance is 10%.
Altitude	≤ 2000 m (6562 ft). Derating is required if the altitude exceeds 2000 m (6562 ft).
Protection level	IPX4
NOTE: The value of vertical difference is positive if the condenser is installed higher than the indoor unit; otherwise the value is negative. NOTE: If the altitude is higher than 2000 m (6562 ft), contact Vertiv representative.	

NOTE: When the condenser is used with a low ambient kit, the condenser must be installed in vertical airflow direction.

NOTE: Low pressure transducer failure or low discharge superheat alarms may occur during start-up at outdoor temperatures below -35°C (-31°F), but they will clear up automatically and the unit will operate normally.

2.6 Storage Environment

Table 2.7 Storage Environment

Item	Requirements
Storage environment	Store the unit in its original factory packaging, in a clean indoor environment with good ventilation and with no dust.
Ambient temperature	-40 °C to +70 °C (-40 °F to 158 °F)
Ambient humidity	5% RH to 95% RH
Storage time	The total storage time should not exceed 6 months. Otherwise, contact Vertiv representative to check that the unit is in good condition.

This page intentionally left blank

3 Pre-installation Preparation



WARNING! Risk of improper moving. Can cause serious injury or death. Building and equipment damage may also result. Use only lifting equipment that is rated for the unit weight by an OSHA-certified rating organization. The center of gravity varies depending on the unit size and selected options. The slings must be equally spaced on either side of the center of gravity indicator.



CAUTION: Risk of contact with sharp edges, splinters, and exposed fasteners. Can cause injury. Only properly trained and qualified personnel wearing appropriate, OSHA-approved PPE should attempt to move, lift, or remove packaging from the unit in preparation for unit installation.

NOTICE

Risk of improper lifting. Can cause equipment damage. Make sure that the spreader bars are wider than the unit. If the spreader bars are too short, the slings may crush the unit.

NOTICE

Risk of doorway/hallway interference. Can cause unit and/or structure damage. The unit may be too large to fit through a doorway or hallway while on the skid. Measure the unit and passageway dimensions, and refer to the installation plans prior to moving the unit to verify clearances.

NOTICE

Risk of improper storage. Can cause unit damage. Keep the unit upright, indoors and protected from dampness, freezing temperatures and contact damage.

Upon arrival of the unit and before unpacking:


- Verify that the labeled equipment matches the bill of lading.
- Carefully inspect all items for visible or concealed damage.
- Report damage immediately to the carrier and file a damage claim with a copy sent to Vertiv or to your sales representative.

3.1 Moving the Unit

It is recommended to use mechanical transport equipment such as forklift or crane when unloading and transferring the condenser closest to the installation site.

When a forklift is used, insert the tines of the forklift in the direction as shown in **Figure 3.1** below .

Figure 3.1 Inserting the Forklift in this Direction



3.2 Unpacking the Unit

Unpacking the Condenser

1. Pull straight the hooks on the top and side wooden panels using a claw hammer.
2. Remove the top and side wooden panels and foam from the condenser. Do not remove the protection cardboard of the fins until the condenser is in its installation position.

Unpacking the Low Ambient Kit

1. Pull straight the hooks on the top and side wooden panels using a claw hammer.
2. Remove the top and side wooden panels from the low ambient kit. Loosen the clamp that secures the kit to the bracket and then remove the kit.

4 Installation

4.1 Installation Notes

- Vertiv™ Liebert® CRV CRV CCD25 and CCD35 condensers are used with Vertiv™ Liebert® CRV CRD25 and CRD35 row-based cooling units. Read SL-70747 Vertiv™ Liebert® CRV CRD25 and CRD35 Row-Based Cooling Units User Manual before installing and using the CCD25 and CCD35 condensers.
- Do not install the unit in the environment with noise restrictions.
- Do not place the unit close to vapors, hot gases, and waste gases.
- Install the unit in a clean place and keep it away from dusts and foreign objects.
- When the ambient temperature is lower than -20 °C (-4 °F), the low ambient kit needs to be used. The low ambient kit can only be used on the outdoor unit that has been installed in vertically upward direction.


4.2 Installing the Unit

4.2.1 Vertical Airflow Installation

Mount the condenser on suitable support in accordance with local codes. Secure the stands to the mounting surface using a field supplied bolt in each of the two 12 mm (0.47 in.) holes in each stand.


NOTE: A 4000 mm (157.5 in.) clearance is required above the condenser air outlet.

Figure 4.1 CCD25 - Dimensions of Condenser for Vertical Airflow Installation




Item	Description mm (in.)	Item	Description mm (in.)
1	1562 (61.5)	4	906 (35.7)
2	1246 (49.1)	5	1272 (50.1)
3	454 (17.9)		

Figure 4.2 CCD35 - Dimensions of Condenser for Vertical Airflow Installation




Item	Description mm (in.)	Item	Description mm (in.)
1	2362 (93.0)	4	906 (35.7)
2	1246 (49.1)	5	1272 (50.1)
3	454 (17.9)		

Figure 4.3 CCD25 - Dimensions of Condenser Stand for Vertical Airflow Installation




Item	Description mm (in.)	Item	Description mm (in.)
1	1325.6 (52.2)	4	75 (3.0)
2	1120 (44.1)	5	75 (3.0)
3	Ob-round: 12 (0.47) x 20 (0.79)		

Figure 4.4 CCD35 - Dimensions of Condenser Stand for Vertical Airflow Installation




Item	Description mm (in.)	Item	Description mm (in.)
1	2126 (83.7)	4	75 (3.0)
2	1120 (44.1)	5	75 (3.0)
3	Ob-round: 12 (0.47) x 20 (0.79)		

Figure 4.5 CCD25 - Vertical Airflow Installation Space Requirements



Item	Description mm (in.)
1	Minimum: 915 (36)
2	Minimum: 1200 (47.2)

Figure 4.6 CCD35 - Vertical Airflow Installation Space Requirements




Item	Description mm (in.)
1	Minimum: 915 (36)
2	Minimum: 1200 (47.2)

4.2.2 Horizontal Airflow Installation


Mount the condenser on suitable other support in accordance with local codes. Secure the unit to the mounting surface using a field supplied bolt in each of the four 10 mm (0.39 in.) holes in sheet metal.

Figure 4.7 CCD25 - Dimensions of Condenser for Horizontal Airflow Installation




Item	Description mm (in.)	Item	Description mm (in.)
1	1562 (61.5)	3	1272 (50.1)
2	830 (32.7)		

Figure 4.8 CCD35 - Dimensions of Condenser for Horizontal Airflow Installation




Item	Description mm (in.)	Item	Description mm (in.)
1	2362 (93.0)	3	1272 (50.1)
2	830 (32.7)		

Figure 4.9 Horizontal Airflow Installation Space Requirements




Item	Description mm (in.)	Item	Description
1	Minimum: 600 (23.6)	3	The area of airflow passage should be equivalent to or larger than the area of the frontal surface.
2	Minimum: 600 (23.6)		

Figure 4.10 CCD25 - Dimensions of Mounting Base for Horizontal Airflow Installation




Item	Description mm (in.)	Item	Description mm (in.)
1	830 (32.7)	4	1440 (56.7)
2	428 (16.9)	5	Ob-round: 10 (0.39) x 16 (0.63)
3	178 (7.0)		

Figure 4.11 CCD35 - Dimensions of Mounting Base for Horizontal Airflow Installation



Item	Description mm (in.)	Item	Description mm (in.)
1	830 (32.6)	4	2236 (88)
2	428 (16.9)	5	Ob-round: 10 (0.39) x 16 (0.63)
3	178 (7)		

Figure 4.12 Multiple Outdoor Units Placed in Overlap Mode



Item	Description mm (in.)	Item	Description mm (in.)
1	4000 (157.5)	3	Airflow
2	600 (23.6)	4	Minimum height of the base: 50 (2.0)

NOTE: Use appropriate angle iron for bracket when two units are installed with one above the other. Use appropriate channel steel for bracket when three units are installed with one above another.

4.3 Installing the Low Ambient Kit


NOTE: Prior to welding off the cap on the inlet and outlet pipes of the condenser and the low ambient kit, release the nitrogen through one Schrader valve on the condenser and three Schrader valves on the low ambient kit.

NOTE: When welding the copper pipe with the inlet and outlet pipes of the condenser and the low ambient kit, wrap a piece of wet cloth around the Schrader valve near the welding position to prevent the valve core from being damaged from heat.

Perform the following steps to install the low ambient kit:

1. Before installing the low ambient kit, weld off the cap on the inlet and outlet pipes of the condenser and the low ambient kit.
2. On the condenser stands, , install two M6 x 30 screws on the upper holes at the same side of the electrical control box but do not tighten the screws.
3. Mount the low ambient kit on the screws. At this time, the pipe connectors of the low ambient kit and the condenser are coupled. Install the other two M6 x 30 screws on the lower holes and then tighten all four screws.
4. Weld the inlet connectors and the outlet connectors.

Figure 4.13 Installing the Low Ambient Kit (CCD25 as an Example)



4.4 Connecting Pipelines



WARNING! For systems requiring EU CE compliance, the system installer must provide and install a pressure relief valve in the high side refrigerant circuit that is rated same as the refrigerant high side “Max Allowable Pressure” rating that is marked on the unit serial tag. Do not install a shutoff valve between the compressor and the field installed relief valve. The pressure relief valve must be CE-certified to the EU Pressure Equipment Directive by an EU “Notified Body”. If the unit is installed with a low ambient kit, the pressure relief valve is not required.



CAUTION: Before cutting into low ambient kit or condenser factory piping, ensure that the nitrogen holding charge has been released.

NOTE: Isolate piping from building using vibration isolating supports. Prevent the dust, water vapor and solid particles from entering the copper pipes.

NOTE: All the joints of the refrigerating pipes must be silver-brazed.

NOTE: Use a flow of dry nitrogen through the piping during brazing to prevent formation of copper oxide scale inside the piping. When copper is heated in the presence of air, copper oxide forms. PVE oils will dissolve these oxides from inside the copper pipes and deposit them throughout the system, clogging filter driers and affecting other system components.

To identify pipe sizes, refer to *SL-70747 Vertiv™ Liebert® CRV CRD25 and CRD35 Row-Based Cooling System User Manual*.

To identify the installation height of the condenser, refer to *SL-70747 Vertiv™ Liebert® CRV CRD25 and CRD35 Row-Based Cooling System User Manual*.

4.5 Connecting Power Cables and Communications Cable



WARNING! Arc flash and electric shock hazard. Can cause serious injury or death. Disconnect all local and remote electric power supplies and wear appropriate, OSHA-approved personal protective equipment (PPE) per NFPA 70E before working within the electric control enclosure. Customer must provide earth ground to unit, per NEC, CEC and local codes, as applicable.



WARNING! Risk of improper wire sizing/rating and loose electrical connections causing overheated wire and electrical connection terminals resulting in smoke or fire. Can cause serious injury or death. Use correctly sized copper wire only and verify that all electrical connections are tight before turning power On. Check all electrical connections periodically and tighten as necessary.

NOTE: Install a manual electrical disconnect switch within 1.6 m (5 ft) of the condenser and in accordance with local codes.

NOTE: Wiring should be protected from touched heated surfaces like refrigeration piping and any heated surface to avoid damage to the wiring insulation.

NOTE: The power supply wiring of the unit should be installed by a professional licensed electrical contractor in accordance to local electrical codes.

NOTE: The power supply wires for the outdoor unit are L+N+PE. The recommended wire size for the power supply cable is no less than 16 AWG (1.5 mm²).


4.5.1 Connecting Power Cable for Condenser

Power is supplied to the condenser from the evaporator. Connect one end of the power supply cable to the outdoor breaker in the evaporator side, and the other end to the circuit breaker in condenser side.

Connecting power cable for condenser CCD25


1. In evaporator CRD25 (used with condenser CCD25), open its rear door and remove filters. The outdoor breaker is located under the electric control box 1.
2. Connect one end of the power cable to the L1, L2, L3, N, and PE terminals of the outdoor breaker.

Figure 4.14 Location of the Outdoor Breaker in Evaporator CRD25



3. In condenser CCD25, remove two M5 screws from its electric control box and remove the cover.
4. Connect the other end of the power cable to the L1, L2, L3, N, and PE terminals of the circuit breaker.

Figure 4.15 CCD25 - Location of the Electric Control Box in Condenser



Item	Description
1	Electric control box

Figure 4.16 CCD25 - Circuit Breaker in Condenser





Figure 4.17 CCD25 - Location of Cable Access on Electrical Box in Condenser




Item	Description	Item	Description
1	Access for condenser fan power supply cable	3	Access for communications cable
2	Access for low ambient kit power supply cable (reserved)	4	Access for condenser power supply cable

Connecting power cable for condenser CCD35


- 1. In evaporator CRD35 (used with condenser CCD35), open its rear door, and the outdoor breaker is located inside the electric control box 1. Remove four M4 screws from the electric control box cover and remove the cover.
- 2. Connect one end of the power cable to the L1, L2, L3, N, and PE terminals of the outdoor breaker.

Figure 4.18 CRD35 - Location of the Outdoor Breaker in Evaporator



- 3. In condenser CCD35, remove two M5 screws from its electric control box and remove the cover.
- 4. Connect the other end of the power cable to the L1, L2, L3, N, and PE terminals of the circuit breaker.

Figure 4.19 CCD35 - Location of the Electric Control Box in Condenser



Item	Description
1	Electric control box

Figure 4.20 CCD35 - Circuit Breaker in Condenser





Figure 4.21 CCD35 - Location of Cable Access on Electrical Box in Condenser




Item	Description	Item	Description
1	Access for condenser fan power supply cable	3	Access for communications cable
2	Access for low ambient kit power supply cable (reserved)	4	Access for condenser power supply cable

4.5.2 Connecting Power Cable for the Low Ambient Kit

Power is provided to the low ambient kit by the condenser. One end of the power cable for the low ambient kit is shipped connected at the factory. Connect the other end of the cable to the electric control box of the condenser.

1. On the electric control box, remove the plug from the hole.
2. Take out a cable gland from the accessories bag, insert the cable through the cable gland, and route the cable to the electric control box through the hole.

Figure 4.22 Connecting Power Cable for the Low Ambient Kit



Item	Description
1	Power cable of the low ambient kit

3. Connect the cable to the L and N terminals of the terminal block.
4. Fasten the cable gland.

Figure 4.23 CCD25 - Communications Terminal in Condenser





Figure 4.24 CCD35 - Communications Terminal in Condenser



4.5.3 Connecting Communications Cable for Condenser


1. For both CCD25 and CCD35, remove two M5 screws from the electric control box cover and remove the cover. Use a field supplied shielded cable. Connect one end to the A2 and B2 terminals, and connect the shielding layer of the cable to the PE terminal on the terminal block. The communications terminal of CCD 25 is shown in **Figure 4.23** on the previous page , and the communications terminal of CCD35 is shown in **Figure 4.24** on the previous page .

NOTE: Use shielded cables as communication cables. The size of the cable should be larger than 0.75 mm², and the length should be shorter than 150 m (492.1 ft).

NOTE: Do not run the communication cable in the same conduit, raceway, or chase used for a power cable.

2. Open the rear door of the indoor unit (CRD25 and CRD35). You do not need to remove filters. Remove four M4 screws from the cover of the electric control box 1 and remove the cover. Connect the other end of the shielded cable to the A2 and B2 terminals, and connect the shielding layer of the cable to the PE terminal on the terminal block.

Figure 4.25 Communications Terminal in Evaporator CRD25 and CRD35



Item	Description	Item	Description
A	CRD25 evaporator	41/42	Static pressure sensor
B	CRD35 evaporator	24/51	Water leakage sensor
A2/B2	RS485	75/76	Common alarm
37/38	Remote on/off device		

4.6 Charging Refrigerant and Adding Lubricating Oil



WARNING! Risk of over-pressurization of the refrigeration system. Can cause serious injury or death. Building and equipment damage may also result. Can cause explosive discharge of high-pressure refrigerant, loss of refrigerant, or environmental pollution. This unit contains fluids and gases under high pressure. Use extreme caution when charging the refrigerant system. Do not pressurize the system higher than the design pressure marked on the unit's nameplate.



WARNING! For systems requiring EU CE compliance (50 Hz), the system installer must provide and install a pressure relief valve in the high side refrigerant circuit that is rated same as the refrigerant high side “Max Allowable Pressure” rating that is marked on the unit serial tag. Do not install a shutoff valve between the compressor and the field installed relief valve. The pressure relief valve must be CE-certified to the EU Pressure Equipment Directive by an EU “Notified Body”.



CAUTION: Risk of excessive refrigerant line pressure. Can cause equipment damage or injury resulting from tubing and component rupture. Do not close off the refrigerant-line isolation valve for repairs unless a pressure-relief valve is field- installed in the line between the isolation valve and the check valve. The pressure-relief valve must be rated 5% to 10% higher than the system-design pressure. An increase in ambient temperature can cause the pressure of the isolated refrigerant to rise and exceed the system-design pressure rating (marked on the unit nameplate).

Refer to *SL-70747 Vertiv™ Liebert® CRV CRD25 and CRD35 Row-Based Cooling System User Manual* for charging refrigerant and adding lubricating oil.

5 Maintenance and Troubleshooting



WARNING! Arc flash and electric shock hazard. Can cause serious injury or death. Disconnect all local and remote electric power supplies and wear appropriate, OSHA-approved personal protective equipment (PPE) per NFPA 70E before working within the electric control enclosure. Customer must provide earth ground to unit, per NEC, CEC and local codes, as applicable.



WARNING! Verify with a voltmeter that power is Off. The unit's controller does not isolate power from the unit, even in the "Unit Off" mode. Some internal components still require and receive power even during the "Unit Off" mode of the controller. The factory-supplied, optional disconnect switch is inside the unit. The line side of this switch contains live high voltage. The only way to ensure that there is NO voltage inside the unit is to install and open a remote disconnect switch. Refer to unit electrical schematic.



WARNING! Before proceeding with installation, read all instructions, verify that all the parts are included and check the nameplate to be sure the voltage matches available utility power. Follow all local codes.



WARNING! Risk of electric shock. Can cause serious injury or death. Open all local and remote electric power supply disconnect switches and verify that power is off with a voltmeter before working within any electric connection enclosures. The unit's microprocessor does not isolate power from the unit, even in the "Unit Off" mode. Fan-motor controls can maintain an electric charge for 10 minutes after power is disconnected. Wait 10 minutes after power is verified as off before working within the electric control/ connection enclosures..



WARNING! Installation, service, and maintenance work must be performed only by properly trained and qualified personnel and in accordance with applicable regulations and manufacturers' specifications. Opening or removing the covers to any equipment may expose personnel to lethal voltages within the unit even when it is apparently not operating and the input wiring is disconnected from the electrical source.



WARNING! Risk of contact with high-speed rotating fan blades. Can cause serious injury or death. Open all local and remote electric power-supply disconnect switches, verify with a voltmeter that power is off, and verify that all fan blades have stopped rotating before working in the unit cabinet or on the fan assembly. If control voltage is applied, the fan motor can restart without warning after a power failure.



WARNING! Risk of contact with extremely hot or cold surfaces. Can cause injury. Verify that all components have reached a temperature that is safe for human contact or wear appropriate, OSHA-approved PPE before working within the electric connection enclosures or unit cabinet. Perform maintenance only when the system is de-energized and component temperatures have become safe for human contact.

NOTICE

Risk of improper maintenance. Can cause equipment damage. All maintenance must be performed only by authorized properly trained and qualified personnel.

NOTICE

Ignoring safety instructions is dangerous. Soiled parts cause a loss of performance and, for switch or control devices, can lead to the breakdown of the unit performance and operation.

NOTICE

Risk of release of hazardous substances into the environment. Can cause environmental pollution and violation of environmental regulations.

NOTICE

The unit contains substances and components hazardous for the environment (electronic components, refrigerating gases and oils). At the end of its useful life, the unit must be dismantled by specialized refrigerating technicians. The unit must be delivered to suitable centers specializing in the collection and disposal of equipment containing hazardous substances.

5.1 Maintenance

5.1.1 Refrigeration System

Perform the following steps for refrigeration system maintenance:

1. Check that the refrigeration pipes are firmly fixed. The refrigeration pipes shall not shake with the vibration of wall, earth, or equipment frame. Otherwise reinforce the refrigeration piping with pipe hangers with vibration isolation.
2. Check for signs of oil in or around the evaporator/condenser and interconnecting piping. If found, check for leaks in those areas with an electronic leak detector or soap bubbles.

5.1.2 Heat Exchanger

Perform the following steps for heat exchanger maintenance:

1. Clean the fin of heat exchanger regularly.
2. The best overall condenser coil cleaner to use is plain water or compressed air. If the coil has been maintained and cleaned at regular intervals, water or compressed air is sufficient to remove dirt and debris from the fins. Heavy build up on the exterior of the fins can be removed with a soft bristle brush. Water pressure from a garden hose and sprayer usually works well. If the installation environment of the condenser does not allow the fins to be cleaned with water, the compressed air may be a better method. The recommended pressure for the air is about 0.3 MPa (43.5 psig).
3. Check for damaged or bent fins and straighten them as needed.
4. Avoid snow accumulation around the condenser in winter.

5.1.3 Fan

Check that the fan runs normally and check it for problems such as abnormal noise, vibration, and bearing failure.

5.2 Troubleshooting

Perform troubleshooting according to **Table 5.1** below .

Table 5.1 Troubleshooting

Symptom	Possible Cause	Check or Remedy
Condenser will not start	No power to condenser	Check voltage at outdoor breaker
High pressure alarm	Insufficient condenser air flow	Clear the alien objects from the coil surface or near the air inlet
	Condenser fan does not run	Check fan motors Check if the outdoor unit cable connection is loosened

This page intentionally left blank

Appendices

Appendix A: Technical Support and Contacts

A.1 Technical Support/Service in the United States

Vertiv Group Corporation

24x7 dispatch of technicians for all products.

1-800-543-2378

Liebert® Thermal Management Products

1-800-543-2778

Liebert® Channel Products

1-800-222-5877

Liebert® AC and DC Power Products

1-800-543-2378

A.2 Technical Support/Service in Europe, the Middle East and Africa

Europe, the Middle East and Africa: For technical support, please contact your local Vertiv or Partner office. You can also contact us using the contact details on our website: <https://www.vertiv.com/en-emea/contacts2>

A.3 Locations

United States

Vertiv Headquarters

1050 Dearborn Drive

Columbus, OH, 43085, USA

Europe

Via Leonardo Da Vinci 8 Zona Industriale Tognana

35028 Piove Di Sacco (PD) Italy

Asia

7/F, Dah Sing Financial Centre

3108 Gloucester Road, Wanchai

Hong Kong

This page intentionally left blank

Connect with Vertiv on Social Media



<https://www.facebook.com/vertiv/>



<https://www.instagram.com/vertiv/>



<https://www.linkedin.com/company/vertiv/>



<https://www.twitter.com/Vertiv/>



Vertiv.com | Vertiv Headquarters, 1050 Dearborn Drive, Columbus, OH, 43085, USA

© 2023 Vertiv Group Corp. All rights reserved. Vertiv™ and the Vertiv logo are trademarks or registered trademarks of Vertiv Group Corp. All other names and logos referred to are trade names, trademarks or registered trademarks of their respective owners. While every precaution has been taken to ensure accuracy and completeness here, Vertiv Group Corp. assumes no responsibility, and disclaims all liability, for damages resulting from use of this information or for any errors or omissions. Specifications, rebates and other promotional offers are subject to change at Vertiv's sole discretion upon notice.

SL-70642_REVC_10-23