



NetSure™ 802 Series

-48 VDC Power System

User Manual (Section 5877), Revision V

Specification Number: 582140000

Model Number: 802NLDB, 802NLEB, 802NL-B

The information contained in this document is subject to change without notice and may not be suitable for all applications. While every precaution has been taken to ensure the accuracy and completeness of this document, Vertiv assumes no responsibility and disclaims all liability for damages resulting from use of this information or for any errors or omissions. Refer to other local practices or building codes as applicable for the correct methods, tools, and materials to be used in performing procedures not specifically described in this document.

The products covered by this instruction manual are manufactured and/or sold by Vertiv. This document is the property of Vertiv and contains confidential and proprietary information owned by Vertiv. Any copying, use or disclosure of it without the written permission of Vertiv is strictly prohibited.

Names of companies and products are trademarks or registered trademarks of the respective companies. Any questions regarding usage of trademark names should be directed to the original manufacturer.

Technical Support Site

If you encounter any installation or operational issues with your product, check the pertinent section of this manual to see if the issue can be resolved by following outlined procedures.

Visit <https://www.vertiv.com/en-us/support/> for additional assistance.

TABLE OF CONTENTS

Admonishments Used in this Document.....	6
Important Safety Instructions	7
Safety Admonishments Definitions.....	7
General Safety	7
Voltages.....	7
AC Input Voltages.....	7
DC Output and Battery Voltages	7
Battery	8
Personal Protective Equipment (PPE).....	9
Hazardous Voltage.....	9
Handling Equipment Containing Static Sensitive Components.....	9
Maintenance and Replacement Procedures.....	9
Static Warning.....	10
FCC Information.....	11
Customer Documentation Package.....	13
System Description.....	14
Description.....	14
System Overview Illustrations.....	17
Navigating the MCA	36
MCA Local Control Panel and Display	36
MCA Numbering Scheme	38
MCA Messages.....	41
System Operating Procedures.....	96
LMS Operating Procedures.....	96
LMS Local Port	96
Local Controls and Indicators.....	97
External Alarms	101
Starting and Stopping System Operation.....	101
Restarting Procedures when Rectifier is Automatically or Manually Inhibited, Shut Down, or Locked Out.....	102
Output Voltage Mode of Operation Selection.....	102
Placing the System into the Float Mode of Operation	102
Placing the System into the Test/Equalize Mode of Operation.....	102
Setting MCA Audible Alarm Cutoff Reset Time Period	108
Setting Rectifier Sequencing Delay Time Period	109
Setting MCA Custom Text Messages (Names).....	110
Mapping LMS LED Channels to the MCA Display and MCA Customer Alarm Relays.....	111
Using the Alarm Relay Test Feature	111
MCA “Power Share” Feature.....	112
MCA “Alternate Current Limit” Feature	115

Power System Remote Temperature Compensation Feature.....	116
MCA System Adjustments.....	117
Adjustment Location and Identification.....	117
Adjusting Float Output Voltage.....	117
Adjusting Test/Equalize Output Voltage.....	118
Adjusting High Voltage Shutdown.....	119
Adjusting Rectifier Current Limit.....	120
Adjusting System High Voltage Alarm 1.....	121
Adjusting System High Voltage Alarm 2.....	122
Adjusting System Battery on Discharge Alarm.....	123
Adjusting System Very Low Voltage Alarm.....	124
Adjusting Total Distribution Load Alarm.....	125
Adjusting Distribution Group A Load Alarm.....	126
Adjusting Distribution Group B Load Alarm.....	127
Adjusting Battery Ambient High Temperature #1 Alarm (if Battery Charge Digital Temperature Compensation Probe is installed).....	128
Adjusting Battery Ambient High Temperature #2 Alarm (if Battery Charge Digital Temperature Compensation Probe is installed).....	129
Adjusting Battery Ambient Low Temperature #1 Alarm (if Battery Charge Digital Temperature Compensation Probe is installed).....	130
Adjusting Battery Ambient Low Temperature #2 Alarm (if Battery Charge Digital Temperature Compensation Probe is installed).....	131
Configuring Battery Charge Digital Temperature Compensation Slope.....	132
Configuring Battery Charge Digital Temperature Compensation Maximum Voltage.....	133
Configuring Battery Charge Digital Temperature Compensation Minimum Voltage.....	134
Configuring Degree Units Displayed (°F or °C).....	135
Configuring the System Date and Time.....	136
Configuring MCA I/O Circuit Card Analog Input(s).....	137
Configuring MCA I/O Circuit Card Analog Output(s).....	138
Configuring MCA I/O Circuit Card Binary Input(s).....	139
MCA Audible Alarm Cutoff Reset Time Period.....	140
MCA Rectifier Sequencing Feature.....	140
Manually Initiated Timed Test/Equalize Feature.....	140
Automatic Test/Equalize Feature.....	140
MCA Power Share Feature.....	140
Alarm Relay Test Feature.....	140
MCA “Alternate Current Limit” Feature.....	140
System Maintenance.....	141
LMS Maintenance Procedures.....	141
System Maintenance Procedures.....	142
Adding a Rectifier.....	147
System Troubleshooting and Repair.....	148

Contact Information.....	148
LMS Troubleshooting Procedures.....	149
Troubleshooting Information.....	149
Replacement Information.....	152
Replacement Procedures.....	152
Adding a Battery Charge Digital Temperature Compensation Probe to a Previously Operated System.....	166
Removing a Battery Charge Digital Temperature Compensation Probe from a Previously Operated System	167

ADMONISHMENTS USED IN THIS DOCUMENT



DANGER! Warns of a hazard the reader *will* be exposed to that will *likely* result in death or serious injury if not avoided. (ANSI, OSHA)



WARNING! Warns of a potential hazard the reader *may* be exposed to that *could* result in death or serious injury if not avoided. This admonition is not used for situations that pose a risk only to equipment, software, data, or service. (ANSI)



CAUTION! Warns of a potential hazard the reader *may* be exposed to that *could* result in minor or moderate injury if not avoided. (ANSI, OSHA) This admonition is not used for situations that pose a risk only to equipment, data, or service, even if such use appears to be permitted in some of the applicable standards. (OSHA)



ALERT! Alerts the reader to an action that *must be avoided* in order to protect equipment, software, data, or service. (ISO)



ALERT! Alerts the reader to an action that *must be performed* in order to prevent equipment damage, software corruption, data loss, or service interruption. (ISO)



FIRE SAFETY! Informs the reader of fire safety information, reminders, precautions, or policies, or of the locations of fire-fighting and fire-safety equipment. (ISO)



SAFETY! Informs the reader of general safety information, reminders, precautions, or policies not related to a particular source of hazard or to fire safety. (ISO, ANSI, OSHA)

IMPORTANT SAFETY INSTRUCTIONS

Safety Admonishments Definitions

Definitions of the safety admonishments used in this document are listed under “Admonishments Used in this Document” on page 6.

General Safety



DANGER! YOU MUST FOLLOW APPROVED SAFETY PROCEDURES.

Performing the following procedures may expose you to hazards. These procedures should be performed by qualified technicians familiar with the hazards associated with this type of equipment. These hazards may include shock, energy, and/or burns. To avoid these hazards:

- a) The tasks should be performed in the order indicated.
- b) Remove watches, rings, and other metal objects.
- c) Prior to contacting any uninsulated surface or termination, use a voltmeter to verify that no voltage or the expected voltage is present. Check for voltage with both AC and DC voltmeters prior to making contact.
- d) Wear eye protection.
- e) Use certified and well maintained insulated tools. Use double insulated tools appropriately rated for the work to be performed.

Voltages

AC Input Voltages



DANGER! This system operates from AC input voltage capable of producing fatal electrical shock. AC input power must be completely disconnected from the branch circuits wiring used to provide power to the system before any AC electrical connections are made. Follow local lockout/tagout procedures to ensure upstream branch circuit breakers remain de-energized during installation. DO NOT apply AC input power to the system until all electrical connections have been completed and checked.

DC Output and Battery Voltages



DANGER! This system produces DC power and may have a battery source connected to it. Although the DC voltage is not hazardously high, the rectifiers and/or battery can deliver large amounts of current. Exercise extreme caution not to inadvertently contact or have any tool inadvertently contact an output terminal or battery terminal or exposed wire connected to an output terminal or battery terminal. NEVER allow a metal object, such as a tool, to contact more than one termination or battery terminal at a time, or to simultaneously contact a termination or battery terminal and a grounded object. Even a momentary short circuit can cause sparking, explosion, and injury.



DANGER! Follow local lockout/tagout procedures to ensure DC branch circuit protection devices remain de-energized during installation at loads, as required.

Battery

Refer to the battery manufacturer documentation for specific battery safety instructions. The following are general guidelines.



WARNING! Correct polarity must be observed when connecting battery leads.



WARNING! Special safety precautions are required for procedures involving handling, installing, and servicing batteries. Observe all battery safety precautions in this manual and in the battery instruction manual. These precautions should be followed implicitly at all times.



WARNING! A battery can present a risk of electrical shock and high short circuit current. Servicing of batteries should be performed or supervised only by properly trained and qualified personnel knowledgeable about batteries and the required precautions.

The following precautions should be observed when working on batteries:

- Follow the recommended PPE requirements per the SDS for the battery to be used.
- Batteries are an energy source that can produce high amounts of electrical current.
- Remove watches, rings, and other metal objects.
- Eye protection should be worn to prevent injury from accidental electrical arcs.
- Use certified and well maintained insulated tools. Use double insulated tools appropriately rated for the work to be performed. Ensure that wrenches with more than one working end have only one end exposed.
- Do not lay tools or metal parts on top of batteries.
- Verify that no current will flow when the battery is connected or disconnected by opening battery disconnects (if available) or adjusting the system to match battery voltage.
- Risk of explosion if battery is replaced with an incorrect type or if polarity is reversed. Recommended to replace batteries with the same manufacturer and type, or equivalent.
- Dispose of used batteries according to the instructions provided with the batteries. Do not dispose of batteries in a fire. They may explode.
- Batteries may generate explosive gases during normal operation. Systems containing batteries should never be installed in an airtight room or space. Only install in a ventilated environment.
- Batteries may contain sulfuric acid. If battery acid enters your eye, immediately flush your eye with running cold water for at least 15 minutes. Get medical attention immediately. If battery acid contacts skin or clothing, wash immediately with soap and water.
- Do not open or mutilate batteries.
- ALWAYS FOLLOW THE BATTERY MANUFACTURER'S RECOMMENDATIONS AND SAFETY INSTRUCTIONS.

 **ALERT!** Performing maintenance and/or troubleshooting procedures may interrupt power to the loads, if battery reserve is not sufficient.

Personal Protective Equipment (PPE)

 **DANGER!** ARC FLASH AND SHOCK HAZARD.
Appropriate PPE and tools required when working on this equipment. An appropriate flash protection boundary analysis should be done determine the “hazard/risk” category, and to select proper PPE.

 Only authorized and properly trained personnel should be allowed to install, inspect, operate, or maintain the equipment.

Do not work on LIVE parts. If required to work or operate live parts, obtain appropriate Energized Work Permits as required by the local authority, per NFPA 70E “Standard for Electrical Safety in the Workplace”.

Hazardous Voltage

 **DANGER!** HAZARD OF ELECTRICAL SHOCK.
More than one disconnect may be required to de-energize the system before servicing.

Handling Equipment Containing Static Sensitive Components

 **ALERT!** Installation or removal of equipment containing static sensitive components requires careful handling. Before handling any equipment containing static sensitive components, read and follow the instructions contained in “Static Warning” on page 10.

Maintenance and Replacement Procedures

 **CAUTION!** When performing any step in procedures that requires removal or installation of hardware, use caution to ensure no hardware is dropped and left inside the unit; otherwise service interruption or equipment damage may occur.

 **NOTE!** When performing any step in procedures that requires removal of existing hardware, retain all hardware for use in subsequent steps, unless otherwise directed.

STATIC WARNING



This equipment contains static sensitive components. The warnings listed below must be observed to prevent damage to these components. Disregarding any of these warnings may result in personal injury or damage to the equipment.

1. Strictly adhere to the procedures provided in this document.
2. Before touching any equipment containing static sensitive components, discharge all static electricity from yourself by wearing a wrist strap grounded through a one megohm resistor. Some wrist straps have a built-in one megohm resistor; no external resistor is necessary. Read and follow wrist strap manufacturer's instructions outlining use of a specific wrist strap.
3. Do not touch traces or components on equipment containing static sensitive components. Handle equipment containing static sensitive components only by the edges that do not have connector pads.
4. After removing equipment containing static sensitive components, place the equipment only on static dissipative surfaces such as conductive foam or ESD bag. Do not use ordinary Styrofoam™ or ordinary plastic.
5. Store and ship equipment containing static sensitive components only in static shielding containers.
6. If necessary to repair equipment containing static sensitive components, wear an appropriately grounded wrist strap, work on a conductive surface, use a grounded soldering iron, and use grounded test equipment.

FCC INFORMATION

The MCA Interface Modem Option (if installed) has been granted a registration number by the Federal Communications Commission, under Part 68 rules and regulations for direct connection to the telephone lines. In order to comply with these FCC rules, the following instructions must be carefully read and applicable portions followed completely:

- a) Direct connection to the telephone lines may be made only through the standard plug- ended cord furnished to the utility-installed jack. No connection may be made to party or coin phone lines. Prior to connecting the device to the telephone lines, you must:
- b) Call your telephone company and inform them you have an FCC registered device you desire to connect to their telephone lines. Give them the number(s) of the line(s) to be used, the make and model of the device, the FCC registration number and ringer equivalence. This information will be found on the device or enclosed with instructions as well as the jack suitable for your device.
- c) After the telephone company has been advised of the above you may connect your device if the jack is available, or after the telephone company has made the installation.
- d) Repairs may be made only by the manufacturer or his authorized service agency. Unauthorized repairs void registration and warranty. Contact seller or manufacturer for details of permissible user performed routine repairs, and where and how to have other than routine repairs.
- e) If, through abnormal circumstances, harm to the telephone lines is caused, it should be unplugged until it can be determined if your device or the telephone line is the source. If your device is the source, it should not be reconnected until necessary repairs are effected.
- f) Should the telephone company notify you that your device is causing harm, the device should be unplugged. The telephone company will, where practicable, notify you, that temporary discontinuance of service may be required. However, where prior notice is not practicable, the telephone company may temporarily discontinue service, if such action is reasonably necessary, in such cases the telephone company must (A) Promptly notify you of such temporary discontinuance, (B) Afford you the opportunity to correct the condition and (C) Inform you of your rights to bring a complaint to the FCC under their rules.
- g) The telephone company may make changes in its communications facilities, equipment, operations or procedures, where such action is reasonably required in the operation of its business and is not inconsistent with FCC rules. If such changes can be reasonably expected to render any customer's devices incompatible with telephone company facilities, or require modification or alteration, or otherwise materially affect its performance, written notification must be given to the user, to allow uninterrupted service.

The following information is provided here and on a label attached to the outside of the MCA Interface Modem Option (if installed).

JACK	RINGER EQUIVALENCE	FCC REGISTRATION NUMBER
RJ-11	0.2A	B46USA-22429-MM-E

This page is intentionally blank.

CUSTOMER DOCUMENTATION PACKAGE



NOTE! These instructions are for the NetSure™ 802 Series -48 VDC Power System, Model 802NLDB (208V Input Power/Distribution and Power Only Bays), 802NLEB (480V Input Power/Distribution and Power Only Bays), and 802NL-B (Distribution Only Bay); Spec. No. 582140000. **This power system is equipped with the MCA (Meter, Control, Alarm Panel) and LMS (Lorain Monitoring System).**

If you have a NetSure™ 8200 Series -48 VDC Power System, Model 8200NLDB (208V Input Power/Distribution and Power Only Bays), 8200NLEB (480V Input Power/Distribution and Power Only Bays), and 8200NL-B (Distribution Only Bay); Spec. No. 582140000, refer to UM582140000 provided with your system. **This power system is equipped with the NCU controller.**

This document (Section 5877) provides *User Instructions* for the NetSure™ 802 Series -48 VDC Power System, Model 802NLDB (208V Input Power/Distribution and Power Only Bays), 802NLEB (480V Input Power/Distribution and Power Only Bays), and 802NL-B (Distribution Only Bay); Spec. No. 582140000.

The complete Customer Documentation Package consists of...

NetSure™ 802 Series

- MCA Menu Tree: Section 5886
- Power System Installation Instructions: Section 5876
- Power System User Instructions: Section 5877
- Power System Installation Guide: Section 5957 (condensed version of Section 5876 Installation Instructions)
- Power System “System Application Guide”: SAG582140000
- Contact Information Page: Section 4154
- Engineering Drawings
 - SD582140000
 - T582140000

Optional Integrated LMS System

- LMS “System Application Guide”: SAG586505000
- LMS Installation Instructions: Section 5879
- LMS User Instructions: Section 5847

SYSTEM DESCRIPTION

Refer to SAG58214-0000 (System Application Guide) for additional information.

Description

-48 VDC @ up to 10,000 Amperes Power System

The NetSure™ 802 Series -48 VDC power system is an integrated power system containing rectifiers, intelligent control, metering, monitoring, and distribution.

This power system is designed to power a load while charging a positive grounded battery. This power system is designed for operation with the positive output grounded. This power system is capable of operating in a batteryless installation or off battery for maintenance purposes.

This system can consist of the following components.

Power/Distribution Bays

The system can consist of one (1) primary power/distribution bay and up to nine (9) additional secondary power/distribution bays.

The system can be expanded right or left.

Each power/distribution bay can be equipped with up to ten (10) rectifiers and provides distribution. Distribution is divided into two buses which accept a choice of fuse and circuit breaker types and sizes.

Each Power/Distribution Bay contains a Monitor and Control Panel. In the Primary Power/Distribution Bay, this panel houses the Meter-Control-Alarm (MCA) assembly. This panel in the Primary Power/Distribution Bay also houses the optional LMS Main CPU circuit card of the integrated LMS Monitoring System. In a Secondary Power/Distribution Bay, this panel can be equipped with an optional LMS Expansion CPU circuit card. (The optional LMS Monitoring System provides a higher level of monitoring and controlling capabilities to the power system.)

The Monitor and Control Panel in both Primary and Secondary Power/Distribution Bays contain a seven-slot card cage to house MCA alarm relay circuit cards, MCA input/output (I/O) circuit cards, and optional LMS I/O circuit cards. (If a Secondary Power/Distribution Bay is to be equipped with optional LMS I/O circuit cards, it must also be equipped with an LMS Expansion CPU circuit card.)

Power Only Bays

The system can consist of one (1) primary power only bay and up to nine (9) additional secondary power only bays.

The system can be expanded right or left.

Each power only bay can be equipped with up to ten (10) rectifiers.

Each Power Only Bay contains a Monitor and Control Panel. In the Primary Power Only Bay, this panel houses the Meter-Control-Alarm (MCA) assembly. This panel in the Primary Power Only Bay also houses the optional LMS Main CPU circuit card of the integrated LMS Monitoring System. In a Secondary Power Only Bay, this panel can be equipped with an optional LMS Expansion CPU circuit card. (The optional LMS Monitoring System provides a higher level of monitoring and controlling capabilities to the power system.)

The Monitor and Control Panel in both Primary and Secondary Power Only Bays contain a seven-slot card cage to house MCA alarm relay circuit cards, MCA input/output (I/O) circuit cards, and optional LMS I/O circuit

cards. (If a Secondary Power Only Bay is to be equipped with optional LMS I/O circuit cards, it must also be equipped with an LMS Expansion CPU circuit card.)

Distribution Only Bays

The system can consist of one (1) to eight (8) distribution only bays. Each distribution only bay provides four (4) distribution buses. Each distribution bus accepts a choice of 218-type circuit breakers and TPL-type fuses. A distribution only bay may also be equipped with an optional distribution panel which accepts a choice of TPS/TLS-type fuseholders or Bullet Nose-type circuit breakers.

Rectifiers

The system contains rectifiers; which provide load power, battery float current, and battery recharge current during normal operating conditions.

MCA (Meter-Control-Alarm)

The MCA controls the operation of the rectifiers and provides power system control, metering, monitoring, and alarm functions.

MCA Local Control Panel: This panel is located on the front of the Primary Power/Distribution Bay or Power Only Bay and contains a keypad, display, and indicators for local MCA User interface.

MCA Relay Circuit Card: Each MCA relay circuit card provides six (6) sets of Form-C relay contacts for customer external alarms. These relays are User programmable for various power system alarms. Up to sixteen (16) MCA relay circuit cards can be installed in the Primary and Secondary Power/Distribution and Power Only Bays. The Primary Power/Distribution and Power Only Bays are factory equipped with two (2) MCA relay circuit cards.

MCA I/O Circuit Cards: The MCA I/O circuit cards provide analog inputs/outputs and binary inputs. Up to sixteen (16) MCA I/O circuit cards can be installed in the Primary and Secondary Power/Distribution and Power Only Bays.

Optional Integrated LMS Monitoring System

The LMS Monitoring System consists of an LMS Main CPU circuit card, optional LMS Expansion CPU circuit cards, optional LMS I/O circuit cards, optional LMS Expansion Cabinet, and optional LMS Expansion Assemblies.

The LMS Main CPU circuit card is mounted in the Primary Power/Distribution and Power Only Bays. Each Secondary Power/Distribution and Power Only Bay that is to be equipped with optional LMS I/O circuit cards must contain an LMS Expansion CPU circuit card. LMS Expansion Cabinets and LMS Expansion Assemblies are available that mount into customer equipment.

The LMS Monitoring System is factory integrated within each Power/Distribution, Power Only, and Distribution Only Bay and requires no additional customer interconnections within the bays. Simple cable connections between the Power/Distribution, Power Only, and Distribution Only Bays complete the interbay connections required. Separate analog, binary, and relay circuit cards do not have to be supplied for power system monitoring. Analog, binary, relay, and temperature circuit cards can be provided to monitor equipment external to the power system.

The LMS input circuit cards monitor a variety of analog, binary, and temperature points external to the system. An LMS relay output circuit card is also available which provides programmable relays. These relays may be used for external alarms, or to control other equipment.

The LMS Monitoring System can be accessed via a local port, a modem port (when optional modem is ordered), an optional TL1 port, and an Ethernet port (for Telnet access, optional Web access, optional SNMP access, optional TL1 access, and Email alarm reporting).

The LMS Monitoring System collects data from the power system and the input circuit cards monitoring external points. The data collected is used for alarm processing and reporting, and to provide statistics.

The LMS Monitoring System is capable of reporting alarm conditions to a remote terminal, pager, Email address, via SNMP traps over Ethernet when the SNMP option is ordered, or via TL1 (over Ethernet) when the 'TL1 over Ethernet' option is ordered. TL1 is also available via a serial connection in 'direct mode'. For remote terminal or pager notification, the LMS Main CPU circuit card must be equipped with the optional modem. Two types of alarm reporting mechanisms are provided, System Alarm Reporting and Individual User Alarm Reporting.

Refer to SAG586505000 for further LMS information.


Applications

The NetSure™ 802NLDB and 802NLEB is capable of interfacing with Vortex® Power Systems (VPS).


The NetSure™ 802NLDB and 802NLEB is capable of interfacing with legacy power systems.

System Overview Illustrations

Power/Distribution Bay



Power Only Bay



Bay LED (Located on outside of front door)
 Green = OK
 Red = Bay Failure
 Yellow (Flashing) = Communicating with MCA

System Monitoring and Control
 See Detail B
 (See Detail D for Front Door Illustration of MCA Control Panel)


Power PCUs
 (See Detail J)

Note
 Each MCA component (i.e. PCU, Bus Monitoring Circuit Card, Bay Router Circuit Card, MCA Relay Circuit Card) can be programmed with a custom text message for identification purposes.


25 Function Channels Provided
 Program each to alarm for selected conditions, then program customer alarm relays (if furnished) to activate if a specific function channel alarms.

Front Door Removed in Illustration for Clarity

Distribution Only Bay



Detail A - Distribution Bus Monitoring Circuit Card



Identification
Indicator


Green = OK

Red = Failure


Yellow (Flashing) = Communicating with MCA

DISTRIBUTION BUS MONITORING CIRCUIT CARD
(P/N 524982)



Detail B - System Monitoring and Control Section




Detail C - Monitoring and Control Section (Distribution Only Bays)



Detail D - Front Door (Primary Power/Distribution and Power Only Bays) MCA Control Panel and Display



(Provided via a USB Type B to RS-232 Port Adapter Unit)





FRONT DOOR
(PRIMARY POWER/DISTRIBUTION AND POWER ONLY BAYS)
MCA CONTROL PANEL AND DISPLAY

Detail E - MCA Circuit Card (Primary Power/Distribution and Power Only Bays) and Router Circuit Card (Secondary Power/Distribution and Power Only Bays and Distribution Only Bays)


* Automatic internal sense when not connected.
 Note: If connected and removed, external A/D Volt Alarm activates. Clear alarm by updating inventory.

*** Green = OK
 Red = Failure
 Yellow (Flashing) = Communicating with MCA

** Apply test contact closure, then apply HVS or ESTOP closure to test these circuits.
 See MCA display to verify circuits operational.




Detail F




Details G - MCA I/O Circuit Cards


Detail G1 - MCA Relay Circuit Card (P/N 514348)




Details G2 - MCA Analog/Binary Circuit Card P/N 524550




Detail H - LMS I/O Circuit Cards




4-Input
Analog
(P/N 506336)
(see Detail H1)




8-Input
Analog
(P/N 514528)
(see Detail H2)




12-Input
Analog
(P/N 520838)
(see Detail H7)




8-Input
Temperature
(P/N 506333)
(see Detail H3)



4-Input
Binary
(P/N 506332)
(see Detail H4)




8-Input
Binary
(P/N 506334)
(see Detail H5)



4-Output
Relay
(P/N 506335)
(see Detail H6)

LMS I/O CIRCUIT CARDS

Detail I1 - LMS 4 Input Analog Circuit Card (P/N 506336)




Note:

Analog input designations A1 through A4 as shown are for the circuit card only. The actual analog channel number depends upon the quantity of analog and temperature circuit cards installed and location of this analog circuit card in the system network.

LMS 4-INPUT ANALOG CIRCUIT CARD (P/N 506336)

Detail I2 - LMS 8 Input Analog Circuit Card (P/N 514528)




Note:

Analog input designations A1 through A8 as shown are for the circuit card only. The actual analog channel number depends upon the quantity of analog and temperature circuit cards installed and location of this analog circuit card in the system network.

**LMS 8-INPUT ANALOG
CIRCUIT CARD (P/N 514528)**

Detail I3 - LMS 8 Input Temperature Circuit Card (P/N 506333)




Note:

Analog input designations A1 through A8 as shown are for the circuit card only. The actual analog channel number depends upon the quantity of analog and temperature circuit cards installed and location of this temperature circuit card in the system network.

**LMS 8-INPUT TEMPERATURE
CIRCUIT CARD (P/N 506333)**

Detail I4 - LMS 4 Input Binary Circuit Card (P/N 506332)




Note:

Binary input designations B1 through B4 as shown are for the circuit card only. The actual binary channel number depends upon the quantity of binary circuit cards installed and the location of this binary circuit card in the system network.

**LMS 4-INPUT BINARY
CIRCUIT CARD (P/N 506332)**


Detail I5 - LMS 8 Input Binary Circuit Card (P/N 506334)



Note:
Binary input designations B1 through B8 as shown are for the circuit card only. The actual binary channel number depends upon the quantity of binary circuit cards installed and the location of this binary circuit card in the system network.

LMS 8-INPUT BINARY
CIRCUIT CARD (P/N 506334)

Detail I6 - LMS 4 Output Relay Circuit Card (P/N 506335)




Note:

Relay designations K1 through K4 as shown are for the circuit card only. The actual relay channel number depends upon the number of relay circuit cards installed and the location of this relay circuit card in the system network.

Relay contacts are shown with the relays deenergized.

LMS 4-OUTPUT RELAY
CIRCUIT CARD (P/N 506335)

Detail I7 - LMS 12 Input Analog Circuit Card (P/N 520838)



Note:

Analog input designations A1 through A12 as shown are for the circuit card only. The actual analog channel number depends upon the quantity of analog and temperature circuit cards installed and location of this analog circuit card in the system network.

**LMS 12-INPUT ANALOG
CIRCUIT CARD (P/N 520838)**


Detail J - Rectifier
208V and 480V Rectifier



Operate / Standby

Operate

Standby



Output
Current
Bargraph



AC / Identify Indicator



Protection Alarm
Indicator




Indicator

NAVIGATING THE MCA

MCA Local Control Panel and Display

Located on the Primary Power/Distribution and Power Only Bays' front door.



Navigating the MCA is an easy process. You just have to remember a few key combinations (as shown in the following chart). The symbols that appear at the end of the fourth line of the display indicate which keypad buttons can be pressed at any given time.

TASK	KEY OR KEY COMBINATIONS	NOTES
Getting to Home Position	<p><u>YES / + / i and NO / -</u></p>	At any level in the MCA menus, pressing YES / + / i and NO / - simultaneously takes you back to the beginning of the MCA menu tree.
Moving from One Menu to Another Menu	<p><u>ENTER</u></p>	You can travel left to right from one menu to another by pressing ENTER . You can also go back to a specified menu by pressing ENTER while the menu's name is being displayed.
Moving Within a Menu	<p><u>UP ARROW, DOWN ARROW</u></p>	Press UP ARROW to move up the list of available entries in the active menu. Press DOWN ARROW to move down the list of available entries in the active menu.
<p><u>Changing a Value or Setting</u></p> <p>Entering the Adjustment/Change Setting Mode</p> <hr/> <p>Changing the Value or Setting</p> <hr/> <p>Locking the Change</p> <hr/> <p>Confirming the Change</p>	<p><u>ENTER and ALARM CUTOFF</u></p> <hr/> <p><u>YES / + / i and NO / -</u></p> <hr/> <p><u>ENTER</u></p> <hr/> <p><u>YES / + / i and NO / -</u></p>	<p>Changing a value or setting requires four (4) steps.</p> <ol style="list-style-type: none"> 1. With the current value or setting being displayed, simultaneously press ENTER and ALARM CUTOFF. 2. To increase the value or change the setting, press YES / + / i. To decrease the value or change the setting, press NO / -. 3. With the correct value or setting being displayed, press ENTER. 4. To accept the change, at the "ARE YOU SURE?" prompt press YES / + / i. To reject the change, at the "ARE YOU SURE?" prompt press NO / -.
<p><u>Changing a Control Function</u></p> <p>Entering the Adjustment/Change Setting Mode</p> <hr/> <p>Confirming the Change</p>	<p><u>ENTER and ALARM CUTOFF</u></p> <hr/> <p><u>YES / + / i and NO / -</u></p>	<p>Changing a control function requires two (2) steps.</p> <ol style="list-style-type: none"> 1. With the control function menu item being displayed, simultaneously press ENTER and ALARM CUTOFF. 2. To accept the change, at the "ARE YOU SURE?" prompt press the YES / + / i. To reject the change, at the "ARE YOU SURE?" prompt press NO / -.

MCA Numbering Scheme

The MCA identifies (numbers) the components of the system as follows.

COMPONENT	MCA IDENTIFICATION NUMBER		
	MCA NUMBERING SCHEME (note that each line shown below is separated with a dash in the MCA display)	NOTES	EXAMPLE
MCA/Router	Bay #	Primary Bay is #1, other bays are numbered consecutively, following the bay-to-bay cabling scheme.	Primary Bay 1 Second Bay 2 Fifth Bay 5
Rectifier (PCU)	Bay # MCA Rectifier # within the Bay / # of Rectifiers Installed in System	Primary Bay is #1, other bays are numbered consecutively, following the bay-to-bay cabling scheme. Rectifiers are identified from 1 to 10, as they are powered-up and recognized by the MCA.	Primary Bay, First Recognized Rectifier (w/ 36 rectifiers installed) 1-01/36 Second Bay, Third Recognized Rectifier (w/ 24 rectifiers installed) 2-03/24 Fifth Bay, Tenth Recognized Rectifier (w/ 12 rectifiers installed) 5-10/12
MCA Relay Circuit Card	Bay # Card Position # w/in Bay Relay # w/in Card	Primary Bay is #1, other bays are numbered consecutively, following the bay-to-bay cabling scheme. Card #1 = left slot, Card #7 = right slot. Relay # (see illustration in <i>System Overview</i> Section)	Primary Bay, Relay Card in First Slot, Relay One on Card 1-1-1 Second Bay, Relay Card in Third Slot, Relay Four on Card 2-3-4 Fifth Bay, Relay Card in Seventh Slot, Relay Six on Card 5-7-6

COMPONENT	MCA IDENTIFICATION NUMBER		
	MCA NUMBERING SCHEME (note that each line shown below is separated with a dash in the MCA display)	NOTES	EXAMPLE
MCA I/O Circuit Card	Bay # Card Position # w/in Bay	Primary Bay is #1, other bays are numbered consecutively, following the bay-to-bay cabling scheme. Card #1 = left slot, Card #7 = right slot.	Primary Bay, I/O Card in First Slot 1-1 Second Bay, I/O Card in Third Slot 2-3 Fifth Bay, I/O Card in Seventh Slot 5-7
Distribution Bus (Power/Distribution Bays)	Bay # Distribution Bus # w/in Bay (A or B Designation)	Primary Bay is #1, other bays are numbered consecutively, following the bay-to-bay cabling scheme. Distribution Bus #1 = Top, Distribution Bus #2 = Bottom. A or B as set by jumper on MCA Distribution Bus Monitoring Circuit Card.	Primary Bay, Top Bus, Set for A Designation 1-1A Second Bay, Bottom Bus, Set for B Designation 2-2B Fifth Bay, Top Bus, Designation Not Set 5-1
Distribution Device (Power/Distribution Bays)	Type Bay # Distribution Point # w/in Bay	Type = Breaker, Fuse, or Plug-In. Primary Bay is #1, other bays are numbered consecutively, following the bay-to-bay cabling scheme. Distribution Point = 1-24 (left - right, Top Bus, Bus #1). 25-36 (left - right, Bottom Bus, Bus #2). Note that distribution components may take more than one mounting position, designation number is the left most mounting position.	Primary Bay, Circuit Breaker Mounted in Position One, Bus 1 Set for A Designation Breaker 1-01A Second Bay, Fuse Mounted in Position Sixteen, Bus 1 Designation Not Set Fuse 2-16 Fifth Bay, Plug-In Mounted in Position Twenty-Six, Bus 2 Set for B Designation Plug-In 5-26B

COMPONENT	MCA IDENTIFICATION NUMBER		
	MCA NUMBERING SCHEME (note that each line shown below is separated with a dash in the MCA display)	NOTES	EXAMPLE
Distribution Only Bay's Distribution Bus	Bay # Distribution Bus # w/in Bay (A or B Designation)	<p>Primary Bay is #1, other bays are numbered consecutively, following the bay-to-bay cabling scheme.</p> <p>Distribution Bus #1 = Top Left, Distribution Bus #2 = Top Right, Distribution Bus #3 = Bottom Left, Distribution Bus #4 = Bottom Right, A or B as set by jumper on MCA Distribution Bus Monitoring Circuit Card.</p>	<p>Fifth Bay, Top Left Bus, Set for B Designation 5-1B</p> <p>Sixth Bay, Top Right Bus, Set for B Designation 6-2B</p> <p>Seventh Bay, Bottom Left Bus, Set for B Designation 7-3B</p> <p>Seventh Bay, Bottom Right Bus, Designation Not Set 7-4</p>
Distribution Only Bay's Distribution Device	Type Bay # Distribution Point # w/in Bay	<p>Type = Breaker or Fuse or MISC 50-73.</p> <p>Primary Bay is #1, other bays are numbered consecutively, following the bay-to-bay cabling scheme.</p> <p>Distribution Point = 1-12 (bottom - top, Top Left Bus, Bus #1). 13-24 (top - bottom, Top Right Bus, Bus #2). 25-36 (bottom - top, Bottom Left Bus, Bus #3). 37-48 (top - bottom, Bottom Right Bus, Bus #4). Note that distribution components may take more than one mounting position, designation number is the left most mounting position.</p> <p>Note: The optional bullet-device fuse panel is displayed as MISC 50-73.</p>	<p>Fifth Bay, Circuit Breaker Mounted in Position One, Bus 1 Set for A Designation Breaker 5-01A</p> <p>Sixth Bay, Fuse Mounted in Position Thirteen, Bus 2 Designation Not Set Fuse 6-13</p>

MCA Messages

The following chart provides an explanation of each MCA message appearing on the MCA Menu Tree (Section 5886). Note that each line in the MCA Menu Tree contains a number. This number is referenced in the following chart.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
1	EMERGENCY STOP INPUT ACTIVE	Main Alarm Menu	Rectifier Module (PCU) emergency shutdown or fire alarm disconnect signal applied to the system.
2	HI VOLTAGE SHUTDOWN INPUT ACTIVE	Main Alarm Menu	High voltage shutdown signal applied to the system.
2A	ALTERNATE CURRENT LIMIT ACTIVE	Main Alarm Menu	Indicates that all rectifier modules (PCUs) are operating in the "Alternate Current Limit" mode. Rectifier output current will be limited to the percent of capacity specified by the "Alternate Current Limit Capacity" parameter setting.
3	SYSTEM VOLTAGE IS VERY LOW	Main Alarm Menu	System voltage below a preset adjustable value, indicating that the battery has been continuously supplying the load and has discharged to approximately half its reserve time. Press ENTER to view the alarm limit setpoint and the current value of the monitored input.
3A	ALARM LIMIT vv.vvV NOW AT vv.vvV	--	Displays the alarm limit setpoint and the actual value of the monitored input.
4	SYSTEM BATTERY IS ON DISCHARGE	Main Alarm Menu	System voltage below a preset adjustable value, indicating that the battery is supplying the load and is discharging. Press ENTER to view the alarm limit setpoint and the current value of the monitored input.
4A	ALARM LIMIT vv.vvV NOW AT vv.vvV	--	Displays the alarm limit setpoint and the actual value of the monitored input.
5	SYSTEM HIGH VOLTAGE #1 ALARM	Main Alarm Menu	System voltage above a preset adjustable value. Press ENTER to view the alarm limit setpoint and the current value of the monitored input.
5A	ALARM LIMIT vv.vvV NOW AT vv.vvV	--	Displays the alarm limit setpoint and the actual value of the monitored input.
6	SYSTEM HIGH VOLTAGE #2 ALARM	Main Alarm Menu	System voltage above a preset adjustable value. Press ENTER to view the alarm limit setpoint and the current value of the monitored input.
6A	ALARM LIMIT vv.vvV NOW AT vv.vvV	--	Displays the alarm limit setpoint and the actual value of the monitored input.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
7	1 SYSTEM BREAKER OR FUSE ALARM or ### SYSTEM BREAKER & FUSE ALARMS	Main Alarm Menu	One or more system fuses or circuit breakers open. (### = number of open system fuses or circuit breakers.) Press ENTER to view which fuse(s) or circuit breaker(s) is open. Note that the individual fuses and circuit breakers in the bullet nose-type device holders (plug-in) are not counted. If any number within a bullet nose-type device holder (plug-in) are open, only one will be counted.
8	F/CB/PI B#-P#A/B IS OPEN	Fuse Alarm Menu	Identification of open system fuse or circuit breaker. (F/CB/PI B#-P#A/B = Fuse or Circuit Breaker or PlugIn, Bay Number-Distribution Device Position Number [Group A or B Designation if applicable.]) Press UP and DOWN ARROWS to scroll if multiple distribution devices are open.
9	GO TO MAIN ALARM MENU	Fuse Alarm Menu	Press ENTER to go to this menu.
10	GO BACK TO MENU TREE BEGINNING	Fuse Alarm Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
11	AC POWER IS OFF TO ALL PCUs	Main Alarm Menu	AC input voltage to all Rectifier Modules (PCUs) below a preset non-adjustable value.
12	1 PCU HAS FAILED or ### PCUs HAVE FAILED or NO PCUs ARE IN INVENTORY	Main Alarm Menu	One or more Rectifier Modules (PCUs) failed. (### = number of failed Rectifier Modules [PCUs].) Press ENTER to view which Rectifier Module (PCU) failed. or If the MCA does not recognize any Rectifier Module (PCU), <i>NO PCUs ARE IN INVENTORY</i> is displayed.
13	PCU B#-ID#/N# FAILURE	PCU Alarm Menu	Identification of failed Rectifier Module (PCU). (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System.) Press UP and DOWN ARROWS to scroll if multiple Rectifier Modules failed. Press ENTER to view why Rectifier Module failed.
14	### REMOTE PCUS HAVE FAILED	PCU Alarm Menu	More than one Remote Rectifier (PCU) failed. (### = number of failed Remote Rectifiers [PCUs].)
15	1 REMOTE PCU HAS FAILED	PCU Alarm Menu	One Remote Rectifier (PCU) failed.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
16	GO TO MAIN ALARM MENU	PCU Alarm Menu	Press ENTER to go to this menu.
17	GO BACK TO MENU TREE BEGINNING	PCU Alarm Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
18	PCU B#-ID#/N# EMERG. STOP	PCU Alarm Detail Menu	Rectifier Module (PCU) is in Emergency Stop Mode. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System.)
19	PCU B#-ID#/N# H.V. SHUTDOWN	PCU Alarm Detail Menu	Rectifier Module (PCU) is in High Voltage Shutdown. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System.)
20	PCU B#-ID#/N# AC LINE OFF	PCU Alarm Detail Menu	No AC Input to Rectifier Module (PCU) or Rectifier Module's (PCU's) processor failed. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System.)
21	PCU B#-ID#/N# AC LINE LOW	PCU Alarm Detail Menu	Rectifier Module's (PCU's) Low AC Line Alarm active. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System.)
22	PCU B#-ID#/N# AC LINE HIGH	PCU Alarm Detail Menu	Rectifier Module's (PCU's) High AC Line Alarm active. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System.)
23	PCU B#-ID#/N# AC PHASE LOST	PCU Alarm Detail Menu	Rectifier Module's (PCU's) AC Line Phase Lost Alarm active. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System.)
24	PCU B#-ID#/N# POWER FACTOR	PCU Alarm Detail Menu	Rectifier Module's (PCU's) internal power factor circuit failed. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System.)
25	PCU B#-ID#/N# DC/DC CONV.	PCU Alarm Detail Menu	Rectifier Module's (PCU's) internal DC/DC converter circuit failed. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System.)
26	PCU B#-ID#/N# FUSE/BREAKER	PCU Alarm Detail Menu	Rectifier Module's (PCU's) DC output fuse open. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System.)
27	PCU B#-ID#/N# INHIBITED	PCU Alarm Detail Menu	Rectifier Module's (PCU's) output inhibited. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System.)

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
28	PCU B#-ID#/N# ON STANDBY	PCU Alarm Detail Menu	Rectifier Module's (PCU's) Standby/Operate switch is in the "standby" position. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System.)
29	PCU B#-ID#/N# THERMAL LIMIT	PCU Alarm Detail Menu	Rectifier Module (PCU) in Thermal Current Limit. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System.)
30	PCU B#-ID#/N# THERMAL STOP	PCU Alarm Detail Menu	Rectifier Module (PCU) in Thermal Shutdown. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System.)
31	PCU B#-ID#/N# HIGH AMBIENT	PCU Alarm Detail Menu	Rectifier Module's (PCU's) High Temperature Alarm active. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System.)
32	PCU B#-ID#/N# LOAD SHARE	PCU Alarm Detail Menu	Load is not balanced with the other Rectifier Modules (PCUs). (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System.)
33	PCU B#-ID#/N# 1 FAN SPEED	PCU Alarm Detail Menu	1 Rectifier Module (PCU) Fan Fail Alarm active. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System.)
34	PCU B#-ID#/N# 2+ FANS SPEED	PCU Alarm Detail Menu	2 or more Rectifier Module (PCU) Fan Fail Alarms active. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System.)
35	PCU B#-ID#/N# NO VOLT SENSE	PCU Alarm Detail Menu	Not used at this time.
36	PCU B#-ID#/N# DUPLICATED	PCU Alarm Detail Menu	Duplicated Reference Designations.
37	PCU B#-ID#/N# NO RESPONSE	PCU Alarm Detail Menu	MCA communications with Rectifier Module (PCU) lost. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System.)
38	GO TO PCU ALARM MENU	PCU Alarm Detail Menu	Press ENTER to go to this menu.
39	GO BACK TO MENU TREE BEGINNING	PCU Alarm Detail Menu	Press ENTER to go to the beginning of the MCA Menu Tree.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
40	1 DIST. PANEL HAS FAILED or ## DIST. PANELS HAVE FAILED or NO DIST. PANELS ARE IN INVENTORY	Main Alarm Menu	One or more Distribution Bus Monitoring Circuit Cards failed. (## = number of failed Distribution Bus Monitoring Circuit Cards.) Press ENTER to view which Distribution Bus Monitoring Circuit Card(s) failed. or If the MCA does not recognize any Distribution Bus Monitoring Circuit Card, <i>NO DIST. PANELS ARE IN INVENTORY</i> is displayed.
41	DIST. PANEL B#-P#A/B FAILURE	Distribution Alarm Menu	Identification of failed Distribution Bus Monitoring Circuit Card. (B#-P# A/B = Bay Number-Distribution Bus Monitoring Circuit Card Position Number [Group A or B Designation if applicable.]) Press UP and DOWN ARROWS to scroll if multiple Distribution Bus Monitoring Circuit Cards failed. Press ENTER to view why Distribution Bus Monitoring Circuit Card failed.
42	GO TO MAIN ALARM MENU	Distribution Alarm Menu	Press ENTER to go to this menu.
43	GO BACK TO MENU TREE BEGINNING	Distribution Alarm Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
44	DIST. PANEL B#-P#A/B DISCONNECTED or DIST. PANEL B#-P#A/B RECONNECT?	Distribution Alarm Detail Menu	Not utilized at this time.
45	POSITION B#-P#A/B NOT FOUND or POSITION NOT FOUND PANEL B#-P#A/B	Distribution Alarm Detail Menu	MCA cannot find a distribution device. (B#-P#A/B = Bay Number-Distribution Device Position Number [Group A or B Designation if applicable.]) (B#-P#A/B = Bay Number-Distribution Bus Monitoring Circuit Card Position Number [Group A or B Designation if applicable.]) Press UP and DOWN ARROWS to scroll if multiple distribution devices not found.
46	POSITION B#-P#A/B TYPE UNKNOWN	Distribution Alarm Detail Menu	MCA cannot identify the distribution device. (B#-P#A/B = Bay Number-Distribution Device Position Number [Group A or B Designation if applicable.]) Press UP and DOWN ARROWS to scroll if multiple distribution devices not identified.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
47	F/CB/PI B#-P#A/B OVER CURRENT	Distribution Alarm Detail Menu	Distribution device current is above the shunt's rating. (F/CB/PI B#-P#A/B = Fuse or Circuit Breaker or PlugIn, Bay Number-Distribution Device Position Number [Group A or B Designation if applicable.]) Press UP and DOWN ARROWS to scroll if multiple shunts are over-ranged.
48	DIST. PANEL B#-P#A/B LVD FAILURE	Distribution Alarm Detail Menu	Not utilized at this time.
49	DIST. PANEL B#-P#A/B A/B CHANGED	Distribution Alarm Detail Menu	Group A / Group B jumper setting on Distribution Bus Monitoring Circuit Card changed. (B#-P# = Bay Number-Distribution Bus Monitoring Circuit Card Position Number)
50	DIST. PANEL B#-P#A/B PROCESSOR	Distribution Alarm Detail Menu	Distribution Bus Monitoring Circuit Card's processor failed. (B#-P#A/B = Bay Number-Distribution Bus Monitoring Circuit Card Position Number [Group A or B Designation if applicable.])
51	DIST. PANEL B#-P#A/B IS DUPLICATED	Distribution Alarm Detail Menu	Duplicated Reference Designations.
52	DIST. PANEL B#-P#A/B NO RESPONSE	Distribution Alarm Detail Menu	MCA communications with Distribution Bus Monitoring Circuit Card lost. (B#-P# = Bay Number-Distribution Bus Monitoring Circuit Card Position Number)
53	GO TO DISTRIBUTION ALARM MENU	Distribution Alarm Detail Menu	Press ENTER to go to this menu.
54	GO BACK TO MENU TREE BEGINNING	Distribution Alarm Detail Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
55	1 I/O BOARD HAS FAILED or ## I/O BOARDS HAVE FAILED or NO I/O BOARD S ARE IN INVENTORY	Main Alarm Menu	One or more MCA I/O Circuit Cards failed. (## = number of failed MCA I/O Circuit Cards.) Press ENTER to view which MCA I/O Circuit Card(s) failed. or If the MCA does not recognize any MCA I/O Circuit Card, NO I/O BOARDS ARE IN INVENTORY is displayed.
56	I/O BOARD B#-P# FAILURE	I/O Board Alarm Menu	Identification of failed MCA I/O Circuit Card. (B#-P# = Bay Number-MCA I/O Circuit Card Position Number.) Press UP and DOWN ARROWS to scroll if multiple MCA I/O Circuit Cards failed. Press ENTER to view why MCA I/O Circuit Card failed.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
57	GO TO MAIN ALARM MENU	I/O Board Alarm Menu	Press ENTER to go to this menu.
58	GO BACK TO MENU TREE BEGINNING	I/O Board Alarm Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
59	<i>Binary Input Customer Text Message</i>	I/O Board Alarm Detail Menu	Custom test message stored in MCA for binary input that is in alarm state. If multiple inputs in alarm state, scroll through each. Note: Refer to <i>System Operating Procedures</i> section in Section 5877 for procedure how to enter custom test messages. Refer to <i>Installing the Rectifier Modules and Initially Starting the Power System</i> section in Section 5876 for procedure how to program binary input alarm state (either open or close contact state).
60	I/O BOARD B#-P# OVER CURRENT	I/O Board Alarm Detail Menu	If the current reflected by the analog inputs or outputs gets up to 95% of the shunt rating, the I/O board activates an over current alarm. (B#-P# = Bay Number-MCA I/O Circuit Card Position Number.)
61	I/O BOARD B#-P# PROCESSOR	I/O Board Alarm Detail Menu	MCA I/O Circuit Card's processor failed. (B#-P# = Bay Number-MCA I/O Circuit Card Position Number.)
62	I/O BOARD B#-P# IS DUPLICATED	I/O Board Alarm Detail Menu	Duplicated Reference Designations.
63	I/O BOARD B#-P# NO RESPONSE	I/O Board Alarm Detail Menu	MCA communications with MCA I/O Circuit Card lost. (B#-P# = Bay Number-MCA I/O Circuit Card Position Number.)
64	GO TO I/O BOARD ALARM MENU	I/O Board Alarm Detail Menu	Press ENTER to go to this menu.
65	GO BACK TO MENU TREE BEGINNING	I/O Board Alarm Detail Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
66	1 ROUTER HAS FAILED or ## ROUTERS HAVE FAILED or NO ROUTERS ARE IN INVENTORY	Main Alarm Menu	One or more Router Circuit Cards failed. (## = number of failed Router Circuit Cards.) Press ENTER to view which Router Circuit Card(s) failed. or If the MCA does not recognize any Router Circuit Card, <i>NO ROUTERS ARE IN INVENTORY</i> is displayed.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
67	ROUTER B# FAILURE	Router Alarm Menu	Identification of failed Router Circuit Card. (B# = Bay Number.) Press UP and DOWN ARROWS to scroll if multiple Router Circuit Cards failed. Press ENTER to view why Router Circuit Card failed.
68	GO TO MAIN ALARM MENU	Router Alarm Menu	Press ENTER to go to this menu.
69	GO BACK TO MENU TREE BEGINNING	Router Alarm Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
70	ROUTER B# REMOTE SENSE OPEN	Router Alarm Detail Menu	Router Circuit Card External A/D Voltage Alarm active. (B# = Bay Number.)
71	ROUTER B# INTERNAL SENSE OPEN	Router Alarm Detail Menu	Router Circuit Card Internal A/D Voltage Alarm active. (B# = Bay Number.)
72	ROUTER B# PROCESSOR	Router Alarm Detail Menu	Router Circuit Card's processor failed. (B# = Bay Number.)
73	ROUTER B# REPORTS AN ILLEGAL NODE	Router Alarm Detail Menu	MCA does not recognize a node's type or identification number. (B# = Bay Number.)
74	ROUTER B# IS DUPLICATED	Router Alarm Detail Menu	Duplicated Reference Designations.
75	ROUTER B# NO RESPONSE	Router Alarm Detail Menu	MCA communications with Router Circuit Card lost. (B# = Bay Number.)
76	GO TO ROUTER ALARM MENU	Router Alarm Detail Menu	Press ENTER to go to this menu.
77	GO BACK TO MENU TREE BEGINNING	Router Alarm Detail Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
78	1 RELAY BOARD HAS FAILED or ## RELAY BOARDS HAVE FAILED or NO RELAY BOARDS ARE IN INVENTORY	Main Alarm Menu	One or more MCA Customer Alarm Relay Circuit Cards failed. (## = number of failed MCA Customer Alarm Relay Circuit Cards.) Press ENTER to view which MCA Customer Alarm Relay Circuit Card(s) failed. or If the MCA does not recognize any MCA Customer Alarm Relay Circuit Card, <i>NO RELAY BOARDS ARE IN INVENTORY</i> is displayed.
79	RELAY BOARD B#-P# FAILURE	Relay Alarm Menu	Identification of failed MCA Customer Alarm Relay Circuit Card. (B#-P# = Bay Number-Relay Circuit Card Position Number.) Press UP and DOWN ARROWS to scroll if multiple MCA Customer Alarm Relay Circuit Cards failed. Press ENTER to view why MCA Customer Alarm Relay Circuit Card failed.
80	GO TO MAIN ALARM MENU	Relay Alarm Menu	Press ENTER to go to this menu.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
81	GO BACK TO MENU TREE BEGINNING	Relay Alarm Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
82	RELAY B#-P#-R# IS STUCK	Relay Alarm Detail Menu	Relay does not change state. (B#-P#-R# = Bay Number-Relay Circuit Card Position Number-Relay Number on Card.)
83	RELAY BOARD B#-P# PROCESSOR	Relay Alarm Detail Menu	MCA Customer Alarm Relay Circuit Card's processor failed. (B#-P# = Bay Number-Relay Circuit Card Position Number.)
84	RELAY BOARD B#-P# IS DUPLICATED	Relay Alarm Detail Menu	Duplicated Reference Designations.
85	RELAY BOARD B#-P# NO RESPONSE	Relay Alarm Detail Menu	MCA communications with MCA Customer Alarm Relay Circuit Card lost. (B#-P# = Bay Number-Relay Circuit Card Position Number.)
86	GO TO RELAY ALARM MENU	Relay Alarm Detail Menu	Press ENTER to go to this menu.
87	GO BACK TO MENU TREE BEGINNING	Relay Alarm Detail Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
88	HIGH TEMPERATURE #1 ALARM	Main Alarm Menu	Battery ambient temperature above preset adjustable value. Press ENTER to view the alarm limit setpoint and the current value of the monitored input.
88A	ALARM LIMIT ttt°C/F NOW AT ttt°C/F	--	Displays the alarm limit setpoint and the actual value of the monitored input.
89	HIGH TEMPERATURE #2 ALARM	Main Alarm Menu	Battery ambient temperature above preset adjustable value. Press ENTER to view the alarm limit setpoint and the current value of the monitored input.
89A	ALARM LIMIT ttt°C/F NOW AT ttt°C/F	--	Displays the alarm limit setpoint and the actual value of the monitored input.
90	LOW TEMPERATURE #1 ALARM	Main Alarm Menu	Battery ambient temperature below preset adjustable value. Press ENTER to view the alarm limit setpoint and the current value of the monitored input.
90A	ALARM LIMIT ttt°C/F NOW AT ttt°C/F	--	Displays the alarm limit setpoint and the actual value of the monitored input.
91	LOW TEMPERATURE #2 ALARM	Main Alarm Menu	Battery ambient temperature below preset adjustable value. Press ENTER to view the alarm limit setpoint and the current value of the monitored input.
91A	ALARM LIMIT ttt°C/F NOW AT ttt°C/F	--	Displays the alarm limit setpoint and the actual value of the monitored input.
92	TEMPERATURE SENSOR NO SIGNAL	Main Alarm Menu	MCA Temperature Sensor signal lost, if Temperature Sensor installed.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
93	MAJOR MONITORING ALARM(S) or <i>Monitoring Major LED Messages</i>	Main Alarm Menu	Major Alarm conditions detected by LMS1000. <i>Alarm Messages derived from LMS1000 are displayed by the MCA.</i>
94	MINOR MONITORING ALARM(S) or <i>Monitoring Minor LED Messages</i>	Main Alarm Menu	Minor Alarm conditions detected by LMS1000. <i>Alarm Messages derived from LMS1000 are displayed by the MCA.</i>
95	MONITORING INFORMATION or <i>Monitoring Info LED Messages</i>	Main Alarm Menu	Status Messages detected by LMS1000. <i>Status Messages derived from LMS1000 are displayed by the MCA.</i>
96	MONITORING DOES NOT RESPOND	Main Alarm Menu	MCA communications with LMS1000 lost.
97	CONTROLLER FAILURE #####	Main Alarm Menu	MCA failed (##### = type of memory failure)
98	THE CONTROLLER IS INITIALIZING	Main Alarm Menu	The MCA is initializing.
99	TOTAL LOAD CURRENT ALARM	Main Alarm Menu	System load current above preset adjustable value (includes distribution loads monitored by the Distribution Bus Monitoring Circuit Cards and any MCA I/O Circuit Card set as "Distribution" [other setting choice is "Auxiliary"]). Press ENTER to view the alarm limit setpoint and the current value of the monitored input.
99A	ALARM LIMIT aaaaaA NOW AT aaaaaA	--	Displays the alarm limit setpoint and the actual value of the monitored input.
100	DISTRIBUTION GROUP A LOAD ALARM	Main Alarm Menu	Sum of load currents monitored by all Distribution Bus Monitoring Circuit Cards set as Group A designation above preset adjustable value. Press ENTER to view the alarm limit setpoint and the current value of the monitored input.
100A	ALARM LIMIT aaaaaA NOW AT aaaaaA	--	Displays the alarm limit setpoint and the actual value of the monitored input.
101	DISTRIBUTION GROUP B LOAD ALARM	Main Alarm Menu	Sum of load currents monitored by all Distribution Bus Monitoring Circuit Cards set as Group B designation above preset adjustable value. Press ENTER to view the alarm limit setpoint and the current value of the monitored input.
101A	ALARM LIMIT aaaaaA NOW AT aaaaaA	--	Displays the alarm limit setpoint and the actual value of the monitored input.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
102	THE DISPLAY DOES NOT RESPOND	Main Alarm Menu	MCA communications with MCA Display lost.
103	GO TO FUNCTION MENU	Main Alarm Menu	Press ENTER to go to this menu.
104	GO BACK TO MENU TREE BEGINNING	Main Alarm Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
105	VIEW THE SYSTEM MEASUREMENTS	Function Menu	Press ENTER to go to this menu.
106	SYSTEM OUTPUT SENSE vv.vvV (REM) or SYSTEM OUTPUT SENSE vv.vvV (AVG)	Measurement Menu	The voltage of the external (remote) source connected to the MCA / Router circuit card (for MCA alarms and meter reading), if connected. or System output sense voltage (average of all bay's internal sense voltages). Press ENTER to view individual bay sense voltages.
107	ROUTER B# REMOTE SENSE vv.vvV	Router Voltage Menu	External (remote) sense voltage applied to the MCA / Router Circuit Card, if connected. (B# = Bay Number). Press UP and DOWN ARROWS to view other Router Circuit Cards' sense voltages.
108	ROUTER B# INTERNAL SENSE vv.vvV	Router Voltage Menu	Internal sense voltage applied to the Router Circuit Card. (B# = Bay Number). Press UP and DOWN ARROWS to view other Router Circuit Cards' sense voltages.
109	GO TO MEASUREMENT MENU	Router Voltage Menu	Press ENTER to go to this menu.
110	GO BACK TO MENU TREE BEGINNING	Router Voltage Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
111	TOTAL SYSTEM LOAD aaaaaA	Measurement Menu	Total system load current.
112	TOTAL DISTRIBUTION LOAD aaaaaA or TOTAL AUXILIARY LOAD aaaaaA	System Load Menu	Total distribution load current (includes distribution loads monitored by the Distribution Bus Monitoring Circuit Cards and any MCA I/O Circuit Card set as " <i>Distribution</i> " [other setting choice is " <i>Auxiliary</i> "]). Press ENTER to view individual bay distribution load currents. or Total (sum) load current monitored by MCA I/O Circuit Cards set as " <i>Auxiliary</i> ". Press ENTER to view individual MCA I/O circuit card load currents.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
113	DISTRIBUTION GROUP A LOAD aaaaaA	System Load Menu	Total load current monitored by Distribution Bus Monitoring Circuit Cards set as Group A designation.
114	DISTRIBUTION GROUP B LOAD aaaaaA	System Load Menu	Total load current monitored by Distribution Bus Monitoring Circuit Cards set as Group B designation.
115	REMOTE SYSTEM LOAD aaaaaA	System Load Menu	Total Remote Distribution load current reported by the LMS when LMS Function Channel 63 value is greater than zero.
116	GO TO MEASUREMENT MENU	System Load Menu	Press ENTER to go to this menu.
117	GO BACK TO MENU TREE BEGINNING	System Load Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
118	DIST. PANEL B#-P#A/B LOAD aaaaaA	Distribution Load Menu	Sum of load currents monitored by the Distribution Bus Monitoring Circuit Card. (B#-P#A/B = Bay Number-Distribution Bus Monitoring Circuit Card Position Number [Group A or B Designation if applicable.]) Press UP and DOWN ARROWS to view other Distribution Bus Monitoring Circuit Cards' load currents. Press ENTER to view individual distribution device load currents.
119	I/O BOARD B#-P# LOAD aaaaaA	Distribution Load Menu	Load current monitored by the first MCA I/O Circuit Card (set as "Distribution" or "Auxiliary" as determined by what is being displayed on line #112). (B#-P# = Bay Number-MCA I/O Circuit Card Position Number.) Press UP and DOWN ARROWS to view other MCA I/O Circuit Cards' load currents.
120	GO TO SYSTEM LOAD MENU	Distribution Load Menu	Press ENTER to go to this menu.
121	GO BACK TO MENU TREE BEGINNING	Distribution Load Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
122	F/CB/MISC 50-73 B#-P#A/B LOAD aaaaaA	Distribution Load Detail Menu	Distribution device identification number and load current. (F/CB/MISC 50-73 B#-P#A/B = Fuse or Circuit Breaker or Bullet Device, Bay Number-Distribution Device Position Number [Group A or B Designation if applicable.]) Press UP and DOWN ARROWS to view other Distribution Devices' load currents.
123	GO TO DISTRIBUTION LOAD MENU	Distribution Load Detail Menu	Press ENTER to go to this menu.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
124	GO BACK TO MENU TREE BEGINNING	Distribution Load Detail Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
125	TOTAL PCU OUTPUT aaaaaA or TOTAL PCU/RECTIFIER aaaaaA	Measurement Menu	Total Rectifier Module (PCU) output current. Press ENTER to view individual Rectifier Module load currents. or Total Rectifier Module and legacy rectifier output current when LMS1000 Function Channel #64 reported value is greater than zero. Press ENTER to view individual Rectifier Module load currents and legacy system current.
126	PCU B#-ID#/N# aaaaaA	PCU Load Menu	Rectifier Module (PCU) output current. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System). Press UP and DOWN ARROWS to view other Rectifier Modules' load currents.
127	RECTIFIER OUTPUT aaaaaA	PCU Load Menu	Legacy Rectifier System output current as reported by the LMS1000 Function Channel #64.
128	GO TO MEASUREMENT MENU	PCU Load Menu	Press ENTER to go to this menu.
129	GO BACK TO MENU TREE BEGINNING	PCU Load Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
130	TEMPERATURE SENSOR ttt°C/F or REMOTE TEMPERATURE ttt°C/F	Measurement Menu	Temperature detected by Temperature Sensor, if installed, or Remote Temperature Sensor.
131	GO TO FUNCTION MENU	Measurement Menu	Press ENTER to go to this menu.
132	GO BACK TO MENU TREE BEGINNING	Measurement Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
133	FLOAT MODE IS ACTIVE SET TEST/EQ? or TEST/EQ MODE ACTIVE SET FLOAT? or TEST/EQUALIZE INPUT IS ACTIVE or TURN OFF POWER SHARE or TURN OFF ALTERNATE CURRENT LIMIT	Function Menu	Allows you to change the Rectifier Module (PCU) output voltage mode. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. or The user tried to set Float Mode while an external test/equalize input signal was being supplied to the system. Note: Test/Equalize Mode requires Power Share and Alternate Current Limit to be turned off. A message is displayed if Power Share or Alternate Current Limit is on. Turn Power Share or Alternate Current Limit off first then return to this menu.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
134	VIEW THE SYSTEM INVENTORY	Function Menu	Press ENTER to go to this menu.
135	1 PCU IS REPORTING or ### PCUs ARE REPORTING or NO PCUs ARE INSTALLED	Inventory Menu	Number of Rectifier Modules (PCUs) in MCA inventory. Press ENTER to view individual Rectifier Module inventory information. or No Rectifier Modules installed.
136	PCU B#-ID#/N# RATED aaaaA	PCU Inventory Menu	Rectifier Module (PCU) identification number and output current rating. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System). Press UP and DOWN ARROWS to view other Rectifier Modules.
137	GO TO INVENTORY MENU	PCU Inventory Menu	Press ENTER to go to this menu.
138	GO BACK TO MENU TREE BEGINNING	PCU Inventory Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
139	B#-ID#/N# ASSY. #####	PCU Inventory Detail Menu	Rectifier Module (PCU) Assembly Number. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System).
140	B#-ID#/N# SERIAL #####	PCU Inventory Detail Menu	Rectifier Module (PCU) Serial Number. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System).
141	B#-ID#/N# BOOT #####	PCU Inventory Detail Menu	Rectifier Module (PCU) Bootcode Number. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System).
142	B#-ID#/N# SW VER #####	PCU Inventory Detail Menu	Rectifier Module (PCU) Software Number. (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System).
143	PSC B#-ID# ASSEMBLY #####	PCU Inventory Detail Menu	PSC (Primary Side Controller) Assembly Number. (B#-ID# = Bay Number-PSC Position Number).
144	PSC B#-ID# SERIAL # #####	PCU Inventory Detail Menu	PSC (Primary Side Controller) Serial Number. (B#-ID# = Bay Number-PSC Position Number).
145	PSC B#-ID# BOOTCODE #####	PCU Inventory Detail Menu	PSC (Primary Side Controller) Bootcode Number. (B#-ID# = Bay Number-PSC Position Number).

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
146	PSC B#-ID# SOFTWARE #####	PCU Inventory Detail Menu	PSC (Primary Side Controller) Software Number. (B#-ID# = Bay Number-PSC Position Number).
147	GO TO PCU INVENTORY	PCU Inventory Detail Menu	Press ENTER to go to this menu.
148	GO BACK TO MENU TREE BEGINNING	PCU Inventory Detail Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
149	1 PCU POSITION IS EMPTY or ### PCU POSITIONS ARE EMPTY or NO PCU POSITIONS ARE EMPTY	Inventory Menu	Number of empty Rectifier Module (PCU) mounting positions in the system.
150	1 DIST. PANEL IS REPORTING or ## DIST. PANELS ARE REPORTING or NO DIST. PANELS ARE INSTALLED	Inventory Menu	Number of Distribution Bus Monitoring Circuit Cards in MCA inventory. Press ENTER to view individual Distribution Bus Monitoring Circuit Card inventory information. or No Distribution Bus Monitoring Circuit Cards installed.
151	PANEL B#-P#A/B INCLUDES 1 POINT or PANEL B#-P#A/B INCLUDES ## POINTS	Distribution Inventory Menu	Number of distribution devices this Distribution Bus Monitoring Circuit Card is monitoring. (B#-P#A/B = Bay Number-Distribution Bus Monitoring Circuit Card Position Number [Group A or B Designation if applicable.]) Press UP and DOWN ARROWS to view other Distribution Bus Monitoring Circuit Cards' distribution devices. Press ENTER to view individual distribution devices' inventory information.
152	GO TO INVENTORY MENU	Distribution Inventory Menu	Press ENTER to go to this menu.
153	GO BACK TO MENU TREE BEGINNING	Distribution Inventory Menu	Press ENTER to go to the beginning of the MCA Menu Tree.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
154	POINT B#-P#A/B IS A F/CB/PI	Distribution Inventory Detail Menu	Distribution device identification number and type. (B#-P#A/B = Bay Number-Distribution Device Position Number [Group A or B Designation if applicable.]) (F/CB/PI = Fuse or Circuit Breaker or PlugIn) Press UP and DOWN ARROWS to view other Distribution Devices' inventory information.
155	PANEL B#-P#A/B ASSEMBLY #####	Distribution Inventory Detail Menu	Distribution Panel Assembly Number. (B#-P#A/B = Bay Number-Distribution Bus Monitoring Circuit Card Position Number [Group A or B Designation if applicable.])
156	PANEL B#-P#A/B SERIAL # #####	Distribution Inventory Detail Menu	Distribution Panel Serial Number. (B#-P#A/B = Bay Number-Distribution Bus Monitoring Circuit Card Position Number [Group A or B Designation if applicable.])
157	PANEL B#-P#A/B BOOTCODE #####	Distribution Inventory Detail Menu	Distribution Panel Bootcode Number. (B#-P#A/B = Bay Number-Distribution Bus Monitoring Circuit Card Position Number [Group A or B Designation if applicable.])
158	PANEL B#-P#A/B SOFTWARE #####	Distribution Inventory Detail Menu	Distribution Panel Software Number. (B#-P#A/B = Bay Number-Distribution Bus Monitoring Circuit Card Position Number [Group A or B Designation if applicable.])
159	GO TO DISTRIBUTION INVENTORY	Distribution Inventory Detail Menu	Press ENTER to go to this menu.
160	GO BACK TO MENU TREE BEGINNING	Distribution Inventory Detail Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
161	1 I/O BOARD IS REPORTING or ## I/O BOARDS ARE REPORTING or NO I/O BOARDS ARE INSTALLED	Inventory Menu	Number of MCA I/O Circuit Cards in MCA inventory. Press ENTER to view individual MCA I/O Circuit Card inventory information. or No MCA I/O Circuit Cards installed.
162	I/O BOARD B#-P# IS INSTALLED	I/O Board Inventory Menu	MCA I/O Circuit Card identification number. (B#-P# = Bay Number-I/O Circuit Card Position Number). Press UP and DOWN ARROWS to view other MCA I/O Circuit Cards' identification numbers.
163	GO TO INVENTORY MENU	I/O Board Inventory Menu	Press ENTER to go to this menu.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
164	GO BACK TO MENU TREE BEGINNING	I/O Board Inventory Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
165	BOARD B#-P# ASSEMBLY #####	I/O Board Inventory Detail Menu	MCA I/O Circuit Card Assembly Number. (B#-P# = Bay Number-MCA I/O Circuit Card Position Number).
166	BOARD B#-P# SERIAL # #####	I/O Board Inventory Detail Menu	MCA I/O Circuit Card Serial Number. (B#-P# = Bay Number-MCA I/O Circuit Card Position Number).
167	BOARD B#-P# BOOTCODE #####	I/O Board Inventory Detail Menu	MCA I/O Circuit Card Bootcode Number. (B#-P# = Bay Number-MCA I/O Circuit Card Position Number).
168	BOARD B#-P# SOFTWARE #####	I/O Board Inventory Detail Menu	MCA I/O Circuit Card Software Number. (B#-P# = Bay Number-MCA I/O Circuit Card Position Number).
169	GO TO I/O BOARD INVENTORY	I/O Board Inventory Detail Menu	Press ENTER to go to this menu.
170	GO BACK TO MENU TREE BEGINNING	I/O Board Inventory Detail Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
171	1 ROUTER IS REPORTING or ## ROUTERS ARE REPORTING or NO ROUTERS ARE INSTALLED	Inventory Menu	Number of Router Circuit Cards in MCA inventory. Press ENTER to view individual Router Circuit Card inventory information. or No Router Circuit Cards installed.
172	ROUTER B# IS INSTALLED	Router Inventory Menu	Router Circuit Card identification number. (B# = Bay Number). Press UP and DOWN ARROWS to view other Router Circuit Cards' identification numbers.
173	GO TO INVENTORY MENU	Router Inventory Menu	Press ENTER to go to this menu.
174	GO BACK TO MENU TREE BEGINNING	Router Inventory Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
175	ROUTER B# ASSEMBLY #####	Router Inventory Detail Menu	Router Assembly Number. (B# = Bay Number).
176	ROUTER B# SERIAL # #####	Router Inventory Detail Menu	Router Serial Number. (B# = Bay Number).

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
177	ROUTER B# BOOTCODE #####	Router Inventory Detail Menu	Router Bootcode Number. (B# = Bay Number).
178	ROUTER B# SOFTWARE #####	Router Inventory Detail Menu	Router Software Number. (B# = Bay Number).
179	GO TO ROUTER INVENTORY	Router Inventory Detail Menu	Press ENTER to go to this menu.
180	GO BACK TO MENU TREE BEGINNING	Router Inventory Detail Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
181	1 RELAY BOARD IS REPORTING or ## RELAY BOARDS ARE REPORTING or NO RELAY BOARDS ARE INSTALLED	Inventory Menu	Number of MCA Customer Alarm Relay Circuit Cards in MCA inventory. Press ENTER to view individual MCA Customer Alarm Relay Circuit Card inventory information. or No MCA Customer Alarm Relay Circuit Cards installed.
182	RELAY BOARD B#-P# IS INSTALLED	Relay Inventory Menu	MCA Customer Alarm Relay Circuit Card identification number. (B#-P# = Bay Number-Relay Circuit Card Position Number). Press UP and DOWN ARROWS to view other MCA Customer Alarm Relay Circuit Cards' identification numbers.
183	GO TO INVENTORY MENU	Relay Inventory Menu	Press ENTER to go to this menu.
184	GO BACK TO MENU TREE BEGINNING	Relay Inventory Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
185	BOARD B#-P# ASSEMBLY #####	Relay Inventory Detail Menu	MCA Customer Alarm Relay Circuit Card Assembly Number. (B#-P# = Bay Number-MCA Customer Alarm Relay Circuit Card Position Number).
186	BOARD B#-P# SERIAL # #####	Relay Inventory Detail Menu	MCA Customer Alarm Relay Circuit Card Serial Number. (B#-P# = Bay Number-MCA Customer Alarm Relay Circuit Card Position Number).
187	BOARD B#-P# BOOTCODE #####	Relay Inventory Detail Menu	MCA Customer Alarm Relay Circuit Card Bootcode Number. (B#-P# = Bay Number-MCA Customer Alarm Relay Circuit Card Position Number).
188	BOARD B#-P# SOFTWARE #####	Relay Inventory Detail Menu	MCA Customer Alarm Relay Circuit Card Software Number. (B#-P# = Bay Number-MCA Customer Alarm Relay Circuit Card Position Number).

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
189	GO TO RELAY BOARD INVENTORY	Relay Inventory Detail Menu	Press ENTER to go to this menu.
190	GO BACK TO MENU TREE BEGINNING	Relay Inventory Detail Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
191	TEMPERATURE SENSOR REPORTING or NO TEMPERATURE SENSOR	Inventory Menu	Temperature Sensor is in MCA inventory. or No Temperature Sensor installed.
192	MONITORING IS REPORTING or NO MONITORING IS INSTALLED	Inventory Menu	LMS1000 is communicating with the MCA. or No LMS1000 installed in the MCA's inventory.
193	MONITORING ASSEMBLY #####	Monitoring Inventory Detail Menu	Specification number (Spec. No.) of the LMS1000 Main CPU circuit card.
194	MONITORING SERIAL # #####	Router Inventory Detail Menu	Serial number of the LMS1000 Main CPU circuit card.
195	MONITORING BOOTCODE #####	Monitoring Inventory Detail Menu	Software bootcode revision number of the LMS1000 Main CPU circuit card.
196	MONITORING SOFTWARE #####	Monitoring Inventory Detail Menu	Software version number of the LMS1000 Main CPU circuit card.
197	GO TO INVENTORY MENU	Monitoring Inventory Detail Menu	Press ENTER to go to this menu.
198	GO BACK TO MENU TREE BEGINNING	Monitoring Inventory Detail Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
199	SENSE VOLTAGE IS REMOTE INPUT or SENSE VOLTAGE IS AVERAGED	Inventory Menu	Indicates if an external (remote) voltage input (for MCA alarms and meter reading) is applied to the MCA / Router circuit card, or if the voltage input for MCA alarms and meter reading is the average of each bay's sense voltages (no external input applied).
200	CONTROLLER ASSEMBLY #####	Inventory Menu	Specification number (Spec. No.) of the MCA/Router circuit card.
201	CONTROLLER SERIAL # #####	Controller Detail Menu	Serial number of the MCA/Router circuit card.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
202	CONTROLLER BOOTCODE #####	Controller Detail Menu	Software bootcode version number of the MCA/Router circuit card.
203	CONTROLLER SOFTWARE #####	Controller Detail Menu	Software version number of the MCA/Router circuit card.
204	DISPLAY ASSEMBLY #####	Controller Detail Menu	Specification number (Spec. No.) of the Display circuit card.
205	DISPLAY SERIAL # #####	Controller Detail Menu	Serial number of the Display circuit card.
206	DISPLAY BOOTCODE #####	Controller Detail Menu	Software bootcode version number of the Display circuit card.
207	DISPLAY SOFTWARE #####	Controller Detail Menu	Software version number of the Display circuit card.
208	GO TO INVENTORY MENU	Controller Detail Menu	Press ENTER to go to this menu.
209	GO BACK TO MENU TREE BEGINNING	Controller Detail Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
210	UPDATE THE INVENTORY	Inventory Menu	<p>Allows resetting the inventory count when an inventory item is removed from the system by the user.</p> <p>When an inventory item is removed from the system, an alarm will be reported until "UPDATE THE INVENTORY" is entered.</p> <p>Example, if a Rectifier Module (PCU) is removed from the system, the Rectifier Module will not be removed from the MCA's inventory until "UPDATE THE INVENTORY" operation is completed.</p> <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
211	GO TO FUNCTION MENU	Inventory Menu	Press ENTER to go to this menu.
212	GO BACK TO MENU TREE BEGINNING	Inventory Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
213	ADJUST THE SYSTEM VOLTS & AMPS	Function Menu	Press ENTER to go to the System Adjustment Menu.
214	FLOAT SETPOINT = vv.vvV	System Adjustment Menu	<p>Allows you to change the Float Output Voltage set point.</p> <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
215	TEST/EQUALIZE = vv.vvV	System Adjustment Menu	<p>Allows you to change the Test/Equalize Output Voltage set point.</p> <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
219	HI VOLTAGE SHUTDOWN = vv.vvV	System Adjustment Menu	Allows you to change the High Voltage Shutdown set point. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
220	TEST H.V. SHUTDOWN = vv.vvV LOSS IS POSSIBLE. GO AHEAD ANYWAY?	System Adjustment Menu	Allows you to temporarily change the High Voltage Shutdown set point to another value (such as system voltage) to test the high voltage shutdown circuits. 1. Press ENTER and ALARM CUTOFF (at the same time). 2. Press YES / + / i or NO / - to increment or decrement, respectively, the High Voltage Shutdown value displayed. 3. A WARNING appears. Press ENTER and ALARM CUTOFF (at the same time) if you wish to proceed. This <u>immediately</u> changes the HVS setting. The HVS setting reverts back to its previous setting by pressing ENTER, or simultaneously pressing YES / + / i and NO / -.
221	PCU CURRENT LIMIT = aaaaaA or PCU CURRENT LIMIT = aaaaaMAX or PCU CURRENT LIMIT POWER SHARE or PCU CURRENT LIMIT ALT. LIMIT	System Adjustment Menu	Allows you to change the Current Limit set point. aaaaaA = System current limit setting, current limit circuit on all Rectifier Modules are automatically adjusted to ensure system current does not exceed this value. aaaaaMAX = System current limit setting is set to the sum of the maximum current capacities of all Rectifier Modules installed in the system. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. Note: When Power Share is enabled, current limit is controlled by the Power Share feature. Note: When Alternate Current Limit is enabled and active, current limit is controlled by the Alternate Current Limit feature.
222	100% PCU CURRENT IS aaaaaA	System Adjustment Menu	This value is only displayed. MCA calculates the value from all Rectifier Modules (PCUs) installed. There is no user adjustment.
223	GO TO FUNCTION MENU	System Adjustment Menu	Press ENTER to go to this menu.
224	GO BACK TO MENU TREE BEGINNING	System Adjustment Menu	Press ENTER to go to the beginning of the MCA Menu Tree.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
225	ADJUST THE ALARM SETPOINTS	Function Menu	Press ENTER to go to the Alarm Adjustment Menu.
226	SYSTEM HI VOLTAGE #1 = vv.vvV	Alarm Adjustment Menu	Allows you to change the System High Voltage #1 Alarm set point. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
227	SYSTEM HI VOLTAGE #2 = vv.vvV	Alarm Adjustment Menu	Allows you to change the System High Voltage #2 Alarm set point. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
228	BATTERY ON DISCHARGE = vv.vvV	Alarm Adjustment Menu	Allows you to change the Battery on Discharge Alarm set point. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
229	VERY LOW VOLTAGE = vv.vvV	Alarm Adjustment Menu	Allows you to change the Very Low Voltage Alarm set point. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
230	TOTAL LOAD CURRENT = aaaaaA	Alarm Adjustment Menu	Allows you to change the Total Load Current Alarm set point. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
231	DISTRIBUTION GROUP A = aaaaaA	Alarm Adjustment Menu	Allows you to change the Distribution Group A Load Current Alarm set point. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
232	DISTRIBUTION GROUP B = aaaaaA	Alarm Adjustment Menu	Allows you to change the Distribution Group B Load Current Alarm set point. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
233	HIGH TEMPERATURE #1 = ttt°C/F or NO HIGH TEMPERATURE #1 ALARM	Alarm Adjustment Menu	Allows you to change the High Temperature #1 Alarm set point, or disable the alarm. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. Note: To disable the feature, press YES / + / i when in the change setting mode to scroll to NO HIGH TEMPERATURE #1 ALARM (displayed when you scroll up to "100°C").

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
234	HIGH TEMPERATURE #2 = ttt°C/F or NO HIGH TEMPERATURE #2 ALARM	Alarm Adjustment Menu	Allows you to change the High Temperature #2 Alarm set point, or disable the alarm. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. Note: To disable the feature, press YES / + / i when in the change setting mode to scroll to <i>NO HIGH TEMPERATURE #2 ALARM</i> (displayed when you scroll up to "100°C").
235	LOW TEMPERATURE #1 = ttt°C/F or NO LOW TEMPERATURE #1 ALARM	Alarm Adjustment Menu	Allows you to change the Low Temperature #1 Alarm set point, or disable the alarm. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. Note: To disable the feature, press NO / - when in the change setting mode to scroll to <i>NO LOW TEMPERATURE #1 ALARM</i> (displayed when you scroll down to "-50°C").
236	LOW TEMPERATURE #2 = ttt°C/F or NO LOW TEMPERATURE #2 ALARM	Alarm Adjustment Menu	Allows you to change the Low Temperature #2 Alarm set point, or disable the alarm. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. Note: To disable the feature, press NO / - when in the change setting mode to scroll to <i>NO LOW TEMPERATURE #2 ALARM</i> (displayed when you scroll down to "-50°C").
237	GO TO FUNCTION MENU	Alarm Adjustment Menu	Press ENTER to go to this menu.
238	GO BACK TO MENU TREE BEGINNING	Alarm Adjustment Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
239	TURN PCUs ON OR OFF or ENERGY MANAGEMENT IS IN CONTROL or PCU SEQUENCER IS IN CONTROL	Function Menu	Press ENTER to go to the Rectifier Module (PCU) Enable Menu. Note: Rectifier Modules cannot be turned on or off when they are being actively managed via the LMS.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
240	PCU B#-ID#/N# ON TURN IT OFF? or PCU B#-ID#/N# OFF TURN IT ON?	PCU Enable Menu	<p>Allows you to turn a Rectifier Module (PCU) ON or OFF (Local TR inhibit feature).</p> <ol style="list-style-type: none"> 1. Press the UP and DOWN ARROWS to navigate to the Rectifier Module to turn ON or OFF (B#-ID#/N# = Bay Number-Rectifier Module MCA ID# w/in Bay/Number of Rectifier Modules in System). 2. Press ENTER and ALARM CUTOFF (at the same time) to change the TR setting for this Rectifier Module. 3. At the "ARE YOU SURE?" prompt, press either YES / + / i to accept the new setting, or NO / - to cancel this operation without changing the existing setting.
241	GO TO FUNCTION MENU	PCU Enable Menu	Press ENTER to go to this menu.
242	GO BACK TO MENU TREE BEGINNING	PCU Enable Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
243	CHANGE CONFIGURATION PARAMETERS	Function Menu	Press ENTER to go to the Configure Menu.
244	CHANGE I/O BOARD PARAMETERS	Configure Menu	<p>Allows you to change the MCA I/O circuit card(s) configurable parameters.</p> <p>Press ENTER to configure the MCA I/O circuit cards.</p>
245	ANALOG INPUT B#-P# IS DISTRIBUTION or ANALOG INPUT B#-P# IS AUXILIARY	I/O Board Configuration Menu	<p>Select the MCA I/O circuit card to be configured, and designate the analog input for this MCA I/O circuit card as "Distribution" or "Auxiliary". The MCA displays the AUXILIARY load currents in a separate menu, the DISTRIBUTION load currents are added to the Distribution Menus.</p> <ol style="list-style-type: none"> 1. Press the UP and DOWN ARROWS to navigate to the MCA I/O circuit card to configure (B#-P# = Bay Number-MCA I/O Circuit Card Position Number). 2. Press ENTER and ALARM CUTOFF (at the same time) to change the setting for this MCA I/O circuit card. 3. At the "ARE YOU SURE?" prompt, press either YES / + / i to accept the new setting, or NO / - to cancel this operation without changing the existing setting.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
246	ANALOG INPUT B#-P# 50mV = aaaaaA	I/O Board Configuration Menu	<p>Select the MCA I/O circuit card to be configured, and set the scale factor for the analog input on this MCA I/O circuit card.</p> <ol style="list-style-type: none"> 1. Press the UP and DOWN ARROWS to navigate to the MCA I/O circuit card to configure (B#-P# = Bay Number-MCA I/O Circuit Card Position Number). 2. Refer to "Changing a Value or Setting" in the table at the beginning of this document to complete the operation.
247	ANALOG OUTPUT B#-P# 50mV = aaaaaA	I/O Board Configuration Menu	<p>Select the MCA I/O circuit card to be configured, and set the scale factor for the analog output on this MCA I/O circuit card.</p> <ol style="list-style-type: none"> 1. Press the UP and DOWN ARROWS to navigate to the MCA I/O circuit card to configure (B#-P# = Bay Number-MCA I/O Circuit Card Position Number). 2. Refer to "Changing a Value or Setting" in the table at the beginning of this document to complete the operation.
248	BINARY INPUT B#-P#-I# ALARM = CLOSED or BINARY INPUT B#-P#-I# ALARM = OPEN	I/O Board Configuration Menu	<p>Select the MCA I/O circuit card to be configured, and set the alarm state for each binary input on this MCA I/O circuit card.</p> <ol style="list-style-type: none"> 1. Press the UP and DOWN ARROWS to navigate to the MCA I/O circuit card and binary input to configure (B#-P#-I# = Bay Number-MCA I/O Circuit Card Position Number-Binary Input Number). 2. Press ENTER and ALARM CUTOFF (at the same time) to change the setting for this MCA I/O circuit card. 3. At the "ARE YOU SURE?" prompt, press either YES / + / i to accept the new setting, or NO / - to cancel this operation without changing the existing setting.
249	GO TO CONFIGURE MENU	I/O Board Configuration Menu	Press ENTER to go to this menu.
250	GO BACK TO MENU TREE BEGINNING	I/O Board Configuration Menu	Press ENTER to go to the beginning of the MCA Menu Tree.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
251	AUDIBLE SILENT TIME = mm MINUTES or AUDIBLE ALARMS STAY SILENCED	Configure Menu	<p>Allows you to enable the MCA Audible Alarm feature and set the Audible Alarm Cutoff Reset Time Period set point, or disable the feature.</p> <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. Note: To disable the feature, press NO / - when in the change setting mode to scroll to <i>AUDIBLE ALARMS STAY SILENCED</i> (displayed when you scroll down to "zero minutes").
252	PCU SEQUENCING IS DISABLED or PCU SEQUENCING DELAY = ss SECONDS	Configure Menu	<p>Allows you to enable the Rectifier Module (PCU) Sequencing feature and set the Rectifier Module (PCU) Sequencing Delay set point, or disable the feature.</p> <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. Note: To disable the feature, press NO / - when in the change setting mode to scroll to <i>Rectifier SEQUENCING IS DISABLED</i> (displayed when you scroll down to "zero seconds").

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
254	AUTO EQUALIZE IS DISABLED or AUTO EQUALIZE FOR ## x DISCHARGE or END AUTO EQUALIZE IN hhh.hh HOURS or TURN OFF POWER SHARE or TURN OFF ALTERNATE CURRENT LIMIT	Configure Menu	Allows you to enable the Auto Test/Equalize feature and set the Auto Test/Equalize Multiplier set point, or disable the feature. <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. Note: To disable the feature, press NO / - when in the change setting mode to scroll to <i>AUTO EQUALIZE IS DISABLED</i> (displayed when you scroll down to "zero x discharge"). or Displays remaining auto test/equalize time if an auto test/equalize is in process. or When the Power Share or Alternate Current Limit feature is enabled, the system cannot be placed in the Test/Equalize mode. Note: Test/Equalize Mode requires Power Share and Alternate Current Limit to be turned off. A message is displayed if Power Share or Alternate Current Limit is on. Turn Power Share or Alternate Current Limit off first then return to this menu.
255	DEFINE RELAY FUNCTIONS	Configure Menu	Allows you to define a Relay Function Channel by assigning alarm conditions to a specific Relay Function Channel. Press ENTER to define relay functions.
256	DEFINE RELAY FUNCTION A#	Relay Function Menu	Select the Relay Function Channel to be defined. <ol style="list-style-type: none"> 1. Press the UP and DOWN ARROWS to navigate to the desired Relay Function Channel. (A# = Relay Function Channel Number.) 2. Press ENTER to define the selected Relay Function Channel. Note: See the table in Section 5876 (Installation Instructions) for the MCA default configuration.
257	GO TO CONFIGURE MENU	Relay Function Menu	Press ENTER to go to this menu.
258	GO BACK TO MENU TREE BEGINNING	Relay Function Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
259	CHECKED CONDITIONS DE-ENERGIZE or CHECKED CONDITIONS ENERGIZE	Relay Function Definition Menu	Select whether the relay(s) assigned to this Relay Function Channel will energize or deenergize for any condition checked (selected) below. <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
260	EMERGENCY STOP INPUT ACTIVE or EMERGENCY STOP INPUT ACTIVE	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
261	HI VOLTAGE SHUTDOWN INPUT ACTIVE or HI VOLTAGE SHUTDOWN INPUT ACTIVE	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
261A	ALTERNATE CURRENT LIMIT ACTIVE or ALTERNATE CURRENT LIMIT ACTIVE	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
262	SYSTEM VOLTAGE IS VERY LOW or SYSTEM VOLTAGE IS VERY LOW	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
263	SYSTEM BATTERY ON DISCHARGE or SYSTEM BATTERY ON DISCHARGE	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
264	SYSTEM HIGH VOLTAGE #1 ALARM or SYSTEM HIGH VOLTAGE #1 ALARM	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
265	SYSTEM HIGH VOLTAGE #2 ALARM or SYSTEM HIGH VOLTAGE #2 ALARM	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
266	1 SYSTEM BREAKER OR FUSE ALARM or 1 SYSTEM BREAKER OR FUSE ALARM	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
267	2+ SYSTEM BREAKER & FUSE ALARMS or 2+ SYSTEM BREAKER & FUSE ALARMS	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
268	AC POWER IS OFF TO 1 PCU or AC POWER IS OFF TO 1 PCU	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
269	AC POWER IS OFF TO 2+ PCUs or AC POWER IS OFF TO 2+ PCUs	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
270	AC POWER IS OFF TO ALL PCUs or AC POWER IS OFF TO ALL PCUs	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
271	1 PCU FAILURE ANY TYPE or 1 PCU FAILURE ANY TYPE	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
272	2+ PCU FAILURES ANY TYPE or 2+ PCU FAILURES ANY TYPE	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
273	1 PCU FAILURE 'MAJOR' TYPE or 1 PCU FAILURE 'MAJOR' TYPE	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. Note: Thermal Current Limit, 1 Fan Failure, High Ambient Temperature, and Sense Loss are 'Minor' alarm conditions. All other Rectifier Module alarms are 'Major' alarm conditions.
274	2+ PCU FAILURES 'MAJOR' TYPE or 2+ PCU FAILURES 'MAJOR' TYPE	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. Note: Thermal Current Limit, 1 Fan Failure, High Ambient Temperature, and Sense Loss are 'Minor' alarm conditions. All other Rectifier Module alarms are 'Major' alarm conditions.
275	1 PCU FAILURE 'MINOR' TYPE or 1 PCU FAILURE 'MINOR' TYPE	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. Note: Thermal Current Limit, 1 Fan Failure, High Ambient Temperature, and Sense Loss are 'Minor' alarm conditions. All other Rectifier Module alarms are 'Major' alarm conditions.
276	2+ PCU FAILURES 'MINOR' TYPE or 2+ PCU FAILURES 'MINOR' TYPE	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. Note: Thermal Current Limit, 1 Fan Failure, High Ambient Temperature, and Sense Loss are 'Minor' alarm conditions. All other Rectifier Module alarms are 'Major' alarm conditions.
277	NO PCUs ARE IN INVENTORY or NO PCUs ARE IN INVENTORY	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
278	1 DIST. PANEL FAILURE or 1 DIST. PANEL FAILURE	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
279	2+ DIST. PANEL FAILURES or 2+ DIST. PANEL FAILURES	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
280	NO DIST. PANELS IN INVENTORY or NO DIST. PANELS IN INVENTORY	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
281	1 I/O BOARD FAILURE or 1 I/O BOARD FAILURE	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
282	2+ I/O BOARD FAILURES or 2+ I/O BOARD FAILURES	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
283	NO I/O BOARDS ARE IN INVENTORY or NO I/O BOARDS ARE IN INVENTORY	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
284	1 ROUTER FAILURE or 1 ROUTER FAILURE	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
285	2+ ROUTER FAILURES or 2+ ROUTER FAILURES	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
286	NO ROUTERS ARE IN INVENTORY or NO ROUTERS ARE IN INVENTORY	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
287	1 RELAY BOARD FAILURE or 1 RELAY BOARD FAILURE	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
288	2+ RELAY BOARD FAILURES or 2+ RELAY BOARD FAILURES	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
289	NO RELAY BOARDS ARE IN INVENTORY or NO RELAY BOARDS ARE IN INVENTORY	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
290	HIGH TEMPERATURE #1 ALARM or HIGH TEMPERATURE #1 ALARM	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
291	HIGH TEMPERATURE #2 ALARM or HIGH TEMPERATURE #2 ALARM	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
292	LOW TEMPERATURE #1 ALARM or LOW TEMPERATURE #1 ALARM	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
293	LOW TEMPERATURE #2 ALARM or LOW TEMPERATURE #2 ALARM	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
294	TEMPERATURE SENSOR NO SIGNAL or TEMPERATURE SENSOR NO SIGNAL	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
295	MAJOR MONITORING ALARM(S) or MAJOR MONITORING ALARM(S)	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. Note: If any of these LMS1000 conditions are selected to contribute to an MCA alarm, the User must ensure that the LMS1000 is programmed so that the MCA does not contribute to the LMS1000 condition.
296	MINOR MONITORING ALARM(S) or MINOR MONITORING ALARM(S)	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. Note: If any of these LMS1000 conditions are selected to contribute to an MCA alarm, the User must ensure that the LMS1000 is programmed so that the MCA does not contribute to the LMS1000 condition.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
297	<p><i>All Monitoring LED Messages</i></p> <p>or</p> <p><i>All Monitoring LED Messages</i></p>	Relay Function Definition Menu	<p>This condition is selected when the (checkmark) symbol is displayed.</p> <p>This condition is deselected when a space is displayed instead of the (checkmark) symbol.</p> <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. <p>Note: If any of these LMS1000 conditions are selected to contribute to an MCA alarm, the User must ensure that the LMS1000 is programmed so that the MCA does not contribute to the LMS1000 condition.</p>
298	<p>MONITORING DOES NOT RESPOND</p> <p>or</p> <p>MONITORING DOES NOT RESPOND</p>	Relay Function Definition Menu	<p>This condition is selected when the (checkmark) symbol is displayed.</p> <p>This condition is deselected when a space is displayed instead of the (checkmark) symbol.</p> <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
299	<p>CONTROLLER FAILURE</p> <p>or</p> <p>CONTROLLER FAILURE</p>	Relay Function Definition Menu	<p>This condition is selected when the (checkmark) symbol is displayed.</p> <p>This condition is deselected when a space is displayed instead of the (checkmark) symbol.</p> <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
300	<p>THE CONTROLLER IS INITIALIZING</p> <p>or</p> <p>THE CONTROLLER IS INITIALIZING</p>	Relay Function Definition Menu	<p>This condition is selected when the (checkmark) symbol is displayed.</p> <p>This condition is deselected when a space is displayed instead of the (checkmark) symbol.</p> <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
301	<p>TOTAL LOAD CURRENT ALARM</p> <p>or</p> <p>TOTAL LOAD CURRENT ALARM</p>	Relay Function Definition Menu	<p>This condition is selected when the (checkmark) symbol is displayed.</p> <p>This condition is deselected when a space is displayed instead of the (checkmark) symbol.</p> <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
302	<p>DIST. GROUP A LOAD ALARM</p> <p>or</p> <p>DIST. GROUP A LOAD ALARM</p>	Relay Function Definition Menu	<p>This condition is selected when the (checkmark) symbol is displayed.</p> <p>This condition is deselected when a space is displayed instead of the (checkmark) symbol.</p> <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
303	DIST. GROUP B LOAD ALARM or DIST. GROUP B LOAD ALARM	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
304	THE DISPLAY DOES NOT RESPOND or THE DISPLAY DOES NOT RESPOND	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
305	TEST/EQUALIZE MODE IS ACTIVE or TEST/EQUALIZE MODE IS ACTIVE	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
306	THE AUDIBLE ALARM IS ACTIVE or THE AUDIBLE ALARM IS ACTIVE	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
307	AUDIBLE ALARMS ARE SILENCED or AUDIBLE ALARMS ARE SILENCED	Relay Function Definition Menu	This condition is selected when the (checkmark) symbol is displayed. This condition is deselected when a space is displayed instead of the (checkmark) symbol. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
308	GO TO RELAY FUNCTION MENU	Relay Function Definition Menu	Press ENTER to go to this menu.
309	GO BACK TO MENU TREE BEGINNING	Relay Function Definition Menu	Press ENTER to go to the beginning of the MCA Menu Tree.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
313	GO TO CONFIGURE MENU	Relay Assignment Menu	Press ENTER to go to this menu.
314	GO BACK TO MENU TREE BEGINNING	Relay Assignment Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
315	NO TEMPERATURE COMPENSATION or TEMPERATURE SLOPE = 0.vvvV/°C/F or TURN OFF POWER SHARE or TURN OFF ALTERNATE CURRENT LIMIT	Configure Menu	<p>Allows you to enable the Battery Charge Temperature Compensation feature and set the Battery Charge Temperature Compensation Slope set point, or disable the feature.</p> <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. <p>Note: To disable the feature, press NO / - when in the change setting mode to scroll to <i>NO TEMPERATURE COMPENSATION</i> (displayed when you scroll down to "OV/°C").</p> <p>Note: This is the voltage slope of the entire battery string, not individual cells.</p> <p>Note: The Temperature Compensation feature requires Power Share and Alternate Current Limit to be turned off. A message is displayed if Power Share or Alternate Current Limit is on. Turn Power Share or Alternate Current Limit off first then return to this menu to enable Temperature Compensation.</p>
316	MAXIMUM COMPENSATION = vv.vvV	Configure Menu	<p>Allows you to change the Maximum Voltage with Temperature Compensation set point.</p> <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
317	MINIMUM COMPENSATION = vv.vvV	Configure Menu	<p>Allows you to change the Minimum Voltage with Temperature Compensation set point.</p> <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
318	NOW DISPLAYING °C/F SET TO °C/F?	Configure Menu	<p>Allows you to change the temperature unit (degrees F or degrees C).</p> <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
319	IT IS NOW hh:mm:ss dd-mon-yy	Configure Menu	<p>Allows you to change the time and time.</p> <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
320	ERASE THE ALARM LOG	Configure Menu	<p>Deletes all MCA Alarm Log entries.</p> <ol style="list-style-type: none"> 1. Refer to "Changing a Control Function" in the table at the beginning of this section.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
320A	CHANGE NETWORK ADDRESSES	Configure Menu	Allows you to view and change the network IP, gateway, and netmask addresses used by the LMS1000 when connecting to the network.
320B	###.###.###.### MAC ADDRESS	Network Address Menu	Displays the Ethernet (MAC) address used by the LMS1000 when connecting to the network. Note: This address cannot be changed, only viewed.
320C	####.###.###.### IP ADDRESS	Network Address Menu	Allows you to change the IP address used by the LMS1000 when connecting to the network.
320D	####.###.###.### NET MASK ADDRESS	Network Address Menu	Allows you to change the netmask address used by the LMS1000 when connecting to the network.
320E	####.###.###.### GATEWAY ADDRESS	Network Address Menu	Allows you to change the gateway address used by the LMS1000 when connecting to the network.
320F	VALIDATE THE ADDRESS CHANGES? or UPDATE/RESTART LMS WITH CHANGES? or THE CHANGES WERE REJECTED	Network Address Menu	This allows you to save the address changes that were made. The system must first verify that the new IP, netmask, and gateway addresses are compatible with each other. or This allows you to pass the saved addresses to the LMS1000. Note: The LMS1000 will need to be restarted for the address changes to take effect. or The new IP, netmask, and gateway addresses are not compatible with each other. The changes are not accepted.
320G	GO TO CONFIGURE MENU	Network Address Menu	Press ENTER to go to this menu.
320H	GO BACK TO MENU TREE BEGINNING	Network Address Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
321	NO FUNCTION IN THIS SYSTEM		
321A	NO FUNCTION IN THIS SYSTEM		
321B	NO FUNCTION IN THIS SYSTEM		
321C	NO FUNCTION IN THIS SYSTEM		
321D	NO FUNCTION IN THIS SYSTEM		
321E	NO FUNCTION IN THIS SYSTEM		
321F	NO FUNCTION IN THIS SYSTEM		
321G	NO FUNCTION IN THIS SYSTEM		
322	GO TO FUNCTION MENU	Configure Menu	Press ENTER to go to this menu.
322A	GO BACK TO MENU TREE BEGINNING	Configure Menu	Press ENTER to go to the beginning of the MCA Menu Tree.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
323	VERIFY TEST, ESTOP, & HVS INPUTS or TEST SHUTDOWN INPUT IS ON or EMERGENCY STOP INPUT IS ON or HI VOLTAGE SHUTDOWN INPUT IS ON	Function Menu	Allows you to verify the test, emergency stop, and high voltage shutdown inputs. <ol style="list-style-type: none"> Navigate to this menu item. Apply the Test input. Verify MCA displays <i>TEST SHUTDOWN INPUT IS ON</i>. With the Test input still applied, apply the Emergency Stop input. Verify MCA displays <i>EMERGENCY STOP INPUT IS ON</i>. Release the Emergency Stop input. With the Test input still applied, apply the High Voltage Shutdown input. Verify MCA displays <i>HI VOLTAGE SHUTDOWN INPUT IS ON</i>. Release the High Voltage Shutdown input. Release the Test input.
324	VIEW THE ALARM LOG	Function Menu	Press ENTER to view the MCA Alarm Log.
325	dd-mon-yy hh:mm:ss♪ CONTROLLER or dd-mon-yy hh:mm:ss CONTROLLER	Alarm Log Menu	Displays the alarms (with date and time stamp) recorded for the Controller element of the system. Note that the recordable alarm conditions are set by configuring MCA Relay Function Channel #24. The factory defaults are shown in this chart. Press UP and DOWN ARROWS to scroll if multiple alarms are recorded. A 'music note' (♪) after the date/time stamp indicates the alarm went active. A 'checkmark' (✓) indicates the alarm retired.
326	SYSTEM CONTROLLER NO ALARMS	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
327	EMERGENCY STOP INPUT ACTIVE	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
328	HI VOLTAGE SHUTDOWN INPUT ACTIVE	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
328A	ALTERNATE CURRENT LIMIT ACTIVE	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
329	SYSTEM VOLTAGE IS VERY LOW	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
330	SYSTEM BATTERY IS ON DISCHARGE	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
331	SYSTEM HIGH VOLTAGE #1 ALARM	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
332	SYSTEM HIGH VOLTAGE #2 ALARM	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
333	NO PCUs ARE IN INVENTORY	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
334	NO DIST. PANELS ARE IN INVENTORY	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
335	NO ROUTERS ARE IN INVENTORY	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
336	NO RELAY BOARDS ARE IN INVENTORY	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
337	HIGH TEMPERATURE #1 ALARM	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
338	HIGH TEMPERATURE #2 ALARM	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
339	LOW TEMPERATURE #1 ALARM	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
340	LOW TEMPERATURE #2 ALARM	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
341	TEMPERATURE SENSOR NO SIGNAL	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
342	MAJOR MONITORING ALARM(S)	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
343	MINOR MONITORING ALARM(S)	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
344	<i>Monitoring LED Messages</i>	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
345	MONITORING DOES NOT RESPOND	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
346	CONTROLLER FAILURE ####	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
347	THE CONTROLLER IS INITIALIZING	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
348	TOTAL LOAD CURRENT ALARM	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
349	GROUP A LOAD CURRENT ALARM	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
350	GROUP B LOAD CURRENT ALARM	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
351	THE DISPLAY DOES NOT RESPOND	MCA Alarm Log Detail Menu	Recordable MCA (Controller) event.
352	SYSTEM OUTPUT SENSE vv.vvV	MCA Alarm Log Detail Menu	Recordable System Data.
353	TOTAL LOAD CURRENT aaaaaA	MCA Alarm Log Detail Menu	Recordable System Data.
354	GO TO ALARM LOG MENU	MCA Alarm Log Detail Menu	Press ENTER to go to this menu.
355	GO BACK TO MENU TREE BEGINNING	MCA Alarm Log Detail Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
356	dd-mon-yy hh:mm:ss🎵 B#-SN# or dd-mon-yy hh:mm:ss B#-SN#	Alarm Log Menu	Displays the alarms (with date and time stamp) recorded for the Rectifier element of the system. Press UP and DOWN ARROWS to scroll if multiple alarms are recorded. A 'music note' (🎵) after the date/time stamp indicates the alarm went active. A 'checkmark' (✓) indicates the alarm retired.
357	PCU B#-SN# NO ALARMS	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) event.
358	PCU B#-SN# EMERG. STOP	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) event.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
359	PCU B#-SN# H.V. SHUTDOWN	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) event.
360	PCU B#-SN# AC LINE OFF	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) event.
361	PCU B#-SN# AC LINE LOW	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) event.
362	PCU B#-SN# AC LINE HIGH	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) event.
363	PCU B#-SN# AC PHASE LOST	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) event.
364	PCU B#-SN# POWER FACTOR	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) event.
365	PCU B#-SN# DC/DC CONV.	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) event.
366	PCU B#-SN# FUSE/BREAKER	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) event.
367	PCU B#-SN# INHIBITED	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) event.
368	PCU B#-SN# ON STANDBY	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) event.
369	PCU B#-SN# THERMAL LIMIT	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) event.
370	PCU B#-SN# THERMAL STOP	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) event.
371	PCU B#-SN# HIGH AMBIENT	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) event.
372	PCU B#-SN# LOAD SHARE	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) event.
373	PCU B#-SN# 1 FAN SPEED	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) event.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
374	PCU B#-SN# 2+ FANS SPEED	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) event.
375	PCU B#-SN# NO VOLT SENSE	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) event.
376	PCU B#-SN# DUPLICATED	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) event.
377	PCU B#-SN# NO RESPONSE	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) event.
378	PCU B#-SN# TURNED ON or PCU B#-SN# TURNED OFF	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) Data.
379	PCU B#-SN# aaaaaA	PCU Alarm Log Detail Menu	Recordable Rectifier Module (PCU) Data.
380	SYSTEM OUTPUT SENSE vv.vvV	PCU Alarm Log Detail Menu	Recordable System Data.
381	TOTAL LOAD CURRENT aaaaaA	PCU Alarm Log Detail Menu	Recordable System Data.
382	GO TO ALARM LOG MENU	PCU Alarm Log Detail Menu	Press ENTER to go to this menu.
383	GO BACK TO MENU TREE BEGINNING	PCU Alarm Log Detail Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
384	dd-mon-yy hh:mm:ss♪ PANEL B#-P#A/B or dd-mon-yy hh:mm:ss PANEL B#-P#A/B	Alarm Log Menu	Displays the alarms (with date and time stamp) recorded for the Distribution Panel element of the system. Press UP and DOWN ARROWS to scroll if multiple alarms are recorded. A 'music note' (♪) after the date/time stamp indicates the alarm went active. A 'checkmark' () indicates the alarm retired.
385	DIST. PANEL B#-P#A/B NO ALARMS	Distribution Alarm Log Detail Menu	Recordable Distribution Panel event.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
386	DIST. PANEL B#-P#A/B DISCONNECTED	Distribution Alarm Log Detail Menu	Recordable Distribution Panel event.
387	POSITION B#-P#A/B IS OPEN	Distribution Alarm Log Detail Menu	Recordable Distribution Panel event.
388	POSITION B#-P#A/B NOT FOUND or POSITION NOT FOUND PANEL B#-P#A/B	Distribution Alarm Log Detail Menu	Recordable Distribution Panel event.
389	POSITION B#-P#A/B TYPE UNKNOWN	Distribution Alarm Log Detail Menu	Recordable Distribution Panel event.
390	POSITION B#-P#A/B OVER CURRENT	Distribution Alarm Log Detail Menu	Recordable Distribution Panel event.
391	DIST. PANEL B#-P#A/B LVD FAILURE	Distribution Alarm Log Detail Menu	Recordable Distribution Panel event.
392	DIST. PANEL B#-P#A/B A/B CHANGED	Distribution Alarm Log Detail Menu	Recordable Distribution Panel event.
393	DIST. PANEL B#-P#A/B PROCESSOR	Distribution Alarm Log Detail Menu	Recordable Distribution Panel event.
394	DIST. PANEL B#-P#A/B IS DUPLICATED	Distribution Alarm Log Detail Menu	Recordable Distribution Panel event.
395	DIST. PANEL B#-P#A/B NO RESPONSE	Distribution Alarm Log Detail Menu	Recordable Distribution Panel event.
396	SYSTEM OUTPUT SENSE vv.vvV	Distribution Alarm Log Detail Menu	Recordable System Data.
397	TOTAL LOAD CURRENT aaaaaA	Distribution Alarm Log Detail Menu	Recordable System Data.
398	GO TO ALARM LOG MENU	Distribution Alarm Log Detail Menu	Press ENTER to go to this menu.
399	GO BACK TO MENU TREE BEGINNING	Distribution Alarm Log Detail Menu	Press ENTER to go to the beginning of the MCA Menu Tree.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
400	dd-mon-yy hh:mm:ss♪ I/O B#-P# or dd-mon-yy hh:mm:ss I/O B#-P#	Alarm Log Menu	Displays the alarms (with date and time stamp) recorded for the MCA I/O element of the system. Press UP and DOWN ARROWS to scroll if multiple alarms are recorded. A 'music note' (♪) after the date/time stamp indicates the alarm went active. A 'checkmark' () indicates the alarm retired.
401	I/O BOARD B#-P# NO ALARMS	I/O Board Alarm Log Detail Menu	Recordable Relay event.
402	I/O BOARD B#-P# BINARY I#	I/O Board Alarm Log Detail Menu	Recordable Relay event.
403	I/O BOARD B#-P# OVER CURRENT	I/O Board Alarm Log Detail Menu	Recordable Relay event.
404	I/O BOARD B#-P# PROCESSOR	I/O Board Alarm Log Detail Menu	Recordable Relay event.
405	I/O BOARD B#-P# IS DUPLICATED	I/O Board Alarm Log Detail Menu	Recordable Relay event.
406	I/O BOARD B#-P# NO RESPONSE	I/O Board Alarm Log Detail Menu	Recordable Relay event.
407	SYSTEM OUTPUT SENSE vv.vvV	I/O Board Alarm Log Detail Menu	Recordable System Data.
408	TOTAL LOAD CURRENT aaaaaA	I/O Board Alarm Log Detail Menu	Recordable System Data.
409	GO TO ALARM LOG MENU	I/O Board Alarm Log Detail Menu	Press ENTER to go to this menu.
410	GO BACK TO MENU TREE BEGINNING	I/O Board Alarm Log Detail Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
411	dd-mon-yy hh:mm:ss♪ ROUTER B# or dd-mon-yy hh:mm:ss ROUTER B#	Alarm Log Menu	Displays the alarms (with date and time stamp) recorded for the Router element of the system. Press UP and DOWN ARROWS to scroll if multiple alarms are recorded. A 'music note' (♪) after the date/time stamp indicates the alarm went active. A 'checkmark' () indicates the alarm retired.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
412	ROUTER B# NO ALARMS	Router Alarm Log Detail Menu	Recordable Router event.
413	ROUTER B# REMOTE SENSE OPEN	Router Alarm Log Detail Menu	Recordable Router event.
414	ROUTER B# INTERNAL SENSE OPEN	Router Alarm Log Detail Menu	Recordable Router event.
415	ROUTER B# PROCESSOR FAILURE	Router Alarm Log Detail Menu	Recordable Router event.
416	ROUTER B# REPORTS AN ILLEGAL NODE	Router Alarm Log Detail Menu	Recordable Router event.
417	ROUTER B# IS DUPLICATED	Router Alarm Log Detail Menu	Recordable Router event.
418	ROUTER B# DOES NOT RESPOND	Router Alarm Log Detail Menu	Recordable Router event.
419	ROUTER B# REMOTE SENSE vv.vvV	Router Alarm Log Detail Menu	Recordable Router Data.
420	ROUTER B# INTERNAL SENSE vv.vvV	Router Alarm Log Detail Menu	Recordable Router Data.
421	SYSTEM OUTPUT SENSE vv.vvV	Router Alarm Log Detail Menu	Recordable System Data.
422	TOTAL LOAD CURRENT aaaaaA	Router Alarm Log Detail Menu	Recordable System Data.
423	GO TO ALARM LOG MENU	Router Alarm Log Detail Menu	Press ENTER to go to this menu.
424	GO BACK TO MENU TREE BEGINNING	Router Alarm Log Detail Menu	Press ENTER to go to the beginning of the MCA Menu Tree.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
425	dd-mon-yy hh:mm:ss🎵 RELAY B#-P# or dd-mon-yy hh:mm:ss RELAY B#-P#	Alarm Log Menu	Displays the alarms (with date and time stamp) recorded for the Relay element of the system. Press UP and DOWN ARROWS to scroll if multiple alarms are recorded. A 'music note' (🎵) after the date/time stamp indicates the alarm went active. A 'checkmark' (☑) indicates the alarm retired.
426	RELAY BOARD B#-P# NO ALARMS	Relay Alarm Log Detail Menu	Recordable Relay event.
427	RELAY B#-P#-R# IS STUCK	Relay Alarm Log Detail Menu	Recordable Relay event.
428	RELAY BOARD B#-P# PROCESSOR	Relay Alarm Log Detail Menu	Recordable Relay event.
429	RELAY BOARD B#-P# IS DUPLICATED	Relay Alarm Log Detail Menu	Recordable Relay event.
430	RELAY BOARD B#-P# NO RESPONSE	Relay Alarm Log Detail Menu	Recordable Relay event.
431	SYSTEM OUTPUT SENSE vv.vvV	Relay Alarm Log Detail Menu	Recordable System Data.
432	TOTAL LOAD CURRENT aaaaaA	Relay Alarm Log Detail Menu	Recordable System Data.
433	GO TO ALARM LOG MENU	Relay Alarm Log Detail Menu	Press ENTER to go to this menu.
434	GO BACK TO MENU TREE BEGINNING	Relay Alarm Log Detail Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
435	GO TO FUNCTION MENU	Alarm Log Menu	Press ENTER to go to this menu.
436	GO BACK TO MENU TREE BEGINNING	Alarm Log Menu	Press ENTER to go to the beginning of the MCA Menu Tree.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
437	PCU B#-ID#/N# RECOGNIZED or DSM B#-P#A/B RECOGNIZED or I/O B#-P# RECOGNIZED or CRM B# RECOGNIZED or RCB B#-P# RECOGNIZED	Function Menu	Lists the last item in the system that was recognized by the MCA.
438	GO BACK TO MENU TREE BEGINNING	Function Menu	Press ENTER to go to the beginning of the MCA Menu Tree.
439	NO FUNCTION IN THIS SYSTEM		
440	NO FUNCTION IN THIS SYSTEM		
441	NO FUNCTION IN THIS SYSTEM		
442	NO FUNCTION IN THIS SYSTEM		
443	NO FUNCTION IN THIS SYSTEM		
444	NO FUNCTION IN THIS SYSTEM		
A	##### WAIT ## V#####	Initialization Menu	When the system is initially started, an initialization time and MCA software version number are displayed.
B	CHECK VALUES BEFORE STARTING	Initialization Menu	Allows you to view (and change) the MCA settings stored in memory before starting the system. 1. Press the UP and DOWN ARROWS to view (change) the following MCA settings.
C	FLOAT SETPOINT = vv.vvV	Initialization Menu	Allows you to change the Float Output Voltage set point. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
D	TEST/EQUALIZE = vv.vvV	Initialization Menu	Allows you to change the Test/Equalize Output Voltage set point. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
E	HI VOLTAGE SHUTDOWN = vv.vvV	Initialization Menu	Allows you to change the High Voltage Shutdown set point. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
F	PCU CURRENT LIMIT = aaaaaA or PCU CURRENT LIMIT = aaaaaMAX or PCU CURRENT LIMIT POWER SHARE or PCU CURRENT LIMIT ALT. LIMIT	Initialization Menu	Allows you to change the Current Limit set point. aaaaaA = System current limit setting, current limit circuit on all Rectifiers are automatically adjusted to ensure system current does not exceed this value. aaaaaMAX = System current limit setting is set to the sum of the maximum current capacities of all Rectifier Modules installed in the system. Note: When Power Share is enabled, current limit is controlled by the Power Share feature. Note: When Alternate Current Limit is enabled and active, current limit is controlled by the Alternate Current Limit feature. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
G	SYSTEM HI VOLTAGE #1 = vv.vvV	Initialization Menu	Allows you to change the System High Voltage #1 Alarm set point. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
H	SYSTEM HI VOLTAGE #2 = vv.vvV	Initialization Menu	Allows you to change the System High Voltage #2 Alarm set point. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
I	BATTERY ON DISCHARGE = vv.vvV	Initialization Menu	Allows you to change the Battery on Discharge Alarm set point. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
J	VERY LOW VOLTAGE = vv.vvV	Initialization Menu	Allows you to change the Very Low Voltage Alarm set point. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
K	TOTAL LOAD CURRENT = aaaaaA	Initialization Menu	Allows you to change the Total Distribution Load Current Alarm set point. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
L	DISTRIBUTION GROUP A = aaaaaA	Initialization Menu	Allows you to change the Distribution Group A Load Current Alarm set point. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
M	DISTRIBUTION GROUP B = aaaaaA	Initialization Menu	Allows you to change the Distribution Group B Load Current Alarm set point. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
N	HIGH TEMPERATURE #1 = ttt°C/F or NO HIGH TEMPERATURE #1 ALARM	Initialization Menu	Allows you to change the High Temperature #1 Alarm set point, or disable the alarm. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. Note: To disable the feature, press YES / + / i when in the change setting mode to scroll to <i>NO HIGH TEMPERATURE #1 ALARM</i> (displayed when you scroll up to "100°C").
O	HIGH TEMPERATURE #2 = ttt°C/F or NO HIGH TEMPERATURE #2 ALARM	Initialization Menu	Allows you to change the High Temperature #2 Alarm set point, or disable the alarm. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. Note: To disable the feature, press YES / + / i when in the change setting mode to scroll to <i>NO HIGH TEMPERATURE #2 ALARM</i> (displayed when you scroll up to "100°C").
P	LOW TEMPERATURE #1 = ttt°C/F or NO LOW TEMPERATURE #1 ALARM	Initialization Menu	Allows you to change the Low Temperature #1 Alarm set point, or disable the alarm. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. Note: To disable the feature, press NO / - when in the change setting mode to scroll to <i>NO LOW TEMPERATURE #1 ALARM</i> (displayed when you scroll down to "-50°C").
Q	LOW TEMPERATURE #2 = ttt°C/F or NO LOW TEMPERATURE #2 ALARM	Initialization Menu	Allows you to change the Low Temperature #2 Alarm set point, or disable the alarm. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. Note: To disable the feature, press NO / - when in the change setting mode to scroll to <i>NO LOW TEMPERATURE #2 ALARM</i> (displayed when you scroll down to "-50°C").
R	AUDIBLE SILENT TIME = mm MINUTES or AUDIBLE ALARMS STAY SILENCED	Initialization Menu	Allows you to enable the MCA Audible Alarm feature and set the Audible Alarm Cutoff Reset Time Period set point, or disable the feature. 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. Note: To disable the feature, press NO / - when in the change setting mode to scroll to <i>AUDIBLE ALARMS STAY SILENCED</i> (displayed when you scroll down to "zero minutes").

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
S	PCU SEQUENCING IS DISABLED or PCU SEQUENCING DELAY = ss SECONDS	Initialization Menu	Allows you to enable the Rectifier Sequencing feature and set the Rectifier Sequencing Delay set point, or disable the feature. <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. Note: To disable the feature, press NO / - when in the change setting mode to scroll to <i>Rectifier SEQUENCING IS DISABLED</i> (displayed when you scroll down to "zero seconds").
T	TEST EQUALIZE IS DISABLED TURN OFF POWER SHARE or MANUAL TEST/EQUALIZE = hh HOURS or TEST/EQUALIZE STOP IS MANUAL	Initialization Menu	Allows you to enable the Manual Timed Test/Equalize feature and set the Timed Test/Equalize set point, or disable the feature. <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. Note: To disable the feature, press NO / - when in the change setting mode to scroll to <i>TEST/EQUALIZE STOP IS MANUAL</i> (displayed when you scroll down to "zero hours"). This indicates the manually initiated timed test/equalize feature is disabled and the system must be manually returned to the float mode if placed in the test/equalize mode. <p>When the Power Share feature is enabled, the system cannot be placed in the Test/Equalize mode.</p> Note: Test/Equalize Mode requires Power Share to be turned off. A message is displayed if Power Share is on. Turn Power Share off first then return to this menu.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
U	AUTO EQUALIZE IS DISABLED or TURN OFF POWER SHARE or AUTO EQUALIZE FOR ## x DISCHARGE	Initialization Menu	<p>Allows you to enable the Auto Test/Equalize feature and set the Auto Test/Equalize Multiplier set point, or disable the feature.</p> <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. <p>Note: To disable the feature, press NO / - when in the change setting mode to scroll to <i>AUTO EQUALIZE IS DISABLED</i> (displayed when you scroll down to "zero x discharge").</p> <p>When the Power Share feature is enabled, the system cannot be placed in the Test/Equalize mode.</p> <p>Note: Test/Equalize Mode requires Power Share to be turned off. A message is displayed if Power Share is on. Turn Power Share off first then return to this menu.</p>
V	NO TEMPERATURE COMPENSATION or TURN OFF POWER SHARE or TEMPERATURE SLOPE = 0.vvV/°C/F	Initialization Menu	<p>Allows you to enable the Battery Charge Temperature Compensation feature and set the Battery Charge Temperature Compensation Slope set point, or disable the feature.</p> <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section. <p>Note: To disable the feature, press NO / - when in the change setting mode to scroll to <i>NO TEMPERATURE COMPENSATION</i> (displayed when you scroll down to "OV / °~").</p> <p>Note: This is the voltage slope of the entire battery string, not individual cells.</p> <p>Note: The Temperature Compensation feature requires Power Share to be turned off. A message is displayed if Power Share is on. Turn Power Share off first then return to this menu to enable Temperature Compensation.</p>
W	MAXIMUM COMPENSATION = vv.vvV	Initialization Menu	<p>Allows you to change the Maximum Voltage with Temperature Compensation set point.</p> <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
X	MINIMUM COMPENSATION = vv.vvV	Initialization Menu	<p>Allows you to change the Minimum Voltage with Temperature Compensation set point.</p> <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.
Y	IT IS NOW hh:mm:ss dd-mon-yy	Initialization Menu	<p>Allows you to change the time and date.</p> <ol style="list-style-type: none"> 1. Refer to "Changing a Value or Setting" in the table at the beginning of this section.

MCA Menu Tree Line No. (Section 5886)	Message Displayed	Associated with ...	Definition
Z	READY TO START THE SYSTEM NOW?	Initialization Menu	<p>Allows you to start the system with the selected settings.</p> <ol style="list-style-type: none"> 1. Press ENTER and ALARM CUTOFF (at the same time). 2. At the "ARE YOU SURE?" prompt, press YES / + / i.

SYSTEM OPERATING PROCEDURES

LMS Operating Procedures

Refer to the LMS User Instructions (Section 5847) for LMS operating procedures.

Security Adapter Unit (SAU)

If the LMS is used with a Security Adapter Unit (SAU), refer to the SAU instruction manual (IM58214000074) for proper (LMS and SAU) network settings, SAU operation, etc.

LMS Local Port

The LMS Local Port is provided via a USB to RS-232 Port Adapter Unit. The proper device driver must be installed on the computer to be connected to the USB port. Use one of the following procedures to install the device driver.

Installing the USB Device Driver from the Furnished CD

A device driver CD is supplied with the USB to RS-232 Port Adapter Unit. The proper driver must be installed on the computer to be connected to the USB port. Use the provided CD to install the driver.

Downloading the USB Driver from the Web

1. Go to this link <http://vscom.de/downloadcenter.htm>.
2. Select “USB to Serial Drivers” from the Product Category drop-down menu.
3. Select your product model’s “Driver and Documentation” to download the files.
4. Select your computer’s operating system.
5. Run or save the application.

Setting up your Computer to Access the Power System

1. Select Hyper terminal.
2. Connect using one of the unused COM ports. (e.g. COM 5)
3. Set Bit Per Second to 19200.
4. Set Data Bits to 8.
5. Set Parity to None.
6. Set Stop bits to 1.
7. Set Flow control to Hardware.
8. Select OK.
9. In Hyper terminal press ENTER.
10. Enter the password 6.
11. Enter “?” to see commands.

Local Controls and Indicators

Location and Identification

Refer to the illustrations in the *System Overview* section.

LMS Main/Expansion CPU Circuit Card (if furnished) Controls and Indicators

Refer to the LMS User Instructions (Section 5847).

Bay LED Indicator

Located on the top front panel of each bay.

Green (steady)	Bay is 'OK'
Red (steady)	'Bay Failure' <i>Note: "Bay Failure" conditions for the Primary Power/Distribution and Power Only Bays are set via the MCA Relay Function Channel #24 configuration.</i>
Yellow (flashing)	Bay is being 'Identified' by MCA

Distribution Bus LED Indicator

Located next to each Distribution Bus (on the front of each MCA Distribution Bus Monitoring circuit card hinged panel) in each bay.

Green (steady)	Distribution Bus is 'OK'
Red (steady)	'Distribution Bus Failure'
Yellow (flashing)	Distribution Bus is being 'Identified' by MCA

MCA Component LED Indicator

Each MCA component (i.e. Distribution Bus Monitoring Circuit Card, Bay MCA/Router Circuit Card, MCA Relay Circuit Card, MCA I/O Circuit Card) contains an LED Indicator.

Green (steady)	Component is 'OK'
Red (steady)	'Component Failure'
Yellow (flashing)	Component is being 'Identified' by MCA

Bay Monitoring and Control Section Indicators

Located in each Bay's Monitoring and Control Section.

Power	Illuminates Green when DC input power is being supplied to the Bay's 'Monitor and Control Section'.
FA	Illuminates Red when any fuse on the Bay's 'Monitor and Control Section' opens (i.e. input fuses to Bay's MCA/Router circuit card, Bay's LMS Main/Expansion CPU circuit card, and Bay's Distribution Bus Monitoring circuit cards).

MCA Controls and Indicators

Control / Indicator	Description
FUNCTION SELECT UP FUNCTION SELECT DOWN (Arrow Pushbuttons)	Moves up and down, respectively, through the list of available entries in the currently displayed menu.
FUNCTION SET ENTER/←/→ (Pushbutton)	Used to move to another menu, as determined by the currently displayed entry. Also used to lock the displayed setting or value of the currently selected menu entry, when in the adjustment or change setting mode. <i>Note: Pressing the ALARM CUTOFF pushbutton and the FUNCTION SET ENTER pushbutton simultaneously, allows the User to enter the adjustment or change setting mode, to change the value or setting of the currently selected menu entry, if available.</i>
FUNCTION SET YES (+) (i) FUNCTION SET NO (-) (Pushbuttons)	Used to increase or decrease the value of the currently selected menu entry when in the adjustment or change setting mode. <i>Note: Pressing the FUNCTION SET YES (+) and NO (-) pushbuttons simultaneously moves the user to the "Initial Message" display (beginning).</i> <i>Note: When in the adjustment or change setting mode, depressing the FUNCTION SET YES (+) pushbutton after the "ARE YOU SURE?" prompt accepts the new value or setting, depressing the FUNCTION SET NO (-) pushbutton after the "ARE YOU SURE?" prompt cancels the adjustment or change setting mode without making any changes.</i> <i>Note: You can view additional information when the MCA displays the "i" symbol by pressing this key.</i>
ALARM CUTOFF (Pushbutton)	Silences the audible alarm. Any new alarms will reactivate the audible alarm. <i>Note: Pressing the ALARM CUTOFF pushbutton and the FUNCTION SET ENTER pushbutton simultaneously, allows the user to enter the adjustment or change setting mode, to change the value or setting of the currently selected menu entry, if available.</i>
ALARM CUTOFF (Indicator)	Illuminates yellow when the MCA audible alarm has been silenced using the ALARM CUTOFF Pushbutton.

<p>MAJOR (Indicator)</p>	<p>Flashes red if any condition listed below occurs.</p> <ul style="list-style-type: none"> • AC fail on two or more Rectifiers. • Rectifier fail alarm activates on two or more Rectifiers. • Battery On Discharge alarm activates. • Very Low Voltage alarm activates. • High Voltage Alarm 1 activates. • High Voltage Alarm 2 activates. • Emergency Stop or Remote HVS activated. • If any system distribution fuse or circuit breaker opens. • Any High or Low Temperature Alarm activates. • Any Router, Distribution, MCA Relay, or MCA I/O circuit card alarm activates. • Duplicate Rectifier, Router, Distribution, MCA Relay, or MCA I/O circuit card reference designation. • System component cannot be identified. • MCA Hardware/Software failure. • MCA Initializing.
<p>MINOR (Indicator)</p>	<p>Illuminates red if any condition listed below occurs.</p> <ul style="list-style-type: none"> • Rectifier fail alarm activates on any single Rectifier. • If the over-current alarm activates. • Loss of communication to the display or LMS.
<p>AC (Indicator)</p>	<p>Illuminates green if AC input voltage to <u>all</u> Rectifiers is greater than the preset non-adjustable low AC input voltage inhibit, less than the preset non-adjustable high AC input voltage inhibit, and the Standby/Operate switch on each Rectifier is in the I "operate" position. Illuminates red if AC input voltage to any Rectifier decreases below or increases above the respective inhibit value.</p> <p>Danger: In standby mode, AC input power <u>IS</u> connected to the Rectifier.</p>
<p>TEST/EQ (Indicator)</p>	<p>Illuminates yellow when the system is placed in the test/equalize mode, locally or remotely.</p>

MCA Display

Refer to the *Navigating the MCA* section for MCA Display descriptions.

Surge Suppression Alarms (available only if a Surge Suppression Option is furnished)

If a surge suppression assembly operates, the MCA displays a "Binary Input Customer Text Message" in the I/O Board Alarm Detail Message. If you wish to change the default message, refer to the "SETTING MCA CUSTOM TEXT MESSAGES" in this section.

"MCA Customer Alarm Relays" may also be programmed to provide an external alarm.

Note that a Surge Suppression Alarm is active when there is NO AC power, and resets when AC power is supplied.

Rectifier Controls and Indicators

208V and 480V Input Rectifiers

Control / Indicator	Description
Operate / Standby Switch	<p>This two positions rocker switch provides the following functions.</p> <p>I (Operate): Enables the Rectifier to provide output power.</p> <p> (Standby): Inhibits Rectifier output.</p> <p><i>Note: In standby mode, AC input power remains connected to the Rectifier.</i></p>
AC / Identify Indicator	<p>This LED operates as follows.</p> <p>Steady green indicates AC input voltage to the Rectifier is within the specified operating range and the Operate/Standby switch is in the 'Operate' position.</p> <p>Blinking green indicates the Rectifier is being 'Identified' by MCA.</p>
Protection Alarm Indicator	<p>This LED operates as follows.</p> <p>Steady YELLOW indicates:</p> <ul style="list-style-type: none"> AC input under/over voltage. Rectifier PFC output under/over voltage. High temperature. Current sharing imbalance. <p>Blinking YELLOW indicates:</p> <ul style="list-style-type: none"> Rectifier communication failure.
Fail Alarm Indicator	<p>This LED operates as follows.</p> <p>Steady RED indicates:</p> <ul style="list-style-type: none"> Output over-voltage. Output fuse blown. Rectifier ID fault. <p>Blinking red indicates:</p> <ul style="list-style-type: none"> Faulty fan.
OUTPUT CURRENT Bargraph	<p>Shows the Rectifier's output current.</p> <p>Each LED segment represents 20A. If the rectifier is in current limit (output current > 200A), the tenth LED blinks.</p>

External Alarms

MCA Customer Alarm Relay circuit cards may be installed. These alarm relays are mapped to the MCA alarms per the MCA configuration. See the table in Section 5876 (Installation Instructions) for the MCA default configuration. Another table is provided in Section 5876 (Installation Instructions) to document a custom configuration.

Starting and Stopping System Operation

Rectifier Normal Starting Procedure

Place the Rectifier Standby/Operate switch in the I "operate" position.

Rectifier Stopping Procedure (Local)

Complete Shutdown

1. Place the Rectifier Standby/Operate switch in the "standby" position.

Local TR Shutdown



NOTE! When a Rectifier is shut down via the Local TR Shutdown feature, it must be manually restarted. The Local TR Shutdown feature DOES NOT automatically restart Rectifiers to deliver current in any operational or alarm state of the DC plant. The Rectifier must be manually restarted by navigating the MCA and selecting to turn the Rectifier back ON as detailed in the following procedure.

1. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
2. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "TURN PCU ON OR OFF" is displayed. Press and release the FUNCTION SET ENTER key.
3. Repeatedly press and release the FUNCTION SELECT UP or DOWN arrow key until the Rectifier to be stopped using the local TR feature is displayed.
4. With this Rectifier being displayed, press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
5. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.
6. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.
7. Repeat this procedure to restart the Rectifier.

Rectifier Stopping Procedure (Remote) (if optional LMS installed)

Refer to the LMS User Instructions (Section 5847).

Restarting Procedures when Rectifier is Automatically or Manually Inhibited, Shut Down, or Locked Out

Rectifier High Voltage Shutdown Lockout

Place the Standby/Operate switch to the "standby" position, and then back to the "operate" position.

Rectifier Emergency Shutdown and Fire Alarm Disconnect

Remove the emergency shutdown and fire alarm disconnect signal, and on each Rectifier place the Standby/Operate switch to the "standby" position and then back to the "operate" position.

Remote On/Off (TR)

Remove the remote on/off (TR) signal from the respective Rectifier. The signal can originate from the LMS (if installed), or via the local MCA Control Panel.

Output Voltage Mode of Operation Selection

Placing the System into the Float Mode of Operation

Manually place the system into float mode by navigating to and activating the "TEST/EQ MODE ACTIVE. SET FLOAT?" menu item in the MCA function menu. A step-by-step procedure is provided next.

1. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.

or

In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.



NOTE! In the following step, if "FLOAT MODE IS ACTIVE. SET TEST/EQ?" is displayed, the system is already operating in the float mode. In this case, DO NOT perform steps 2) through 4), proceed with step 5).

2. Press and release the FUNCTION SELECT DOWN arrow key to display "TEST/EQ MODE ACTIVE. SET FLOAT?".
3. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
4. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.
5. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Placing the System into the Test/Equalize Mode of Operation



WARNING! Do not supply equalize output voltage for a longer period than necessary. Prolonged higher battery charge voltage overcharges the battery cells and reduces battery life.



NOTE! Test/Equalize Mode requires Power Share to be turned off.

There are four methods of placing the system from the float mode to the test/equalize mode.

Method 1 (Manual Test/Equalize) Procedure

In this method, a user manually places the system into the test/equalize mode via the MCA Control Panel. A user must manually return the system to the float mode via the MCA Control Panel. Follow the procedures described below.

Setting for Manual Test/Equalize: Set the "MANUAL TEST/EQUALIZE = hh HOURS" menu item in the MCA configure menu to below 0. The display changes to "TEST/EQUALIZE STOP IS MANUAL" to indicate manual test/equalize mode is set. A step-by-step procedure is provided next.

1. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
2. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "CHANGE CONFIGURATION PARAMETERS" is displayed. Press and release the FUNCTION SET ENTER key.
3. Press and release the FUNCTION SELECT DOWN arrow key to display "MANUAL TEST/EQUALIZE = hh HOURS" or "TEST/EQUALIZE STOP IS MANUAL" is displayed.



NOTE! If "TEST/EQUALIZE STOP IS MANUAL" is displayed, the system is already set for manual test/equalize. In this case, proceed with step 8).



NOTE! If "END TEST/EQUALIZE IN hhh.hh HOURS" is displayed, the system is set for manually initiated timed test/equalize, and a timed test/equalize is in progress. In this case, you can proceed with steps 4) through 7) to cancel the timed test/equalize in progress and change the current setting, or proceed with step 8) to proceed with the timed test/equalize in progress and make no changes.

4. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
5. Press the FUNCTION SET NO / - key to scroll the displayed value towards 0. Release the key when "TEST/EQUALIZE STOP IS MANUAL" is displayed. This indicates the manually initiated timed test/equalize feature is disabled and the system must be manually returned to the float mode if placed in the test/equalize mode.
6. Press and release the FUNCTION SET ENTER key.
7. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.
8. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Placing the System into Test/Equalize Mode: Manually place the system into test/equalize mode by navigating to and activating the "FLOAT MODE IS ACTIVE. SET TEST/EQ?" menu item in the MCA function menu. The system is placed in the test/equalize mode and must be manually placed back to the float mode. A step-by-step procedure is provided next.

1. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key

until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.

 **NOTE!** In the following step, if "TEST/EQ MODE ACTIVE. SET FLOAT?" is displayed, the system is already operating in the test/equalize mode. In this case, DO NOT perform steps 2) through 4), proceed with step 5).

2. Press and release the FUNCTION SELECT DOWN arrow key to display "FLOAT MODE IS ACTIVE. SET TEST/EQ?".
3. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
4. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.
5. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Returning to Float Mode: To return to float mode, navigate to and activate the "TEST/EQ MODE ACTIVE. SET FLOAT?" menu item in the MCA function menu, as previously described in this section.

Method 2 (Manually Initiated Timed Test/Equalize) Procedure

In this method, a user manually places the system into the test/equalize mode via the MCA Control Panel. The system automatically returns to the float mode after a preset programmable time period (1-99 hours, in increments of one hour). Follow the procedures described below.

1. **Setting for Manually Initiated Timed Test/Equalize:** Set the "MANUAL TEST/EQUALIZE = hh HOURS" menu item in the MCA configure menu to a value between 1 and 99. A step-by-step procedure is provided next.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "CHANGE CONFIGURATION PARAMETERS" is displayed. Press and release the FUNCTION SET ENTER key.
4. Press and release the FUNCTION SELECT DOWN arrow key to display "MANUAL TEST/EQUALIZE = hh HOURS" or "TEST/EQUALIZE STOP IS MANUAL" is displayed.

 **NOTE!** If "MANUAL TEST/EQUALIZE = hh HOURS" is displayed, the system is already set for manually initiated timed test/equalize. In this case, you can proceed with steps 4) through 7) to change the current setting, or proceed with step 8) if no changes are required.

 **NOTE!** If "END TEST/EQUALIZE IN hhh.hh HOURS" is displayed, the system is already set for manually initiated timed test/equalize, and a timed test/equalize is in progress. In this case, you can proceed with steps 4) through 7) to cancel the timed test/equalize in progress and change the current setting, or proceed with step 8) to proceed with the timed test/equalize in progress and make no changes.

5. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.

6. Press the FUNCTION SET YES (+) or FUNCTION SET NO (-) key until the desired value is displayed, then release the key. Note that as you scroll BELOW 0, "TEST/EQUALIZE STOP IS MANUAL" is displayed. Scroll back up to redisplay "MANUAL TEST/EQUALIZE =".
7. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
8. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.
9. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Placing the System into Test/Equalize Mode: Manually place the system into test/equalize mode by navigating to and activating the "FLOAT MODE ACTIVE. SET TEST/EQ?" menu item in the MCA function menu. The system is placed in the test/equalize mode for the time period set in "MANUAL TEST/EQUALIZE = hh HOURS". The system automatically returns to the float mode when this time period expires. A step-by-step procedure is provided next.

1. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.

 **NOTE!** In the following step, if "TEST/EQ MODE ACTIVE. SET FLOAT?" is displayed, the system is already operating in the test/equalize mode. In this case, DO NOT perform steps 2) through 4), proceed with step 5).

2. Press and release the FUNCTION SELECT DOWN arrow key to display "FLOAT MODE IS ACTIVE. SET TEST/EQ?".
3. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
4. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.
5. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Returning to Float Mode: The system automatically returns to float mode when the "timed test/equalize period" expires.

 **NOTE!** Navigating to "END TEST/EQUALIZE IN hhh.hh HOURS" of the MCA configure menu displays the hours remaining in the timed test/equalize period.

 **NOTE!** Timed test/equalize is canceled and the system is placed in the float mode if any of the following occurs.

- 1) Manually placing the system in the float mode by navigating to and activating "TEST/EQ MODE ACTIVE. SET FLOAT?" menu item in the MCA function menu, as previously described in this section.

- 2) Resetting the "MANUAL TEST/EQUALIZE = hh HOURS" value in the MCA configure menu when "END TEST/EQUALIZE IN hhh.hh HOURS" is being displayed, as described in the previous procedure
- 3) Applying an external test/equalize signal as described in the next procedure.

Method 3 (Automatic Test/Equalize) Procedure

In this method, a user enables the Automatic Equalize feature via the MCA Control Panel. The system is automatically placed in the equalize mode and automatically returns to float mode for the conditions as described above. Follow the procedures described below.



NOTE! *The automatic equalize feature is intended for use only with wet cell batteries. Using this feature with valve regulated batteries is not recommended.*

Description

This feature can be enabled or disabled by a user via the MCA. The default state is disabled.

The Automatic Equalize feature is a time based function which is controlled by a customer selectable multiplier and by the "System Battery is on Discharge" alarm setpoint. The MCA's default setting is for a multiplier of zero, which disables the Automatic Equalize feature.

When the Automatic Equalize feature is enabled, if system voltage drops to less than the "System Battery is on Discharge" alarm setpoint, the MCA initiates a timing cycle to measure the discharge time period. The MCA requires at least 15 minutes of continuous "System Battery is on Discharge" alarm in order to prevent nuisance equalization cycles. When system voltage rises to above the "System Battery is on Discharge" alarm setpoint, the MCA ends the discharge timing cycle and (assuming a minimum of 15 minutes has elapsed) places the Rectifiers into the equalize mode for a customer selectable multiple of the discharge time period (the discharge time period includes the initial 15 minutes).

The equalize time period can be set for 0 to 15 times the discharge time period, up to a maximum of 300 hours. A zero (0) setting disables the feature.

When the Automatic Equalize feature is enabled, the MCA prevents a user from setting the equalize value lower than the float setpoint. If the equalize value is set first, the MCA automatically sets the Automatic Equalize Multiplier to zero (0), disabling the feature.

Manually setting the system to float or equalize mode cancels the automatic function, if active.



NOTE! *Equalization is only effective if the correct multiplier is entered to allow the battery to charge to capacity. It makes no sense to end the equalize cycle before battery capacity has been restored. To determine the multiplier, load current and system capacity must be known. For example, consider a system with 200 amps of Rectifier capacity and 150 amps of load. If there is a 2-hour outage of AC power, 300 amp-hours (150 x 2) will be drained from the battery. When AC power is restored, the battery charge current will be 50 amps (200-150), and it will take at least 6 hours (300/50) to replace the battery capacity. In this scenario, the multiplier must be set greater than 3 for the Automatic Equalize feature to have any effect.*

Enabling and Disabling the Automatic Equalize Feature: To enable, set the "AUTO EQUALIZE FOR ## x DISCHARGE" menu item in the MCA Configure Menu to a value between 0 and 15. To disable, set the "AUTO EQUALIZE FOR ## x DISCHARGE" menu item in the MCA Configure Menu to 0. A step-by-step procedure is provided next.

1. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
2. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "CHANGE CONFIGURATION PARAMETERS" is displayed. Press and release the FUNCTION SET ENTER key.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "AUTO EQUALIZE FOR ## x DISCHARGE" or "AUTO EQUALIZE IS DISABLED" is displayed.

 **NOTE!** If "AUTO EQUALIZE FOR ## x DISCHARGE" is displayed, the system is already set for Automatic Equalize. In this case, you can proceed with steps 4) through 7) to change the current setting, or proceed with step 8) if no changes are required.

 **NOTE!** If "END AUTO EQUALIZE IN hhh.hh HOURS" is displayed, the system is already set for Automatic Equalize, and an Automatic Equalize is in progress. In this case, you can proceed with steps 4) through 7) to cancel the Automatic Equalize in progress and change the current setting, or proceed with step 8) to proceed with the Automatic Equalize in progress and make no changes.

4. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
5. Press the FUNCTION SET YES (+) or FUNCTION SET NO (-) key until the desired value is displayed, then release the key. Note that as you scroll below 1, "AUTO EQUALIZE IS DISABLED" is displayed. Scroll back up to redisplay "AUTO EQUALIZE FOR ##".
6. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
7. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.
8. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Placing the System into Test/Equalize Mode: The MCA automatically does this for the conditions as previously described.

Returning to Float Mode: The MCA automatically does this for the conditions as previously described.

 **NOTE!** Navigating to "END AUTO EQUALIZE IN hhh.hh HOURS" of the MCA Configure Menu displays the hours remaining in an automatic equalize period, if active.

 **NOTE!** Auto Equalize is canceled and the system is placed in the float mode if any of the following occurs.

- 1) Manually placing the system in the float mode by navigating to and activating "TEST/EQUALIZE MODE ACTIVE. SET FLOAT?" menu item in the MCA Function Menu.
- 2) Resetting the "AUTO EQUALIZE FOR ## x DISCHARGE" value in the MCA Configure Menu when "END AUTO hhh.hh HR" is being displayed, as described in the previous procedure
- 3) Applying an external test/equalize signal.

Method 4 (External Test/Equalize) Procedure

In this method, a user (or external equipment) places the system in the test/equalize mode by applying an external signal to the system. The system returns to the float mode when the external signal is removed. This method overrides the other three methods.

Placing the System into Test/Equalize Mode: Apply an external test/equalize loop closure to the system's remote equalize terminals.

Returning to Float Mode: Remove the external test/equalize loop closure from the system's remote equalize terminals.



NOTE! *If a manual test/equalize, manually initiated timed test/equalize, or automatic equalize is in process; it is canceled and the system returns to float mode when system ground is removed from the test/equalize terminal.*

Setting MCA Audible Alarm Cutoff Reset Time Period

An audible alarm device is located on the MCA Control Panel. This alarm sounds when any alarm condition monitored by the MCA occurs. The alarm can be manually silenced (cut off) by pressing a local key. A local indicator illuminates when the audible alarm has been cut off. The alarm remains silenced for the current alarm condition only. If another alarm condition occurs, the audible alarm again sounds.

A programmable audible alarm cutoff reset feature is provided. Once an audible alarm has been cut off, it automatically resets (and sounds if the alarm condition is still present) after the time period programmed expires. If another alarm condition occurs, the audible alarm again sounds.

The MCA Audible Alarm Cutoff Reset feature is active when an "AUDIBLE SILENT TIME = mm MINUTES" value is selected.

The MCA Audible Alarm Cutoff Reset feature is inactive when "AUDIBLE ALARMS STAY SILENCED" is selected.

Procedure

1. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
2. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "CHANGE CONFIGURATION PARAMETERS" is displayed. Press and release the FUNCTION SET ENTER key.
3. "AUDIBLE SILENT TIME = mm MINUTES" or "AUDIBLE ALARMS STAY SILENCED" is displayed.
4. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
5. Observe the value displayed. Press and hold the FUNCTION SET YES (+) or NO (-) key until the desired value or "AUDIBLE ALARMS STAY SILENCED" is displayed. Release the key.
6. With the desired value or "AUDIBLE ALARMS STAY SILENCED" being displayed, press and release the FUNCTION SET ENTER key.
7. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.

 **NOTE!** The audible alarm cutoff reset time period will not be changed and the adjustment mode will be exited if the FUNCTION SET YES (+) key is not pressed within 10 seconds of the “ARE YOU SURE?” prompt.

8. To return to the beginning of the MCA Logic Tree, press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously.

Setting Rectifier Sequencing Delay Time Period

The MCA can be set to provide Rectifier Sequencing. When the MCA senses an “AC POWER IS OFF TO ALL PCUs” alarm, it turns off all Rectifiers. When the “AC POWER IS OFF TO ALL PCUs” alarm clears, the MCA turns on Rectifier #1, then turns on the other Rectifiers starting with Rectifier #2 every n seconds (n is user programmable from 1 to 20 seconds). If the MCA fails or the communication link is broken during a Rectifier Sequencing routine, all Rectifiers turn on immediately.

The time delay between turning individual Rectifiers on is adjustable from 1 to 20 seconds, or you can set the feature to be disabled. Refer to the following procedure.

Procedure

1. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
2. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "CHANGE CONFIGURATION PARAMETERS" is displayed. Press and release the FUNCTION SET ENTER key.
3. Press and release the FUNCTION SELECT DOWN arrow key until "PCU SEQUENCE DELAY = ss SECONDS" or "PCU SEQUENCING IS DISABLED" is displayed.
4. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
5. Observe the value displayed. Press and hold the FUNCTION SET YES (+) or NO (-) key until the desired value or "PCU SEQUENCING IS DISABLED" is displayed. Release the key.
6. With the desired value or "PCU SEQUENCING IS DISABLED" being displayed, press and release the FUNCTION SET ENTER key.
7. “ARE YOU SURE?” is displayed. Press and release the FUNCTION SET YES (+) key.

 **NOTE!** The Rectifier sequencing feature will not be changed and the adjustment mode will be exited if the FUNCTION SET YES (+) key is not pressed within 10 seconds of the “ARE YOU SURE?” prompt.

8. To return to the beginning of the MCA Logic Tree, press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously.

Setting MCA Custom Text Messages (Names)

You can set a custom text message (name) to be displayed for the following MCA items...

MCA, Router (Bay), Rectifier, Distribution Bus, Individual Distribution Points, MCA Customer Alarm Relay Cards, Individual MCA Relays, MCA I/O Card Binary Alarms.

Whenever the MCA is displaying specific information pertaining to a specific MCA item, an *i* (information available) is also displayed on the fourth line. Pressing the **FUNCTION SET YES (+) (i)** key toggles the name of the displayed MCA item between the normal MCA naming convention and a custom test message (if set).

To enter or change a custom text message, perform the following procedure.

Procedure

1. Navigate to an MCA menu item that displays information about the particular MCA item you want to set a custom text message for. Note that the *i* is displayed on the fourth line.
2. Press the **FUNCTION SET YES (+) (i)** key to display the text message.
3. Press and release the **ALARM CUTOFF** and **FUNCTION SET ENTER** keys simultaneously.
4. An underline appears below the first character. Repeatedly, press and release the **FUNCTION SET YES (+)** or **NO (-)** keys to enter the desired character.
5. Press the **FUNCTION SET ENTER** key to lock the character and to move to the next character.
6. You can enter up to 32 characters for the custom text message in this fashion. If the custom text message contains less than 32 characters, simply repeatedly press the **FUNCTION SET ENTER** key until you exit the text change mode.

Mapping LMS LED Channels to the MCA Display and MCA Customer Alarm Relays

You can set the MCA to display a message if an LMS LED channel activates. You can then map an MCA Customer Alarm Relay to also activate.

Procedure

1. Map the LMS LED Channel to one of the MCA Relay Function Channels by adding the Monitoring LED * Message condition to the MCA Relay Function Channel definition. Refer to Setting and Testing MCA Customer Alarm Relays section of the separate INSTALLATION INSTRUCTIONS (Section 5876) for a procedure. (Note that if you add the LMS LED Channel condition to the default MCA Relay Function Channel #1, the condition will be mapped and displayed as an MCA Major Alarm condition. Note that if you add the LMS LED Channel condition to the default MCA Relay Function Channel #2, the condition will be mapped and displayed as an MCA Minor Alarm condition. Note that if you add the LMS LED Channel condition to any other MCA Relay Function Channel, the condition will be mapped and displayed as an MCA Info condition.)
2. Now you can map an MCA Customer Alarm Relay to activate when the LMS LED Channel activates by assigning the MCA Relay Function Channel defined above to a particular MCA Relay. Refer to Setting and Testing MCA Customer Alarm Relays section in the separate INSTALLATION INSTRUCTIONS (Section 5876) for a procedure.

Using the Alarm Relay Test Feature

Refer to *Setting and Testing MCA Customer Alarm Relays* section in the separate INSTALLATION INSTRUCTIONS (Section 5876).

MCA “Power Share” Feature

Description

The MCA Power Share feature allows you to connect a Spec. No. 582140000 Power System (referred to as “New Power System” in this document) to an existing DC power system (referred to as “Existing Power System” in this document) instead of extending or completely replacing the Existing Power System.

The MCA Power Share feature provides for the sharing of the total load in a controlled manner.

When Power Share is programmed, the MCA in the New Power System adjusts Rectifier output voltage per load demands to ensure proper sharing between the New and Existing Power Systems.

Operating Modes

Depending on the systems’ configurations, their Rectifier capacities, their distribution load capacities, and the Power Share configuration; four operating modes can occur.

Low Load Operation

When the total load current demand is lower than the programmed percentage value of the total capacity of the New Power System that will initially feed the load (**PS Initial Capacity Limit**), the New Power System voltage will be increased by the programmed **PS Voltage Offset** forcing the New Power System to carry the load. Make sure that the output voltage does not exceed the battery float range recommended by the manufacturer. In this operating mode, no current will be delivered by the Existing Power System.

Normal Load Operation

When the total load current demand reaches the **PS Initial Capacity Limit**, the New Power System output voltage will be decreased by the **PS Voltage Offset**, allowing the Existing Power System to deliver the remaining current up to the New Power System’s maximum capacity. Both New and Existing Power Systems are now providing current to the load.

High Load Operation

When the total load current demand exceeds the sum of the maximum capacity of the Existing Power System and the **PS Initial Capacity Limit** of the New Power System, the New Power System will deliver the remaining current up to the maximum of its capacity. The two systems will then reach their maximum capacities. This operation may occur when the batteries are being recharged, after a commercial AC failure for example.

Overload Operation

When the total load current demand is higher than the sum of the maximum capacity of the Existing Power System and the maximum capacity of the New Power System, both Existing and New Power Systems and the batteries will feed the load. The output voltage will depend on the conditions of the batteries. This operation occurs if the total capacity of the PCUs (rectifiers) is too low in relation to the need for increased current.

Requirements and Conditions

The two DC power systems must be connected in parallel as described in the *Installation Instructions* (Section 5776).

Programming the MCA Power Share Feature in the New Power System

After a New Power System has been connected to an Existing Power System and both systems set for the same float voltage, you will have to configure the Power Share parameters in the MCA of the New Power System.

 **NOTE!** The Rectifier sequencing feature will not be changed and the adjustment mode will be exited if the **FUNCTION SET YES (+)** key is not pressed within 10 seconds of the “ARE YOU SURE?” prompt.

 **NOTE!** The “Power Share” feature is not compatible with the temperature compensation feature. If temperature compensation is programmed ON, then “Turn Off Temperature Compensation” is displayed in the Power Share menu. If Power Share is programmed ON, then “Turn Off Power Share” is displayed in the temperature compensation menu.

 **NOTE!** The Rectifier current limit menu item setting is ignored when Power Share is enabled. When Power Share is enabled, the message “PCU Current Limit Power Share” is displayed in the PCU Current Limit menu.

Enabling Power Share

1. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
2. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "ADJUST THE SYSTEM VOLTS & AMPS" is displayed.
3. Press and release the FUNCTION SET ENTER key.
4. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "POWER SHARE IS OFF, TURN IT ON?" is displayed.

 **NOTE!** If “TURN OFF TEMPERATURE COMPENSATION” is displayed, the MCA is set for temperature compensation. Disable temperature compensation and then return to this procedure.

5. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.
6. Continue with the next procedure.

Setting the Power Share Initial Capacity Limit

1. From the previous procedure, press and release the FUNCTION SELECT DOWN arrow key to display "PS INITIAL CAPACITY LIMIT = ##%".
2. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
3. Press and hold the FUNCTION SET YES (+) or NO (-) key to change this setting as required. Release the key when the desired value is displayed.

 **NOTE!** Enter the percentage value of the total capacity of the New Power System that will initially feed the load. This value must be set to ensure that the current delivered by the New Power System is lower than the total load current from the existing and New Power Systems.

(Adjustable from 20% to 90%, factory set at 80%.)

4. With the desired value being displayed, press and release the FUNCTION SET ENTER key.
5. “ARE YOU SURE?” is displayed. Press and release the FUNCTION SET YES (+) key.
6. Continue with the next procedure.

Setting the Power Share Voltage Offset

1. From the previous procedure, press and release the FUNCTION SELECT DOWN arrow key to display "PS VOLTAGE OFFSET = v.vV".
2. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
3. Press and hold the FUNCTION SET YES (+) or NO (-) key to change this setting as required. Release the key when the desired value is displayed.



NOTE! Enter the value that will be added to the float voltage to ensure the New Power System will initially carry the load. This value must be higher than the sum of the voltage drop in the cables connecting the two systems in parallel and the output voltage regulation specific to the rectifiers of the Existing Power System. If the sense leads are connected to the same sensing points as the Existing Power System, the Voltage Offset should take into consideration the output voltage regulation only.

(Adjustable from 0.1V to 1.0V, factory set at 0.1V.)

4. With the desired value being displayed, press and release the FUNCTION SET ENTER key.
5. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.
6. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Verifying the Operation of the Power Share Feature

After programming the "Power Share" feature, verify its operation as follows.

1. In a Power Share application where the New Power System is taking all of the load and the rectifiers in the Existing Power System are all in the standby mode, use an external dry load bank of sufficient capacity to increase the load on the New Power System over the "PS Initial Capacity Limit".
 - a) Verify that the New Power System limits the total output of its (PCUs) rectifiers to the current equivalent to this programmed percentage.
 - b) Verify that the New Power System lowers its output voltage by the value of the programmed "PS Voltage Offset".
 - c) Verify that the rectifiers in the Existing Power System take the additional load as the load increases pass the "PS Initial Capacity Limit".
 - d) Further increase the load in order to exceed the total capacity of the rectifiers in the Existing Power System (or shut down some of the rectifiers in the Existing Power System if the capacity of the external dry load bank is not sufficient). Verify that the New Power System starts taking the additional load as soon as the total capacity of the rectifiers in the Existing Power System is exceeded.
2. In a Power Share application where the New Power System is taking only part of the load (operating continuously at the current level equivalent to the programmed "PS Initial Capacity Limit" percentage) and the rectifiers in the Existing Power System are taking the rest of the load, use an external dry load bank of sufficient capacity to increase the load in order to exceed the total capacity of the rectifiers in the Existing Power System (or shut down some of the rectifiers in the Existing Power System if the capacity of the external dry load bank is not sufficient).

- e) Verify that the New Power System starts taking the additional load as soon as the total capacity of the rectifiers in the Existing Power System is exceeded.

MCA “Alternate Current Limit” Feature

Description

The MCA Alternate Current Limit feature provides the means to automatically change the current limit operation of power system’s rectifiers (PCUs) when an external event/condition occurs.

Operating Modes

Normal Current Limit Operation

When the signal connected to the “Alternate Current Limit Input” is inactive, the system’s PCUs current limiting feature operates at the value based on the “PCU Current Limit” parameter setting.

Alternate Current Limit Operation

When the signal connected to the “Alternate Current Limit Input” is active, the system’s PCUs current limiting feature operates at the value based on the “Alternate Current Limit Capacity” parameter setting.

Requirements and Conditions

The system must have an MCA I/O circuit card installed.

Binary input #4 must be connected to a signal that will indicate to the MCA to place the rectifiers into the “Alternate Current Limit” mode.

Programming the MCA Alternate Current Limit Feature

When the Alternate Current Limit is first enabled, the “Alternate Current Limit Capacity” parameter defaults to a value of 100% of available capacity.



NOTE! The “Alternate Current Limit” feature is not compatible with the Power Share feature. If Power Share is programmed ON, then “Turn Off Power Share” is displayed in the Alternate Current Limit menu.



NOTE! The PCU current limit menu item setting is ignored when Alternate Current Limit is enabled AND the Alternate Current Limit Input is active. When this occurs, the message “ALT. LIMIT” is displayed in the PCU Current Limit menu.

Enabling Alternate Current Limit

1. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
2. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "ADJUST THE SYSTEM VOLTS & AMPS" is displayed.
3. Press and release the FUNCTION SET ENTER key.
4. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "ALT. LIMIT IS OFF, TURN IT ON?" is displayed.
5. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.

6. Continue with the next procedure.

Setting the Alternate Current Limit Initial Capacity Limit

1. From the previous procedure, press and release the FUNCTION SELECT DOWN arrow key to display "ALTERNATE CURRENT LIMIT = ###".
2. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
3. Press and hold the FUNCTION SET YES (+) or NO (-) key to change this setting as required. Release the key when the desired value is displayed.



NOTE! Enter the percentage value of the total PCU output capacity at which the system will current limit when the "Alternate Current Limit Input" becomes active.

(Adjustable from 10% to 110%, factory set at 100%.)

4. With the desired value being displayed, press and release the FUNCTION SET ENTER key.
5. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.
6. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Power System Remote Temperature Compensation Feature

Refer to the LMS Installation Manual (Section 5879) for programming information.

Description

The LMS can provide a remote temperature compensation signal to the power system.

This feature utilizes temperature measurement reported by the LMS via function channel F58.

Remote Temperature compensation overrides local power system (temperature sensor) temperature compensation.

Remote Temperature displayed in MCA measurement menu only when reported by the LMS.

Remote Temperature compensation is disabled if the LMS stops issuing temperature measurement updates for more than 60 seconds. This includes loss of communication.

Allow local and remote power system adjustment of Temperature Compensation Slope setpoint and temperature units conversion when receiving remote temperature measurement from LMS.



NOTE! There is a restriction on the temperature measurement reported by the LMS. The temperature must be in Degree C only. This is the default units setting for LMS Function Channel F58.

MCA SYSTEM ADJUSTMENTS

Adjustment Location and Identification

All system alarm and control circuits intended for customer adjustment are accessible via the MCA Control Panel. Unless otherwise stated, these circuits have been factory set to the values listed in the System Application Guide. If readjustment is necessary, perform the appropriate adjustment procedure detailed below.

These adjustments can also be done remotely via the LMS (if furnished). To adjust the system via the optional LMS system, refer to the LMS User Instructions (Section 5847).

Refer to the illustrations in the *System Overview* section for local adjustment controls locations.

Adjusting Float Output Voltage

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "ADJUST THE SYSTEM VOLTS & AMPS" is displayed.
4. Press and release the FUNCTION SET ENTER key. "FLOAT SETPOINT = vv.vvV" is displayed.
5. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
6. Observe the value displayed. This is the float voltage setting for all Rectifiers. If the system is used with a battery charge digital temperature compensation probe, this value is the float voltage setting at 25°C. To change this value, press and hold the FUNCTION SET YES (+) or NO (-) key. Release the key when the desired value is displayed.

 **NOTE!** The float voltage value is prevented from being adjusted higher than 1V below the high voltage shutdown setting. When used with a Battery Charge Digital Temperature Compensation Probe, float voltage is prevented from being adjusted higher than the Maximum Voltage with Temperature Compensation setting, or lower than the Minimum Voltage with Temperature Compensation setting.

7. With the desired float voltage value being displayed, press and release the FUNCTION SET ENTER key.
8. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.

 **NOTE!** The Rectifiers will assume the new value at their prevailing load current.

 **NOTE!** The float voltage will not be changed and the adjustment mode will be exited if the FUNCTION SET YES (+) key is not pressed within 10 seconds of the "ARE YOU SURE?" prompt.

9. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Adjusting Test/Equalize Output Voltage

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "ADJUST THE SYSTEM VOLTS & AMPS" is displayed.
4. Press and release the FUNCTION SET ENTER key.
5. Press and release the FUNCTION SELECT DOWN arrow key to display "TEST/EQUALIZE = vv.vvV".
6. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
7. Observe the value displayed. This is the test/equalize voltage setting for all Rectifiers. To change this value, press and hold the FUNCTION SET YES (+) or NO (-) key. Release the key when the desired value is displayed.



NOTE! The test/equalize voltage value is prevented from being adjusted higher than 1V below the high voltage shutdown setting. When used with a Battery Charge Digital Temperature Compensation Probe, test/equalize voltage is prevented from being adjusted higher than the Maximum Voltage with Temperature Compensation setting, or lower than the Minimum Voltage with Temperature Compensation setting.

8. With the desired test/equalize voltage value being displayed, press and release the FUNCTION SET ENTER key.
9. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.



NOTE! The Rectifiers will assume the new value at their prevailing load current.



NOTE! The test/equalize voltage will not be changed and the adjustment mode will be exited if the FUNCTION SET YES (+) key is not pressed within 10 seconds of the "ARE YOU SURE?" prompt.

10. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Adjusting High Voltage Shutdown

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "ADJUST THE SYSTEM VOLTS & AMPS" is displayed.
4. Press and release the FUNCTION SET ENTER key.
5. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "HI VOLTAGE SHUTDOWN = vv.vvV" is displayed.
6. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
7. Observe the value displayed. This is the high voltage shutdown setting for all Rectifiers. To change this value, press and hold the FUNCTION SET YES (+) or NO (-) key. Release the key when the desired value is displayed.

 **NOTE!** The system will not allow a value higher than 59.5 to be entered. Also, the high voltage shutdown value is prevented from being adjusted lower than 1V above the higher of the float or test/equalize setting. When used with a Battery Charge Digital Temperature Compensation Probe, high voltage shutdown is prevented from being adjusted lower than 1V above the Maximum Voltage with Temperature Compensation setting.

8. With the desired high voltage shutdown value being displayed, press and release the FUNCTION SET ENTER key.
9. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.

 **NOTE!** The high voltage shutdown value will not be changed and the adjustment mode will be exited if the FUNCTION SET YES (+) key is not pressed within 10 seconds of the "ARE YOU SURE?" prompt.

10. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Adjusting Rectifier Current Limit

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "ADJUST THE SYSTEM VOLTS & AMPS" is displayed.
4. Press and release the FUNCTION SET ENTER key.
5. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "PCU CURRENT LIMIT = aaaaaA" or "PCU CURRENT LIMIT = aaaaaMAX" is displayed.
6. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
7. Observe the value displayed. This is the system current limit setting. Each Rectifier's current limit circuit will be automatically adjusted to ensure that system current does not exceed this value. To change this value, press and hold the FUNCTION SET YES (+) or NO (-) key. Release the key when the desired value is displayed.



NOTE! PCU current limit = aaaaaMAX indicates system current limit is set to the sum of the maximum current capacities of all Rectifier Modules installed in the system.

8. With the desired current limiting value being displayed, press and release the FUNCTION SET ENTER key.
9. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.



NOTE! The system current limit value will not be changed and the adjustment mode will be exited if the FUNCTION SET YES (+) key is not pressed within 10 seconds of the "ARE YOU SURE?" prompt.

10. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Adjusting System High Voltage Alarm 1

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "ADJUST THE ALARM SETPOINTS" is displayed.
4. Press and release the FUNCTION SET ENTER key.
5. "SYSTEM HI VOLTAGE #1 = vv.vvV" is displayed.
6. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
7. Observe the value displayed. This is the high voltage alarm 1 setting. To change this value, press and hold the FUNCTION SET YES (+) or NO (-) key. Release the key when the desired value is displayed.
8. With the desired high voltage alarm 1 value being displayed, press and release the FUNCTION SET ENTER key.
9. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.



NOTE! The high voltage alarm 1 value will not be changed and the adjustment mode will be exited if the FUNCTION SET YES (+) key is not pressed within 10 seconds of the "ARE YOU SURE?" prompt.

10. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Adjusting System High Voltage Alarm 2

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "ADJUST THE ALARM SETPOINTS" is displayed.
4. Press and release the FUNCTION SET ENTER key.
5. Press and release the FUNCTION SELECT DOWN arrow key to display "SYSTEM HI VOLTAGE #2 = vv.vvV".
6. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
7. Observe the value displayed. This is the high voltage alarm 2 setting. To change this value, press and hold the FUNCTION SET YES (+) or NO (-) key. Release the key when the desired value is displayed.
8. With the desired high voltage alarm 2 value being displayed, press and release the FUNCTION SET ENTER key.
9. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.



NOTE! The high voltage alarm 2 value will not be changed and the adjustment mode will be exited if the FUNCTION SET YES (+) key is not pressed within 10 seconds of the "ARE YOU SURE?" prompt.

10. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Adjusting System Battery on Discharge Alarm

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "ADJUST THE ALARM SETPOINTS" is displayed.
4. Press and release the FUNCTION SET ENTER key.
5. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "BATTERY ON DISCHARGE = vv.vvV" is displayed.
6. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
7. Observe the value displayed. This is the battery on discharge alarm setting. To change this value, press and hold the FUNCTION SET YES (+) or NO (-) key. Release the key when the desired value is displayed.
8. With the desired battery on discharge alarm value being displayed, press and release the FUNCTION SET ENTER key.
9. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.



NOTE! The battery on discharge value will not be changed and the adjustment mode will be exited if the FUNCTION SET YES (+) key is not pressed within 10 seconds of the "ARE YOU SURE?" prompt.

10. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Adjusting System Very Low Voltage Alarm

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "ADJUST THE ALARM SETPOINTS" is displayed.
4. Press and release the FUNCTION SET ENTER key.
5. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "VERY LOW VOLTAGE = vv.vvV" is displayed.
6. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
7. Observe the value displayed. This is the very low voltage alarm setting. To change this value, press and hold the FUNCTION SET YES (+) or NO (-) key. Release the key when the desired value is displayed.
8. With the desired very low voltage alarm value being displayed, press and release the FUNCTION SET ENTER key.
9. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.



NOTE! The very low voltage alarm value will not be changed and the adjustment mode will be exited if the FUNCTION SET YES (+) key is not pressed within 10 seconds of the "ARE YOU SURE?" prompt.

10. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Adjusting Total Distribution Load Alarm

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "ADJUST THE ALARM SETPOINTS" is displayed.
4. Press and release the FUNCTION SET ENTER key.
5. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "TOTAL DISTRIBUTION = aaaaaA" is displayed.
6. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
7. Observe the value displayed. This is the system current alarm setting. To change this value, press and hold the FUNCTION SET YES (+) or NO (-) key. Release the key when the desired value is displayed.
8. With the desired system current alarm value being displayed, press and release the FUNCTION SET ENTER key.
9. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.



NOTE! *The system current alarm value will not be changed and the adjustment mode will be exited if the FUNCTION SET YES (+) key is not pressed within 10 seconds of the "ARE YOU SURE?" prompt.*

10. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Adjusting Distribution Group A Load Alarm

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "ADJUST THE ALARM SETPOINTS" is displayed.
4. Press and release the FUNCTION SET ENTER key.
5. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "DISTRIBUTION GROUP A = aaaaaA" is displayed.
6. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
7. Observe the value displayed. This is the Group A Load Current alarm setting. To change this value, press and hold the FUNCTION SET YES (+) or NO (-) key. Release the key when the desired value is displayed.
8. With the desired Group A Load Current alarm value being displayed, press and release the FUNCTION SET ENTER key.
9. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.



NOTE! The Group A Load Current alarm value will not be changed and the adjustment mode will be exited if the FUNCTION SET YES (+) key is not pressed within 10 seconds of the "ARE YOU SURE?" prompt.

10. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Adjusting Distribution Group B Load Alarm

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "ADJUST THE ALARM SETPOINTS" is displayed.
4. Press and release the FUNCTION SET ENTER key.
5. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "DISTRIBUTION GROUP B = aaaaaA" is displayed.
6. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
7. Observe the value displayed. This is the Group B Load Current alarm setting. To change this value, press and hold the FUNCTION SET YES (+) or NO (-) key. Release the key when the desired value is displayed.
8. With the desired Group B Load Current alarm value being displayed, press and release the FUNCTION SET ENTER key.
9. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.



NOTE! The Group B Load Current alarm value will not be changed and the adjustment mode will be exited if the FUNCTION SET YES (+) key is not pressed within 10 seconds of the "ARE YOU SURE?" prompt.

10. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Adjusting Battery Ambient High Temperature #1 Alarm (if Battery Charge Digital Temperature Compensation Probe is installed)

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "ADJUST THE ALARM SETPOINTS" is displayed.
4. Press and release the FUNCTION SET ENTER key.
5. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "NO HIGH TEMPERATURE #1 ALARM" or "HIGH TEMPERATURE #1 = ttt°C/F" is displayed.
6. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
7. Observe the value displayed. This is the high temperature #1 alarm setting. To change this value, press and hold the FUNCTION SET YES (+) or NO (-) key. Release the key when the desired value is displayed.
8. With the desired high temperature #1 alarm value being displayed, press and release the FUNCTION SET ENTER key.
9. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.



NOTE! The high temperature #1 alarm value will not be changed and the adjustment mode will be exited if the FUNCTION SET YES (+) key is not pressed within 10 seconds of the "ARE YOU SURE?" prompt.

10. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Adjusting Battery Ambient High Temperature #2 Alarm (if Battery Charge Digital Temperature Compensation Probe is installed)

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "ADJUST THE ALARM SETPOINTS" is displayed.
4. Press and release the FUNCTION SET ENTER key.
5. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "NO HIGH TEMPERATURE #2 ALARM" or "HIGH TEMPERATURE #2 = ttt°C/F" is displayed.
6. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
7. Observe the value displayed. This is the high temperature #2 alarm setting. To change this value, press and hold the FUNCTION SET YES (+) or NO (-) key. Release the key when the desired value is displayed.
8. With the desired high temperature #2 alarm value being displayed, press and release the FUNCTION SET ENTER key.
9. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.



NOTE! The high temperature #2 alarm value will not be changed and the adjustment mode will be exited if the FUNCTION SET YES (+) key is not pressed within 10 seconds of the "ARE YOU SURE?" prompt.

10. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Adjusting Battery Ambient Low Temperature #1 Alarm (if Battery Charge Digital Temperature Compensation Probe is installed)

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "ADJUST THE ALARM SETPOINTS" is displayed.
4. Press and release the FUNCTION SET ENTER key.
5. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "NO LOW TEMPERATURE #1 ALARM" or "LOW TEMPERATURE #1 = ttt°C/F" is displayed.
6. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
7. Observe the value displayed. This is the low temperature #1 alarm setting. To change this value, press and hold the FUNCTION SET YES (+) or NO (-) key. Release the key when the desired value is displayed.
8. With the desired low temperature #1 alarm value being displayed, press and release the FUNCTION SET ENTER key.
9. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.



NOTE! The low temperature #1 alarm value will not be changed and the adjustment mode will be exited if the FUNCTION SET YES (+) key is not pressed within 10 seconds of the "ARE YOU SURE?" prompt.

10. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Adjusting Battery Ambient Low Temperature #2 Alarm (if Battery Charge Digital Temperature Compensation Probe is installed)

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "ADJUST THE ALARM SETPOINTS" is displayed.
4. Press and release the FUNCTION SET ENTER key.
5. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "NO LOW TEMPERATURE #2 ALARM" or "LOW TEMPERATURE #2 = tt°C/F" is displayed.
6. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
7. Observe the value displayed. This is the low temperature #2 alarm setting. To change this value, press and hold the FUNCTION SET YES (+) or NO (-) key. Release the key when the desired value is displayed.
8. With the desired low temperature #2 alarm value being displayed, press and release the FUNCTION SET ENTER key.
9. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.



NOTE! The low temperature #2 alarm value will not be changed and the adjustment mode will be exited if the FUNCTION SET YES (+) key is not pressed within 10 seconds of the "ARE YOU SURE?" prompt.

10. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Configuring Battery Charge Digital Temperature Compensation Slope



NOTE! The Temperature Compensation feature requires Power Share to be turned off.

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "CHANGE CONFIGURATION PARAMETERS" is displayed.
4. Press and release the FUNCTION SET ENTER key.
5. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "NO TEMPERATURE COMPENSATION" or "TEMPERATURE SLOPE = 0.vvvV°C/F" is displayed.
6. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
7. Observe the value displayed. This is the Battery Charge Digital Temperature Compensation slope setting. To change this value, press and hold the FUNCTION SET YES (+) or NO (-) key. Release the key when the desired value is displayed.



NOTE! Refer to Battery and Equipment Manufacturers' recommendations or site requirements for the value. Note that this is the compensation for the entire battery string, not per battery cell.

8. With the desired slope value being displayed, press and release the FUNCTION SET ENTER key.
9. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.



NOTE! The slope value will not be changed and the adjustment mode will be exited if the FUNCTION SET YES (+) key is not pressed within 10 seconds of the "ARE YOU SURE?" prompt.

10. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Configuring Battery Charge Digital Temperature Compensation Maximum Voltage

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "CHANGE CONFIGURATION PARAMETERS" is displayed.
4. Press and release the FUNCTION SET ENTER key.
5. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "MAXIMUM COMPENSATION = vv.vvV" is displayed.
6. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
7. Observe the value displayed. This is the Battery Charge Digital Temperature Compensation maximum voltage setting. To change this value, press and hold the FUNCTION SET YES (+) or NO (-) key. Release the key when the desired value is displayed.



NOTE! Refer to Battery and Equipment Manufacturers' recommendations or site requirements for the value.



NOTE! Maximum Voltage with Temperature Compensation is prevented from being adjusted higher than 1.0V below the High Voltage Shutdown setting, or lower than the float voltage setting.

8. With the desired maximum voltage with temperature compensation value being displayed, press and release the FUNCTION SET ENTER key.
9. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.



NOTE! The maximum voltage with temperature compensation value will not be changed and the adjustment mode will be exited if the FUNCTION SET YES (+) key is not pressed within 10 seconds of the "ARE YOU SURE?" prompt.

10. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Configuring Battery Charge Digital Temperature Compensation Minimum Voltage

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "CHANGE CONFIGURATION PARAMETERS" is displayed.
4. Press and release the FUNCTION SET ENTER key.
5. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "MINIMUM COMPENSATION = vv.vvV" is displayed.
6. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
7. Observe the value displayed. This is the Battery Charge Digital Temperature Compensation minimum voltage setting. To change this value, press and hold the FUNCTION SET YES (+) or NO (-) key. Release the key when the desired value is displayed.



NOTE! Refer to Battery and Equipment Manufacturers' recommendations or site requirements for the value.

8. With the desired minimum voltage with temperature compensation value being displayed, press and release the FUNCTION SET ENTER key.
9. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.



NOTE! The minimum voltage with temperature compensation value will not be changed and the adjustment mode will be exited if the FUNCTION SET YES (+) key is not pressed within 10 seconds of the "ARE YOU SURE?" prompt.

10. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Configuring Degree Units Displayed (°F or °C)

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "CHANGE CONFIGURATION PARAMETERS" is displayed.
4. Press and release the FUNCTION SET ENTER key.
5. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "NOW DISPLAYING °(C or F) SET TO °(F or C)" is displayed.
6. To toggle the degree units being displayed, press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
7. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.



NOTE! The minimum voltage with temperature compensation value will not be changed and the adjustment mode will be exited if the FUNCTION SET YES (+) key is not pressed within 10 seconds of the "ARE YOU SURE?" prompt.

8. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Configuring the System Date and Time

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "CHANGE CONFIGURATION PARAMETERS" is displayed.
4. Press and release the FUNCTION SET ENTER key.
5. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "IT IS NOW hh:mm:ss dd-mon-yy" is displayed.
6. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously. The day of the month is underlined.
7. Press FUNCTION SET YES (+) and NO (-) keys to change the day of month.
8. Press FUNCTION SET ENTER key. Month is underlined.
9. Press FUNCTION SET YES (+) and NO (-) keys to change the month.
10. Press FUNCTION SET ENTER key. Year is underlined.
11. Press FUNCTION SET YES (+) and NO (-) keys to change the year.
12. Press FUNCTION SET ENTER key. Hour is underlined.
13. Press FUNCTION SET YES (+) and NO (-) keys to change the hour.
14. Press FUNCTION SET ENTER key. Minutes is underlined.
15. Press FUNCTION SET YES (+) and NO (-) keys to change the minutes.
16. Press FUNCTION SET ENTER key.

Configuring MCA I/O Circuit Card Analog Input(s)

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "CHANGE CONFIGURATION PARAMETERS" is displayed.
4. Press and release the FUNCTION SET ENTER key.
5. CHANGE I/O BOARD PARAMETERS is displayed. Press and release the FUNCTION SET ENTER key.
6. ANALOG INPUT B#-P# IS DISTRIBUTION or ANALOG INPUT B#-P# IS AUXILIARY is displayed (B#-P# = Bay Number – MCA I/O Circuit Card Position Number).

This setting determines if the monitored input appears in the MCA DISTRIBUTION MEASUREMENT menus or in separate MCA AUXILIARY MEASUREMENT menus.

To toggle the setting, press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.

"ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.

To select another analog input (if available), press the FUNCTION SELECT DOWN arrow key.

7. When the last MCA I/O circuit card with an analog input is selected, press the FUNCTION SELECT DOWN arrow key to display ANALOG INPUT B#-P# 50mV = aaaaA (B#-P# = Bay Number – MCA I/O Circuit Card Position Number).

This sets the scale factor for the analog input.

Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.

Observe the value displayed. To change this value, press and hold the FUNCTION SET YES (+) or NO (-) key. Release the key when the desired value is displayed.

With the desired value being displayed, press and release the FUNCTION SET ENTER key.

"ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.

To select another analog input (if available), press the FUNCTION SELECT DOWN arrow key.

8. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Configuring MCA I/O Circuit Card Analog Output(s)

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "CHANGE CONFIGURATION PARAMETERS" is displayed.
4. Press and release the FUNCTION SET ENTER key.
5. CHANGE I/O BOARD PARAMETERS is displayed. Press and release the FUNCTION SET ENTER key.
6. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until ANALOG OUTPUT B#-P# 50mV = aaaaA (B#-P# = Bay Number – MCA I/O Circuit Card Position Number).

This sets the scale factor for the analog output.

Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.

Observe the value displayed. To change this value, press and hold the FUNCTION SET YES (+) or NO (-) key. Release the key when the desired value is displayed.

With the desired value being displayed, press and release the FUNCTION SET ENTER key.

"ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.

To select another analog output (if available), press the FUNCTION SELECT DOWN arrow key.

7. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Configuring MCA I/O Circuit Card Binary Input(s)

1. All controls are located on the MCA Interface Pad.
2. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
3. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "CHANGE CONFIGURATION PARAMETERS" is displayed.
4. Press and release the FUNCTION SET ENTER key.
5. CHANGE I/O BOARD PARAMETERS is displayed. Press and release the FUNCTION SET ENTER key.
6. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until BINARY INPUT B#-P#-I# IS ALARM = CLOSED or BINARY INPUT B#-P#-I# IS ALARM = OPEN is displayed (B#-P#-I# = Bay Number – MCA I/O Circuit Card Position Number – Binary Input Number).

This setting determines the alarm state of the monitored binary input.

To toggle the setting press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.

"ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.

To select another binary input located on the card, press the FUNCTION SELECT DOWN arrow key. When the last binary input is selected, pressing the FUNCTION SELECT DOWN arrow key displays the next MCA I/O circuit card with binary inputs (if available).

7. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.



NOTE! If a binary input alarms, the MCA displays a "Binary Input Customer Text Message" in the I/O Board Alarm Detail Message. If you wish to change the default message, refer to the 'System Operating Procedures' section for an adjustment procedure.

MCA Audible Alarm Cutoff Reset Time Period

Refer to *System Operating Procedures* section for an adjustment procedure.

MCA Rectifier Sequencing Feature

Refer to *System Operating Procedures* section for an adjustment procedure.

Manually Initiated Timed Test/Equalize Feature

Refer to *System Operating Procedures* section for an adjustment procedure.

Automatic Test/Equalize Feature

Refer to *System Operating Procedures* section for an adjustment procedure.

MCA Power Share Feature

Refer to *System Operating Procedures* section for an adjustment procedure.

Alarm Relay Test Feature

Refer to *Setting and Testing MCA Customer Alarm Relays* section in the separate INSTALLATION INSTRUCTIONS (Section 5876).

MCA “Alternate Current Limit” Feature

Refer to *System Operating Procedures* section for an adjustment procedure.

SYSTEM MAINTENANCE

General Safety



DANGER! SERVICE PERSONNEL MUST FOLLOW APPROVED SAFETY PROCEDURES.

Performing the following procedures may expose service personnel to hazards. These procedures should be performed by qualified service personnel familiar with the hazards associated with this type of equipment. These hazards may include shock, energy, and/or burns. To avoid these hazards:

- a) The tasks should be performed in the order indicated.*
- b) Remove watches, rings, and other jewelry.*
- c) Prior to contacting any uninsulated surface or termination, use a voltmeter to verify that no voltage or the expected voltage is present.*
- d) Wear eye protection, and use recommended tools.*
- e) Use insulated tools.*

(To avoid danger to the installer or damage to the equipment, the tools used in this procedure should have insulated grips. All exposed metal shafts, extensions, handles, etc. should be completely insulated with a minimum of three half-lapped layers of electrical tape. Ensure that wrenches with more than one working end have only one end exposed.)

Voltages

AC Input Voltages



DANGER! This system operates from AC voltage capable of producing fatal electrical shock.

DC Input/Output Voltages



DANGER! This system produces DC Power and requires battery to be connected to it. Although the DC voltage is not hazardously high, the rectifier modules and/or battery can deliver large amounts of current. Exercise extreme caution not to inadvertently contact or have any tool inadvertently contact a battery terminal or exposed wire connected to a battery terminal. NEVER allow a metal object, such as a tool, to contact more than one termination at a time, or to simultaneously contact a termination and a grounded object. Even a momentary short circuit can cause explosion and injury.

LMS Maintenance Procedures

Refer to the LMS User Instructions (Section 5847) for LMS maintenance procedures.

System Maintenance Procedures

The maintenance procedures listed in Table 1 should be performed and recorded at the recommended interval to ensure continual system operation.

The procedures listed in Table 2 may be performed and recorded at the recommended interval to track system operation. Table 2 procedures ARE NOT necessary for continual system operation. They are recommended only to provide a service record for the system.

The tables reference specific sections in these User Instructions (Section 5877) or the separate Installation Instructions (Section 5876) that help in performing these procedures.

Table 1: Maintenance Procedures to be Performed at 6-Month Intervals

PROCEDURE	REFERENCED IN
Check Ventilation Openings for Obstructions such as Dust, Papers, Manuals, etc.	--
Inspect and Tighten All Installer's Connections	Section 5876, <i>Making Electrical Connections.</i>

Table 2: Procedures that MAY be Performed at 12-Month Intervals to Track System Operation (cont'd on next page)

PROCEDURE	REFERENCED IN	VALUE
Measure and Record System Float (Output) Voltage and Compare MCA Display Voltage with Reference Meter	Section 5877, <i>Navigating the MCA</i> , (Line #133) to Place in Float Mode, if required. Record System Output Voltage as Shown on the MCA Display. Record also Reference Meter Voltage Connected to System Output Busbars.	
Measure and Record System Test/Equalize (Output) Voltage and Compare MCA Display Voltage with Reference Meter	Section 5877, <i>Navigating the MCA</i> , (Line #133) to Place in Test/Equalize Mode. Record System Output Voltage as Shown on the MCA Display. Record also Reference Meter Voltage Connected to System Output Busbars. Section 5877, <i>Navigating the MCA</i> , (Line #133) to Return to Float Mode.	
Measure and Record Total System Output Current	Record System Output Current as Shown on the MCA Display.	
Measure and Record Total Rectifier Output Current	Section 5877, <i>Navigating the MCA</i> , (Line #125).	

Table 2: Procedures that MAY be Performed at 12-Month Intervals to Track System Operation (cont'd from previous page, cont'd on next page)

PROCEDURE	REFERENCED IN	Rectifier	VALUE
Measure and Record Output Current of Each Individual Rectifier	Section 5877, <i>Navigating the MCA</i> , (Line #126).	Bay # (), Rectifier 1	
		Bay # (), Rectifier 2	
		Bay # (), Rectifier 3	
		Bay # (), Rectifier 4	
		Bay # (), Rectifier 5	
		Bay # (), Rectifier 6	
		Bay # (), Rectifier 7	
		Bay # (), Rectifier 8	
		Bay # (), Rectifier 9	
		Bay # (), Rectifier 10	
Record Rectifier High Voltage Shutdown Value	Section 5877, <i>Navigating the MCA</i> , (Line #219).	--	
Record Rectifier Current Limit Value	Section 5877, <i>Navigating the MCA</i> , (Line #221).	--	

Table 2: Procedures that MAY be Performed at 12-Month Intervals to Track System Operation (cont'd from previous page, cont'd on next page)

PROCEDURE	REFERENCED IN	VALUE
Record System High Voltage 1 Alarm Value or Record and Check System High Voltage 1 Alarm Value	Section 5877, <i>Navigating the MCA</i> , (Line #226). or Section 5876, <i>Installing the Rectifiers and Initially Starting the Power System</i> .	
Record System High Voltage 2 Alarm Value or Record and Check System High Voltage 2 Alarm Value	Section 5877, <i>Navigating the MCA</i> , (Line #227). or Section 5876, <i>Installing the Rectifiers and Initially Starting the Power System</i> .	
Record System Battery On Discharge Alarm Value or Record and Check System Battery On Discharge Alarm Value	Section 5877 <i>Navigating the MCA</i> , (Line #228). or Section 5876, <i>Installing the Rectifiers and Initially Starting the Power System</i> .	
Record System Very Low Voltage Alarm Value or Record and Check System Very Low Voltage Alarm Value	Section 5877 <i>Navigating the MCA</i> , (Line #229). or Section 5876, <i>Installing the Rectifiers and Initially Starting the Power System</i> .	

Table 2: Procedures that MAY be Performed at 12-Month Intervals to Track System Operation (cont'd from previous page, cont'd on next page)

PROCEDURE	REFERENCED IN	VALUE
Record System Total Distribution Load Current Alarm Value or Record and Check Total Distribution Load Current Alarm Value	Section 5877 <i>Navigating the MCA,</i> (Line #230). or Section 5876, <i>Installing the Rectifiers and Initially Starting the Power System.</i>	
Record Distribution Group A Load Current Alarm Value or Record and Check Distribution Group A Load Current Alarm Value	Section 5877 <i>Navigating the MCA,</i> (Line #231). or Section 5876, <i>Installing the Rectifiers and Initially Starting the Power System.</i>	
Record Distribution Group B Load Current Alarm Value or Record and Check Distribution Group B Load Current Alarm Value	Section 5877 <i>Navigating the MCA,</i> (Line #232). or Section 5876, <i>Installing the Rectifiers and Initially Starting the Power System.</i>	

Adding a Rectifier

To increase system current capacity, an additional Rectifier can easily be installed in an existing bay that contains an empty Rectifier mounting position. Follow the procedure detailed below. A Rectifier may be installed in a live system.

The Rectifier weighs approximately 40 lbs.

Rectifiers can be inserted or removed with power applied (hot swappable).

Procedure

1. Remove the blank panel from the Rectifier mounting position. Save this panel. The panel must be re-installed if a Rectifier is removed.
2. Ensure that the Standby/Operate switch on the Rectifier to be installed is in the "standby" position.

 **NOTE!** In the next step, a safety latch is present on the left-hand (as viewed from the front) side panel of each Rectifier. The latch is designed to prevent the Rectifier from inadvertently being removed completely from the Bay once it has been installed. It should not be necessary to depress the safety latch release when installing the Rectifier.

3. Install the Rectifier into the bay by sliding it evenly into its mounting position. Secure the Rectifier to the bay by tightening the captive fasteners on the Rectifier.
4. Place the Standby/Operate switch on the Rectifier installed to the I "operate" position.
5. The MCA automatically adds the capacity of the new Rectifier to the current limit and displays the new current limit setting.
6. If the current limit setting is correct, go to step 10). If the current limit setting is not correct, press and release the ALARM CUTOFF and FUNCTION SET ENTER pushbuttons simultaneously.
7. Observe the value displayed. This is the system current limit setting. Reset this value to the new current limit setting. Each Rectifier's current limit circuit will be automatically adjusted to ensure that system current does not exceed this value. To change this value, press and hold the FUNCTION SET YES (+) or NO (-) pushbutton. Release the pushbutton when the desired value is displayed.
8. With the desired current limiting value being displayed, press and release the FUNCTION SET ENTER pushbutton.
9. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) pushbutton.

 **NOTE!** The system current limit value will not be changed and the adjustment mode will be exited if the FUNCTION SET YES (+) pushbutton is not pressed within 10 seconds of the "ARE YOU SURE?" prompt.

10. Press and release the FUNCTION SET YES (+) and NO (-) pushbuttons simultaneously, to return to the beginning of the MCA menu tree.
11. Ensure that there are no local or remote alarms activated on the system.

SYSTEM TROUBLESHOOTING AND REPAIR

Contact Information

Support contact information is provided on the inside of the back cover of this document.

General Safety



DANGER! *SERVICE PERSONNEL MUST FOLLOW APPROVED SAFETY PROCEDURES.*

Performing the following procedures may expose service personnel to hazards. These procedures should be performed by qualified service personnel familiar with the hazards associated with this type of equipment. These hazards may include shock, energy, and/or burns. To avoid these hazards:

- a) The tasks should be performed in the order indicated.*
- b) Remove watches, rings, and other jewelry.*
- c) Prior to contacting any uninsulated surface or termination, use a voltmeter to verify that no voltage or the expected voltage is present.*
- d) Wear eye protection, and use recommended tools.*
- e) Use insulated tools.*

(To avoid danger to the installer or damage to the equipment, the tools used in this procedure should have insulated grips. All exposed metal shafts, extensions, handles, etc. should be completely insulated with a minimum of three half-lapped layers of electrical tape. Ensure that wrenches with more than one working end have only one end exposed.)

Voltages

AC Input Voltages



DANGER! This system operates from AC voltage capable of producing fatal electrical shock.

DC Input/Output Voltages



DANGER! This system produces DC Power and requires battery to be connected to it. Although the DC voltage is not hazardously high, the rectifier Modules and/or battery can deliver large amounts of current. Exercise extreme caution not to inadvertently contact or have any tool inadvertently contact a battery terminal or exposed wire connected to a battery terminal. NEVER allow a metal object, such as a tool, to contact more than one termination at a time, or to simultaneously contact a termination and a grounded object. Even a momentary short circuit can cause explosion and injury.



CAUTION! Performing the following procedures may interrupt power to the loads, if battery reserve is not sufficient.

Circuit Card Handling



WARNING! Installation or removal of the circuit cards requires careful handling. Before handling any circuit card, read and follow the instructions contained on the Static Warning Page located at the beginning of this manual. DC input power should always be removed from a circuit card before inserting or removing a circuit card. To avoid possibility of circuit card damage from static discharge, a static wrist strap grounded through a one megohm resistor should always be worn when handling the circuit cards.

LMS Troubleshooting Procedures

Refer to the LMS User Instructions (Section 5847) for LMS troubleshooting procedures.

Troubleshooting Information

General

This system is designed for ease in troubleshooting and repair. The various indicators, as described in the *System Operating Procedures* section, are designed to isolate a failure to a specific element. Once the faulty element has been identified, refer to the next sections, "Replacement Information" and "Replacement Procedures".

The procedures listed in the *System Maintenance* section, can also be used by servicing personnel in identification and/or prevention of trouble symptoms in the system.

Adjustments

If the suspected cause of a trouble symptom is an out of adjustment condition, that particular adjustment setting should be checked or reset using the appropriate adjustment procedure detailed in the *MCA System Adjustments* section. If a failed Rectifier or circuit card is suspected, the adjustment procedures can also be used to verify the setpoints as well as the operation of the Rectifier or circuit card.

MCA Messages

An MCA Menu Tree (Section 5886) is provided with the system documentation. Each line in the MCA Menu Tree contains a number. This number is referenced in a chart provided in the *Navigating the MCA* section. This chart provides a description of each line listed on the MCA Menu Tree.

If the MCA displays an alarm message, find the line in the MCA Menu Tree showing this message. For an explanation of this alarm, locate the corresponding MCA Menu Tree Line Number in the chart provided in the *Navigating the MCA* section.

 **NOTE!** *If the MCA is replaced with an MCA previously used in another power system, the MCA may reflect inventory items not in the current power system and may display alarms. In this case, update the inventory as detailed in this section. Also, if you remove an inventory item (a component) from the power system, you must update the inventory to clear alarms.*

 **NOTE!** *If you remove a Battery Charge Digital Temperature Compensation Probe, alarms are displayed. Manually set the Battery Charge Digital Temperature Compensation feature to off as described in the "MCA System Adjustments" section to clear the alarms.*

Rectifier Current Sharing Unbalance

When multiple rectifiers are operating in parallel and the current sharing unbalance among them is greater than 3%, check if the communications cables are correctly connected.

If the current sharing unbalance still persists, following the verification suggested above, then replace the rectifier which has had its current sharing function disabled.

Rectifier Module Fault Symptoms and Troubleshooting

The fault indicators that can be displayed by the rectifier are as follows: Power indicator (green) off, Protection indicator (yellow) on, Protection indicator (yellow) flashing, Alarm indicator (red) on, and Alarm indicator (red) flashing. Refer to Table 6-1 for a list of possible causes and corrective actions.

Table 3: Rectifier Module Troubleshooting

Symptom	Possible Cause(s)	Suggested Action(s)
Power Indicator (Green) Off	No input voltage.	Make sure there is input voltage.
	Input polarity reversed.	Reconnect the input power correctly.
	Input fuse blown.	Replace the rectifier.
Protection Indicator (Yellow) On	AC input voltage outside the normal range.	Ensure that the AC input voltage is within the acceptable range.
	PFC over-voltage.	Replace the rectifier.
	Current sharing function is disabled.	Replace the rectifier.
	Rectifier not inserted into the slot completely.	Insert the rectifier again properly.
	Rectifier over-temperature protection, which could be caused by:	
	1. Fan blocked.	1. Remove any object that may be blocking the fan.
	2. Ventilation blocked (inlet or outlet).	2. Remove any object that may be blocking the inlet or outlet.
3. Ambient temperature too high or rectifier inlet too close to a heat source.	3. Lower the ambient temperature, relocate the heat source.	
Protection Indicator (Yellow) Flashing	Rectifier communication failure.	Check the communication cables.
Alarm Indicator (Red) On	Rectifier over-voltage.	Remove the rectifier from the DC power system, restart the rectifier, and replace the rectifier if the over-voltage condition still persists.
Alarm Indicator (Red) Flashing	Fan not operating.	Replace the rectifier.

Updating the Inventory after Changes to the System Have Been Made

When an inventory item is removed from the system, an alarm will be reported until the following procedure is performed.

Example, if a Rectifier is removed from the system, the Rectifier will not be removed from the MCA's inventory until "VIEW THE SYSTEM INVENTORY" is entered and the "UPDATE THE INVENTORY" operation is completed.

Procedure

1. With SYSTEM OK being displayed on the MCA Interface Pad, press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
or
In the MAIN ALARM MENU, repeatedly press and release the FUNCTION SELECT DOWN arrow key until "GO TO FUNCTION MENU" is displayed. Press and release the FUNCTION SET ENTER key. The FUNCTION MENU is displayed.
2. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "VIEW THE SYSTEM INVENTORY" is displayed.
3. Press and release the FUNCTION SET ENTER key.
4. Repeatedly press and release the FUNCTION SELECT DOWN arrow key until "UPDATE THE INVENTORY" is displayed.
5. Press and release the ALARM CUTOFF and FUNCTION SET ENTER keys simultaneously.
6. "ARE YOU SURE?" is displayed. Press and release the FUNCTION SET YES (+) key.
7. Press and release the FUNCTION SET YES (+) and NO (-) keys simultaneously, to return to the beginning of the MCA menu tree.

Replacement Information

Replacement Assemblies

When a trouble symptom is localized to a faulty Rectifier or circuit card, that particular Rectifier or circuit card should be replaced in its entirety. No attempt should be made to troubleshoot or repair individual components on any Rectifier or circuit card.

Refer to SAG582140000 (System Application Guide) for replacement part numbers.

Replacement Cables

Refer to SAG582140000 (System Application Guide) for replacement part numbers.

Replacement Procedures

Rectifier Replacement



DANGER! Observe the instructions on top of the Rectifier as you remove it.



NOTE! If a Rectifier is removed without being replaced, perform the *UPDATE INVENTORY* procedure to clear alarms.

The Rectifier weighs approximately 40 lbs.

Rectifiers can be inserted or removed with power applied (hot swappable).

Procedure

1. Observe the admonishments presented at the beginning of this section, and those encountered in this procedure.
2. Performing this procedure may activate external alarms. Do one of the following. If possible, disable these alarms. If these alarms cannot be easily disabled, notify the appropriate personnel to disregard any future alarms associated with this system.
3. On the Rectifier to be removed, place the Standby/Operate switch to the "standby" position.





NOTE! In the next step, a safety latch is present on the left-hand (as viewed from the front) side panel of each Rectifier. The latch is designed to prevent the Rectifier from inadvertently being removed completely from the Bay once it has been installed. It should not be necessary to depress the safety latch release when installing the Rectifier.

4. Loosen the captive fasteners on the front of the Rectifier to be removed. Use the handle provided on the front of the Rectifier, and pull the Rectifier out until it is stopped by a safety latch located on the left-hand side panel of the Rectifier. Refer to **Figure 1** for latch and release location. Depress and hold the latch release, and remove the Rectifier from the shelf. Support the bottom of the Rectifier as you pull it out. **Observe the instructions on top of the Rectifier as you remove it.**
5. Ensure that the Standby/Operate switch on the replacement Rectifier is in the "standby" position.
6. Slide the replacement Rectifier evenly into its mounting position. It should not be necessary to depress the safety latch release. Secure the Rectifier to the bay by tightening the captive fasteners located on the Rectifier.
7. Place the Standby/Operate switch on this Rectifier to the I "operate" position.

8. Enable the external alarms, or notify appropriate personnel that this procedure is finished.
9. Ensure that there are no local or remote alarms active on the system.

Figure 1: 208V and 480V Rectifiers



MCA Circuit Card Replacement

The MCA circuit card is installed in the Primary Power/Distribution Bay and Primary Power Only Bay. Router circuit cards are installed in the Secondary Power/Distribution Bays, Secondary Power Only Bays, and Distribution Only Bays.

Note: Refer to **Figure 2** as this procedure is performed.

Procedure

1. Observe the admonishments presented at the beginning of this section, and those encountered in this procedure.
2. Performing this procedure may activate external alarms. Do one of the following. If possible, disable these alarms. If these alarms cannot be easily disabled, notify the appropriate personnel to disregard any future alarms associated with this system.
3. Replacing the MCA circuit card **WILL** result in all MCA settings being returned to their factory default values. In **Table 4** and **Table 5**, either manually record all existing MCA settings or record the required settings for your site from your company's DC Plant Set Points specifications (standards).



NOTE! The MCA configuration can be saved by downloading the configuration using the LMS Monitoring System (if installed).

4. Refer to the MCA Menu Tree (Section 5886) and the *Navigating the MCA* section to manually record MCA settings.
5. Open the bay's front door to access the MCA circuit card mounting position.



WARNING! Damage to the MCA circuit card may result if the next step is not followed.

6. Connect an approved grounding strap to your wrist. Attach the other end to a suitable ground.
7. Remove fuse F3 that supplies input power to the MCA circuit card. Refer to **Figure 7** for location.
8. With an external voltmeter, verify plant voltage is correct (MCA is powered down at this point).
9. Remove any network cables from the circuit card, noting their locations for re-assembly.
10. Remove the alarm cable connector TB1 from the circuit card. Note that terminal block TB1 consists of two pieces snapped together. The two pieces can be separated by first loosening the two screws; then gently pulling the one half from the other.
11. Loosen the circuit card retaining screw.
12. Remove the circuit card.
13. Set the switches of S1 on the replacement circuit card to match the settings of the removed circuit card.
14. Slide the replacement circuit card into its mounting location, ensuring the rear edge connector is firmly seated.
15. Secure the circuit card by tightening the circuit card retaining screw .
16. Replace fuse F3 which supplies input power to the MCA circuit card. Refer to **Figure 7** for location.

17. The MCA goes through an initialization routine (as detailed in the *Installing the Rectifiers and Initially Starting the System* section of the INSTALLATION INSTRUCTIONS [Section 5877]). During this initialization routine, check (and if required change) the MCA settings for your Site. In lieu of manually entering new MCA settings, if the old MCA configuration was downloaded via the LMS; upload the configuration. Refer to the LMS User Instructions for a procedure.
18. Remove the grounding wrist strap.
19. Close the bay's front door.
20. Enable the external alarms, or notify appropriate personnel that this procedure is finished.
21. Ensure that there are no local or remote alarms active on the system.

Table 4: MCA Basic Settings

Setting	Factory Default Setting	Required Site Setting
Float Output Voltage	52.00V	
Test/Equalize Output Voltage	52.00V	
High Voltage Shutdown	57.50V	
Rectifier Current Limit	100% of Rated Full Load	
High Voltage #1 Alarm	55.50V	
High Voltage #2 Alarm	56.50V	
Battery On Discharge Alarm	51.00V	
Very Low Voltage Alarm	47.00V	
Total Distribution Load Alarm	2000A	
Distribution Group A Load Alarm	2000A	
Distribution Group B Load Alarm	2000A	
High Battery Ambient Temperature #1 Alarm	Off	
High Battery Ambient Temperature #2 Alarm	Off	
Low Battery Ambient Temperature #1 Alarm	Off	
Low Battery Ambient Temperature #2 Alarm	Off	
Digital Temperature Compensation (Slope)	Off (0V/°C)	
Digital Temperature Compensation (Maximum Compensation)	56.50V	
Digital Temperature Compensation (Minimum Compensation)	50.00V	

Table 5: MCA Advanced Setting

Setting	Factory Default Setting	Required Site Setting
MCA Audible Alarm Silent Time Period	15 Minutes	
Manually Initiated Timed Test/Equalize Feature	1 Hour	
Automatic Test/Equalize Feature	Disabled	
Alarm Relay Test Feature	45 Seconds	
MCA Customer Alarm Relays	--	Program as required.

Router Circuit Card Replacement

The MCA circuit card is installed in the Primary Power/Distribution Bay and Primary Power Only Bay. Router circuit cards are installed in the Secondary Power/Distribution Bays, Secondary Power Only Bays, and Distribution Only Bays.



NOTE! Refer to **Figure 2** and **Figure 3** as this procedure is performed.

Procedure

1. Observe the admonishments presented at the beginning of this section, and those encountered in this procedure.
2. Performing this procedure may activate external alarms. Do one of the following. If possible, disable these alarms. If these alarms cannot be easily disabled, notify the appropriate personnel to disregard any future alarms associated with this system.
3. Open the bay's front door to access the Router circuit card mounting position.



WARNING! Damage to the Router circuit card may result if the next step is not followed.

4. Connect an approved grounding strap to your wrist. Attach the other end to a suitable ground.
5. Remove the fuse which supplies input power to the Router circuit card. Refer to **Figure 7** and **Figure 8** for location.
6. Remove any network cables from the circuit card, noting their locations for re-assembly.
7. Loosen the circuit card retaining screw.
8. Remove the circuit card.
9. Slide the replacement circuit card into its mounting location, ensuring the rear edge connector is firmly seated.
10. Secure the circuit card by tightening the circuit card retaining screw.
11. Replace the fuse which supplies input power to the Router circuit card. Refer to **Figure 7** and **Figure 8** for location.
12. Remove the grounding wrist strap.
13. Close the bay's front door.
14. Enable the external alarms, or notify appropriate personnel that this procedure is finished.
15. Ensure that there are no local or remote alarms active on the system.

Figure 2: Power/Distribution Bay MCA/Router Circuit Card Replacement (Power Only Bay Similar)





Figure 3: Distribution Only Bay MCA/Router Circuit Card Replacement



Distribution Bus Monitoring Circuit Card Replacement

Two Distribution Bus Monitoring circuit cards are installed in each Power/Distribution Bay.

Four Distribution Bus Monitoring circuit cards are installed in each Distribution Only Bay.



NOTE! Refer to **Figure 4** and **Figure 5** as this procedure is performed.

Procedure

1. Observe the admonishments presented at the beginning of this section, and those encountered in this procedure.
2. Performing this procedure may activate external alarms. Do one of the following. If possible, disable these alarms. If these alarms cannot be easily disabled, notify the appropriate personnel to disregard any future alarms associated with this system.
3. Open the bay's front door to access the Distribution Bus Monitoring circuit card mounting positions.



WARNING! Damage to the Distribution Bus Monitoring circuit card may result if the next step is not followed.

4. Connect an approved grounding strap to your wrist. Attach the other end to a suitable ground.
5. Remove the fuse that supplies input power to the Distribution Bus Monitoring circuit card. Refer to **Figure 7** and **Figure 8** for location.
6. Open the hinged panel to access to Distribution Bus Monitoring circuit card.
7. Remove the circuit card.
8. Slide the replacement circuit card into its mounting location, ensuring the rear edge connector is firmly seated.
9. Close the hinged panel.
10. Replace the fuse which supplies input power to the Distribution Bus Monitoring circuit card. Refer to **Figure 7** and **Figure 8** for location.
11. Remove the grounding wrist strap.
12. Close the bay's front door.
13. Enable the external alarms, or notify appropriate personnel that this procedure is finished.
14. Ensure that there are no local or remote alarms active on the system.

Figure 4: Power/Distribution Bay Distribution Bus Monitoring Circuit Card Replacement





Figure 5: Distribution Only Bay Distribution Bus Monitoring Circuit Card Replacement



MCA Customer Alarm Relay Circuit Card Replacement

Refer to the Installation Procedure detailed in the *Installation Instructions* (Section 5876).

MCA I/O Circuit Card Replacement

Refer to the Installation Procedure detailed in the *Installation Instructions* (Section 5876).

Alarm, Reference, and Control Fuse Replacement

If an alarm, reference, or control fuse opens; replace with the same type and rating, or equivalent. Refer to SAG582140000 for fuse replacement part numbers. Refer to **Figure 7** and **Figure 8** for alarm, reference, and control fuse locations.

Rectifier: The input of each Rectifier contains double pole/neutral fusing. This fusing is not customer replaceable. If a fuse opens, replace the entire Rectifier. An open fuse causes the Rectifiers Rectifier fail alarm circuit to activate. The input fuses have higher amperage ratings than the recommended external branch circuit protection.

Distribution Fuses: If a distribution fuse opens, the associated alarm-type fuse opens to activate the fuse alarm circuit. Replace the distribution fuse before replacing the alarm-type fuse.

Safety Fuse Covers: Safety fuse covers are provided for all alarm-type fuses installed in the system. These covers snap onto the fuses and provide protection from exposed electrical terminations when a fuse opens. Insure that the safety fuse cover is installed after replacing a fuse. Refer to **Figure 6** for installation details. Note that there are different types of safety fuse covers for the different brand alarm-type fuses.

Figure 6: *Installation of Safety Fuse Covers*






Figure 7: Power/Distribution Bay Fuse Locations (Power Only Bay Similar)




LMS / DIST / MCA



F1 F2 F3
3A 3A 3A

Figure 8: Distribution Only Bay Fuse Locations



Rectifier Fan Replacement

The rectifier fans are not field-replaceable. If a fan fails, replace the rectifier as described in this section.



CAUTION! In a system with NO redundant Rectifier Module, battery must have sufficient reserve to power the load(s) while the Rectifier Module is removed.

Adding a Battery Charge Digital Temperature Compensation Probe to a Previously Operated System

This procedure details the steps to add a Battery Charge Digital Temperature Compensation Probe to a system that has been previously started, configured, and checked.

Procedure

1. Refer to the separate Installation Manual, “Making Electrical Connections” section, and mount the Battery Charge Digital Temperature Compensation Probe near the batteries.
2. Refer to the separate Installation Manual, “Making Electrical Connections” section, and connect the Battery Charge Digital Temperature Compensation Probe to the system. The MCA automatically detects the probe and adds it to the inventory without any alarms. The default slope setting is NO TEMPERATURE COMPENSATION.
3. Refer to “MCA System Adjustments” section of these instructions, and set the following digital battery charge temperature compensation parameters: SLOPE, MAXIMUM COMPENSATION, and MINIMUM COMPENSATION.
4. Refer to “MCA System Adjustments” section of these instructions, and set the following alarm parameters: HIGH TEMPERATURE #1 ALARM, HIGH TEMPERATURE #2 ALARM, LOW TEMPERATURE #1 ALARM, and LOW TEMPERATURE #2 ALARM.
5. Verify that battery charge temperature compensation has begun by comparing the SYSTEM voltage reading versus the FLOAT setting. Depending on the battery ambient temperature, the SYSTEM voltage should be higher or lower than the FLOAT setting by the amount of slope V/°C (note that SYSTEM voltage will also vary from the FLOAT setpoint depending on the load).



NOTE! At 25°C, the battery charge temperature compensated SYSTEM voltage equals the FLOAT voltage setting.



NOTE! If the probe is disconnected or fails, a major alarm (local and extended) activates and the system returns to the FLOAT voltage setting.

Removing a Battery Charge Digital Temperature Compensation Probe from a Previously Operated System

This procedure details the steps to remove a Battery Charge Digital Temperature Compensation Probe from a system that has been previously started, configured, and checked.

Procedure

1. In the Configure Menu, set the SLOPE = 0.vvvV°C/F to NO TEMPERATURE COMPENSATION. Temperature Compensation stops and the System returns to the FLOAT voltage setting.
2. Remove the probe. The Major Alarm activates. Update inventory to clear this alarm, as described in this section.



Vertiv.com | Vertiv Headquarters, 1050 Dearborn Drive, Columbus, OH, 43085, USA

© 2021 Vertiv Group Corp. All rights reserved. Vertiv™ and the Vertiv logo are trademarks or registered trademarks of Vertiv Group Corp. All other names and logos referred to are trade names, trademarks or registered trademarks of their respective owners. While every precaution has been taken to ensure accuracy and completeness here, Vertiv Group Corp. assumes no responsibility, and disclaims all liability, for damages resulting from use of this information or for any errors or omissions. Specifications, rebates and other promotional offers are subject to change at Vertiv's sole discretion upon notice.