



**Liebert® GXT5™**

**Firmware Update Procedure**

**16-20K I Models**

The information contained in this document is subject to change without notice and may not be suitable for all applications. While every precaution has been taken to ensure the accuracy and completeness of this document, Vertiv assumes no responsibility and disclaims all liability for damages resulting from use of this information or for any errors or omissions. Refer to other local practices or building codes as applicable for the correct methods, tools, and materials to be used in performing procedures not specifically described in this document.

The products covered by this instruction manual are manufactured and/or sold by Vertiv. This document is the property of Vertiv and contains confidential and proprietary information owned by Vertiv. Any copying, use or disclosure of it without the written permission of Vertiv is strictly prohibited.

Names of companies and products are trademarks or registered trademarks of the respective companies. Any questions regarding usage of trademark names should be directed to the original manufacturer.

## Technical Support Site

If you encounter any installation or operational issues with your product, check the pertinent section of this manual to see if the issue can be resolved by following outlined procedures.

Visit <https://www.vertiv.com/en-us/support/> for additional assistance.

## 1. Overview

The GXT5 UPS firmware is easily updated by downloading zip files from the Vertiv website to your computer and then using one of two methods to update the UPS detailed in this document.

- Web interface on the IntelliSlot RDU101 communication card. (Recommended) [Section 3](#)
- Command line interface using a serial connection to the RS-232 port of the UPS. [Section 4](#)


## 2. Preparation

- 2.1 Reserve approximately 10-15 minutes for this update procedure.
- 2.2 If your UPS has a serial number with the first five digits of 20305\*\*\*\*\* or higher, the UPS output will remain on throughout the update. **If your UPS has a serial number with the first five digits of 20304\*\*\*\*\* or lower, make preparations for the UPS connected equipment to be shut down during the update, as the UPS needs to cycle power to its outlets to complete.** If you have an external Maintenance Bypass Cabinet, follow the instructions included with the cabinet to switch to maintenance bypass prior to the update to keep the connected equipment powered directly by utility.
- 2.3 Power the UPS by the nominal utility AC input source during the update. Battery mode cannot be used. Be sure there are no expected utility outages during the update. If a utility outage happens during the update, the update needs to be restarted.
- 2.4 Download to your computer and unzip the latest update zip file from the [Vertiv website](#) to be used for the update.

## 3. Updating Firmware with RDU101 Card Connection

- 3.1 Connect network
  - 3.1.1 Connect a network cable to the RJ-45 Ethernet port of the RDU101 card indicated in Figure 1. For detailed operating instructions for the card, refer to the RDU101 Communications Card Installer/User Guide, available [here](#).
  - 3.1.2 On a computer connected to the same network as the UPS, open a browser window and enter the IP address of the RDU101 card in the address bar. You can get the card's IP address from the UPS LCD. Select the About menu then the Product tab and locate IPv4 address. You may need to scroll up or down to find the correct field. Alternatively, contact your network administrator for the IP address assigned UPS.

Figure 1 – Network connection to RDU101




- 3.2 Confirm Bypass Disabled alarm is not active
  - 3.2.1 On the RDU101 web interface, select the GXT5 tab at the top of the page.
  - 3.2.2 Click the Active Events folder in the tab-menu on the left side of the page. Confirm that Bypass Disabled is not shown. If Bypass Disable is shown, see [Appendix A](#). If it is not, proceed to the next step.

### 3.3 Determine Current UPS Firmware Version

3.3.1 On the RDU101 web interface, select the *GXT5* tab at the top of the page.

3.3.2 Click the *File Transfer* folder in the tab-menu on the left side of the page. The current firmware versions will be displayed at the top of the page. Take note of the MCUVXXX version.

**Figure 2 – File Transfer page on the RDU101 Web Interface**



### 3.4 Transfer to Maintenance Bypass if available

If the first five digits of the serial number are 20305\*\*\*\*\* or higher, this step is not necessary. The UPS output will remain powered throughout the update.

If the first five digits of the serial number are 20304\*\*\*\*\* or lower and you have an external Maintenance Bypass Cabinet, follow the instructions included with the cabinet to switch to maintenance bypass prior to the update to keep the connected equipment powered directly by utility.

### 3.5 Remove REPO Terminal Block

If the first five digits of the serial number are 20305\*\*\*\*\* or higher, this step is not necessary. The UPS output will remain powered throughout the update.

If the first five digits of the serial number are 20304\*\*\*\*\* or lower, remove the small green terminal block labeled REPO on the rear panel, see Figure 1. **Reminder: This will turn off the UPS output if you did not transfer to maintenance bypass.** See [Section 2.2](#) for details.

### 3.6 Firmware File Transfer to UPS

With the 5.30.2020 firmware release (UPS firmware version MCV180), Vertiv has put in place a security enhancement to only allow Vertiv authentic encrypted firmware files to be transferred to the UPS. Therefore, when updating UPS firmware that is older than the 5.30.2020 release (UPS firmware versions MCV170, MCV160, etc.), it will be necessary to first update the UPS to this secure method, and then repeat the update to the latest version. The secure update file is included with each zip download and is named *GXT5LA-EncryptedUpdate-16-20k-I.bin*.

3.6.1 On the *File Transfer* page, click *Choose File*, select the upgrade file, and click *Transfer file*.

3.6.2 Enter the Username and Password, then click *Login*. The username and password may have been changed from the default. If so, contact your company's administrator for credentials.

The factory defaults are:

Username: Liebert (case-sensitive)

Password: Liebert (case-sensitive)

3.6.3 Confirm the Firmware Transfer Status field first changes to Image Transferring and then cycles through additional status. Do not leave or close this page.

3.6.4 Confirm after approx. 5 mins the Firmware Transfer Status field changes to Update complete, the UPS restarts, and the web page refreshes after the restart.

3.6.5 Confirm both firmware versions on the File Transfer page match the file loaded.

### 3.7 Reinstall the REPO Terminal Block If Removed

### 3.8 Transfer the UPS to Normal Operation

3.8.1 If the UPS was transferred to Maintenance Bypass, transfer back to Normal Operation.

## 4. Updating Firmware with a CLI Connection

You can use the GXT5 command-line interface to update firmware with a computer connected to the RS-232 (RJ-45) port on the rear of the UPS.

### 4.1 Preparation

To perform the update via CLI, you need the following:

- Serial-terminal emulator with Ymodem file transfer capability (for example: ExtraPuTTY)
- RJ-45-to-DB9 serial cable or RJ-45-to-USB serial-to-USB adaptor cable



### 4.2 Serial Connection

- 4.2.1 Connect the RJ-45 connector to the RS-232 port on the UPS. This may be labeled RS-232 or R232 depending on model. See Figure 3 for port location.
- 4.2.2 Connect the DB9/USB connector to the computer with the serial-terminal emulator installed.

Figure 3 – RS-232 Port



### 4.3 Determine Current UPS Firmware Version

- 4.3.1 Determine the version of MCU firmware currently running on the UPS using the UPS LCD by selecting the About menu, then the Product tab, and locate the *Monitor FW version* (MCU) and *DSP FW version* (DSP). You may need to scroll up or down to find the correct field.

### 4.4 Confirm Bypass Disabled alarm is not active

- 4.4.1 On the UPS LCD, select the Log, and confirm that Bypass Disabled is not active in the Current tab. If Bypass Disable is shown, see [Appendix A](#). If it is not, proceed to the next step.

#### 4.5 Transfer to Maintenance Bypass

If the first five digits of the serial number are 20305\*\*\*\*\* or higher, this step is not necessary. The UPS output will remain powered throughout the update.

If the first five digits of the serial number are 20304\*\*\*\*\* or lower and you have an external Maintenance Bypass Cabinet, follow the instructions included with the cabinet to switch to maintenance bypass prior to the update to keep the connected equipment powered directly by utility.

#### 4.6 Remove REPO Terminal Block

If the first five digits of the serial number are 20305\*\*\*\*\* or higher, this step is not necessary. The UPS output will remain powered throughout the update.

If the first five digits of the serial number are 20304\*\*\*\*\* or lower, remove the small green terminal block labeled REPO on the rear panel, see Figure 3. **Reminder: This will turn off the UPS output if you did not transfer to maintenance bypass.** See [Section 2.2](#) for details.

#### 4.7 Firmware File Transfer to UPS

With the 5.30.2020 firmware release (UPS firmware version MCUV180), Vertiv has put in place a security enhancement to only allow Vertiv authentic encrypted firmware files to be transferred to the UPS.

Therefore, when updating UPS firmware that is older than the 5.30.2020 release (UPS firmware versions MCUV170, MCUV160, etc.), it will be necessary to first update the UPS to this secure method, and then repeat the update to the latest version. The secure update file is included with each zip download and is named *GXT5LA-EncryptedUpdate-16-20k-l.bin*.

4.7.1 Open the serial-terminal emulator and adjust the settings to communicate with the UPS. Select *Serial* connection for the session.

4.7.2 Check the computer *Device Management* settings to determine the correct the communication port (for example, COM6) and select it in the emulator.

4.7.3 Select 115200 for the connection speed and open the terminal emulator session.

4.7.4 On the CLI, enter the username and password. The username and password may have been changed from the default. If so, contact your company's administrator for credentials.

The factory defaults are:

Username: user (case-sensitive)

Password: 123456 (case-sensitive)


4.7.5 On the command line, enter *update*, then press *d* on the keyboard, see Figure 4 on the next page.

4.7.6 In the menu bar, select *Files Transfer*, then *Ymodem*, select the upgrade file, and click *Send*.

4.7.7 The status of the transfer displays in a status dialog. After about 5 minutes, the UPS restarts and the CLI exits update mode. Do not close the status dialog.

4.7.8 After the UPS restarts, confirm both firmware versions on the UPS LCD *About* menu *Product* tab match the file loaded.

Figure 4 - File Transfer with the CLI





## Appendix A – Firmware Update with Bypass Disabled


If the UPS output is on, it must switch to bypass during the update process. The update may also be performed with the UPS output off. If bypass is disabled, it is recommended to simply turn off the output, perform the update, and turn the output back on. You may also wish to consider changing the Frequency selection setting to enable the bypass while the UPS is off so that any future updates may be done remotely and with the output remaining on. To adjust this setting, you must have physical access to the UPS LCD and output must be turned off.

To turn off the UPS output:

1. Power must be removed from all connected devices to perform the update with Bypass Disabled. You may wish to gracefully shutdown the devices manually now rather than remove power from them by turning off the UPS.
2. Turn the UPS output OFF by holding the Power button, selecting *Turn off output*, and then selecting *Yes* to confirm. Reminder: This will remove power from all connected devices.

To change the Frequency Selection setting and enable the bypass:

1. From the flow screen, press Enter to go to the main menu.
2. Use the arrow keys to select Settings and press Enter. A password prompt will pop up.



3. Enter the password for the settings menu using the up arrow to increase the current digit and the down arrow to move to the next digit. The default password is 111111.
4. Press Enter to select the Output tab.
5. Use the arrow keys to select *Frequency selection* and press Enter.
6. Change the setting value to *Auto, bypass enabled* and press Enter to save your selection.
7. Use the Esc key to return to the flow screen.

To turn on the UPS output:

1. Turn the UPS output ON by holding the Power button, selecting *Turn on UPS*, and then selecting *Yes* to confirm.



© 2022 Vertiv Group Corp. All rights reserved. Vertiv™ and the Vertiv logo are trademarks or registered trademarks of Vertiv Group Corp. All other names and logos referred to are trade names, trademarks, or registered trademarks of their respective owners. While every precaution has been taken to ensure accuracy and completeness here, Vertiv Group Corp. assumes no responsibility, and disclaims all liability, for damages resulting from use of this information or for any errors or omissions. Specifications, rebates, and other promotional offers are subject to change at Vertiv's sole discretion upon notice.

GXT5\_LAFW\_16-20K\_I\_REV1\_05-2022