

## Dacobas Advanced Basic Assemblies



Dacobas Advanced Basic Assemblies		Order number	
Type	Depth D	Straight	Lowered
linear	1050	01.329.220.9	01.329.200.9
45°	1050	01.329.222.9	01.329.202.9
90°	1050	01.329.223.9	01.329.203.9
90° Trapezoid	1050	01.329.224.9	01.329.204.9
R3000 Circular	1050	01.329.225.9	01.329.205.9
linear	1200	01.329.260.9	01.329.240.9
45°	1200	01.329.262.9	01.329.242.9
90°	1200	01.329.263.9	01.329.243.9
90° Trapezoid	1200	01.329.264.9	01.329.244.9
R3000 Circular	1200	01.329.265.9	01.329.245.9

- In order to bring quotations faster to your desk and to make Dacobas Advanced easily understandable you will find below a helpful overview of the most common Basic Assemblies.
- Each Basic Assembly consists of Starter-, End- and Link Up-Side Elements as well as the respective number of Basic Frames.

## Dacobas Advanced Basic Assemblies

- Planning, configuration and order of any setup should always start with one of the below Basic Assemblies.
- The next step is to choose the right quantities of Link Up Side-Elements, Basic Frames, Cover Panels, Doors, Worktops and completing the setup with accessories.
- When extending a Basic Assembly with further Basic Frames, the second End-Side Element moves to the End of the row.

### Linear Basic Assemblies

- Linear Basic Assemblies always consist of two Basic Frames W1230, one Start-, one Link Up- and one End-Side Element. Starting from W630, any shorter or longer Basic Assemblies can be created from a corresponding selection of W630 or W1230 Basic Frames.

### 45°-Basic Assemblies

- 45°-Basic Assemblies consist of two Basic Frames W1230, one Start-, two Link Up and one End-Side Element as well as front and rear 45°-Cover Panels.

### 90°-Basic Assemblies

- 90°-Basic Assemblies consist of two Basic Frames W1230, one Start- and one End-Side Element, one 90° Corner Element.

### 90°-Trapezoid-Basic Assemblies

- 90°-Trapezoid-Basic Assemblies consist of two Basic Frames W1230, one Start- and one End-Side Element, one 90°-Trapezoid Corner Element with 600mm front edge.

### Circular Basic Assemblies

### How supplied

- Preamsembled modules

### Please note

All of the above Basic Assemblies and corresponding worktops can be extended to up to 3600mm at a stretch. Instead of the before mentioned basic frames W 1230 mm you can also use basic frames W 630 mm!

### Further helpful accessories as

- Cable Management
  - Power Strips
  - Lighting
  - Seating and Ambient Furniture
- can be found in our catalogues.