

## Dacobas Advanced Perforated Rear Panels



Dacobas Advanced Perforated Rear Panels				Order number
Type	Height H [mm]	Width W [mm]	Depth D [mm]	Straight
<b>Perforated rear panel</b>	350	630		<b>01.329.160.9</b>
	350	1230		<b>01.329.165.9</b>
	350		1050	<b>01.329.170.9</b>
	350		1200	<b>01.329.172.9</b>
	350		1050	<b>01.329.180.9</b>
	350		1200	<b>01.329.182.9</b>
	450	630		<b>01.329.161.9</b>
	450	1230		<b>01.329.166.9</b>
	450		1050	<b>01.329.171.9</b>
	450		1200	<b>01.329.173.9</b>
	450		1050	<b>01.329.181.9</b>
	450		1200	<b>01.329.183.9</b>
<b>IM Profile extension</b>	350			<b>01.329.175.9</b>
	450			<b>01.329.176.9</b>
	700			<b>01.329.177.9</b>
	800			<b>01.329.178.9</b>
	900			<b>01.329.179.9</b>

- Perforated rear panels fit W630 and W1230 Basic Frames, 45°, 90° and 90° Trapezoid Corners
- Perforation: 8 mm in 25 mm pattern
- Privacy screen for monitors and monitor cables
- Vertical profiles to be connected in line with Basic Frame's vertical profiles

## Dacobas Advanced Perforated Rear Panels

### Material / Finish

- Sheet steel perforated rear panel and extruded aluminium profile, powdercoated, RAL 6009  
White aluminum

### Supply schedule

1 Perforated Rear Panel resp. IM profile  
Mounting material

### How supplied

- Preassembled modules

### Please note

Chose H350 Rear Panels and Profile Extensions in combination with one story Monitor Mounts and straight worktops.

These can be combined seamlessly with H450 Rear Panels and Profile Extensions which fit with lowered Monitor Levels.

For two story Monitor Mounts, just add a second line of H350 Rear Panels and use H700 Profile Extensions or H800 Profile Extensions for Consoles with lowered Monitor Levels.