# Vertiv<sup>™</sup> Geist<sup>™</sup> Temperature Sensor



Quick Installation Guide

## Part Number:

Geist<sup>™</sup> Temperature Sensors

SRT-12, SRT-20, SRT50, and SRT-100

### Description

TheSRT sensor probe is used to monitor temperature in critical environments.

**NOTE:** The SRT sensor and cable assembly can span atotal cable distance up to 600 ft from the Geist™ environmental monitoring device. There is one sensor with several standard cable lengths. The standard temperature probe measures 1.25 inches (3.18 cm) in length.


### Installation

- 1. Mount the temperature sensor anywhere in the data center with zip ties or Velcro tape.
- Plug the uplink cable into the sensor port (RJ12/Q) of the Geist™ environmental monitoring deviceor rack PDU.

Once connected, the Geist™ environmental monitoring device automaticallydetectsandidentifiesthe sensor.



#### **Typical Error Curve**





#### To contact Vertiv Technical Support: visit www.Vertiv.com

©2022VertivGroupCorp.Allrightsreserved.Vertiv<sup>™</sup>andtheVertivlogoaretrademarksorregisteredtrademarksofVertivGroupCorp.Allothernamesandlogosreferredtoaretradenames,trademarksorregistered trademarksoftheirrespectiveowners.Whileeveryprecautionhasbeentakentoensureaccuracyandcompletenesshere,VertivGroupCorp.assumesnoresponsibility,anddisclaimsallliability,fordamagesresultingfrom use of this information or for any errors or omissions. Specifications, rebates and other promotional offers are subject to change at Vertiv's sole discretion upon notice.

