IMPORTANT NOTICE





SAVE THESE INSTRUCTIONS

- For installation/operation instructions, scan the QR code or visit the following web page:
 <u>https://www.vertiv.com/en-emea/products-catalog/critical-power/static-transfer-switches/vertiv-powerswitch-7000-static-transfer-switch/</u>
- Refer the Vertiv[™] PowerSwitch 7000 Installer/User Manual for more information such as:
 - Instructions on how to install power and control wiring.

NOTE: Upstream over-current protection is required.

- Field wire sizes (including maximum sizes), temperature rating, and routing information.
- Voltage and current specifications for all control circuit wiring.

NOTE: Always use a minimum of 300 V rated wire for all control wire connections.

- The unit is intended to be professionally installed by properly trained and qualified service personnel.
- This unit is intended for installation in a temperature-regulated, indoor area that is relatively free of conductive contaminants, and dust.
- Do not walk, stand, or sit on top of the unit. Remove conduit plates/top hats from the unit prior to any cutting, drilling, or punching. Clean and remove all metallic shavings, burrs, and debris before re-installation of conduit plates/top hats to the unit.
- The feet must make firm contact with floor.

NOTE: Refer to the user manual if installing the unit with floor stands.

- Refer to the project submittal drawings for required cooling and service clearances.
- Documentation can be obtained from at <u>www.Vertiv.com</u> or in the user manual accessible via the QR code located on this page.

