

Alber™ Battery Xplorer Enterprise Software



Quick Installation Guide

This guide provides instructions for preparing, installing and configuring the Alber Battery Xplorer Enterprise (BXE) software.

Two setup types for installing the Alber BXE software components are available. These components can be installed on a single computer using the Complete installation setup type or installed separately on multiple computers using the Custom installation setup type.

NOTE: Use the Custom installation setup type for installing specific software components on multiple computers. Steps 4 and 5 may be on different computers if the Custom installation setup type is used.

1. Preparing for installation

Review and ensure your system complies with the Alber BXE hardware and software system requirements.

2. Installing and configuring Internet Information Services (IIS)

If IIS is not already installed, install and configure IIS.

NOTE: If Custom installation setup type is used, only install IIS where the Alber Battery Xplorer Web component is installed.

In the Windows features, verify that you have Windows Authentication checked in the Security group.

3. Running the software installer

Install the Alber BXE Monitoring application software.

4. Running the Web Application Manager (WAM)

Configure the database, the Web settings and connections required for the application to function properly.

5. Running the Database Import Manager (DIM)

Import your device configuration or existing database of battery information to the application.

6. Running the Monitor Service Manager (MSM)

Configure the MSM software through device monitor assignments in the application.

7. Running the Alber BXE application

Double-click the Battery Xplorer Enterprise Website desktop icon. When accessing the Alber BXE software for the first time, the application goes into initialization mode.

The owner/system administrator is required to enter the administrator account information before logging into the system. The owner will have access rights to add users and their roles.

8. Activating the Alber BXE features

The Alber BXE monitoring system features require activation keys that allow certain features to be activated within the software application.

In order to receive activation keys to turn on your Alber BXE features, you must register by contacting customer service. Locate your Purchase Order number and Installation Key in the Features Activation Manager page and contact customer service 1-800-543-2378 or email customerservice-request@vertiv.com.

NOTE: The application comes with an automatic 30-day demo license key that is activated at time of software installation.

For additional product or installation information, refer to the Vertiv™ Alber™ BXE product page on www.Vertiv.com.



To contact Vertiv Technical Support: visit www.Vertiv.com

© 2025 Vertiv Group Corp. All rights reserved. Vertiv™ and the Vertiv logo are trademarks or registered trademarks of Vertiv Group Corp. All other names and logos referred to are trade names, trademarks or registered trademarks of their respective owners. While every precaution has been taken to ensure accuracy and completeness here, Vertiv Group Corp. assumes no responsibility, and disclaims all liability, for damages resulting from use of this information or for any errors or omissions.

