


Managed Rack PDU MPH2™ / Basic Rack PDU MPE™

Mounting Options in Knürr DCM® Rack




The PDUs can be installed in Knürr DCM® rack in different ways using various mounting brackets:

- ① **MPH2 SpeedMount InstKit DCM H2000** – order no. **03.951.405.0.001** (kit includes: 1 bottom bracket, 1 upper bracket)
- ② **Mounting Kit Z-Shape** – order no. **03.951.406.0.001** (kit includes: 2 brackets, 2 spring nuts, 2 screws)
- ③ **Mounting Kit Standard** – supplied with the PDU (kit includes: 2 brackets (a), 4 spring nuts + screws, 2 mounting buttons (b) + screws)
- ④ **PDU Mounting Kit Short** – order no. **01.147.813.9** (kit includes: 2 brackets, 4 spring nuts + washers + screws, 4 cage nuts + screws)
- ⑤ **PDU Mounting Kit Long** – order no. **01.147.814.9** (kit includes: 2 brackets, 4 spring nuts + washers + screws, 8 cage nuts + screws)



Based on the PDU length and rack height, you can choose the mounting method which best suits your needs.

MPH2/MPE Length [mm]	Rack Height 2000 mm			
	Fixed Installation		Toolless Installation	
916.5	<p>③a + ④</p>	<p>③a + ⑤</p>	<p>③b + ④</p>	<p>③b + ⑤</p>
1004	same as above (length 916.5 mm)		same as above (length 916.5 mm)	
1736.5	<p>②</p>	<p>③a</p>	<p>①</p>	



MPH2/MPE Length [mm]	Rack Height 2200 mm	
	Fixed Installation	Toolless Installation
916.5	3a + 4 or 5 (same as at rack H2000)	3b + 4 or 5 (same as at rack H2000)
1004	3a + 4 or 5 (same as at rack H2000 / PDU L916.5)	3b + 4 or 5 (same as at rack H2000 / PDU L916.5)
1736.5	3a + 4 or 5 (same as at rack H2000 / PDU L916.5)	3b + 4 or 5 (same as at rack H2000 / PDU L916.5)
1826.5	3a + 4 or 5 (same as at rack H2000 / PDU L916.5)	3b + 4 or 5 (same as at rack H2000 / PDU L916.5)